




# ACCUTOME



## Accutome A-Scan Plus

24-4216

Revision A

User's Guide

**Federal law restricts this device to sale by or on the order of a physician.**

**FEDERAL COMMUNICATIONS COMMISSION (FCC)  
UNINTENTIONAL EMITTER PER FCC PART 15**

This device has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in an office installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions in the user manual, may cause harmful interference to radio or television reception. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause interference to radio and television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a different circuit from that to which the receiver is connected.
- Consult Accutome Ultrasound, Inc. or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation of this product is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

**CAUTION:**

Changes or modifications not expressly approved by Accutome Ultrasound, Inc. could void the FCC compliance and negate your authority to operate the product.

Authorized Representative in Europe (for regulatory affairs only):



0086



EMERGO EUROPE  
Molenstraat 15  
2513 BH, The Hague  
The Netherlands

# Table of Contents

<b>Chapter 1: Introduction</b> .....	1
Accutome A-Scan Plus Overview.....	1
Features.....	2
Measurements.....	2
IOL Calculations.....	3
Components.....	3
Optional Components.....	4
About this Manual.....	4
<b>Chapter 2: Safety</b> .....	6
Safety Information.....	6
Safety Issues to Consider When Using the Accutome A-Scan Plus.....	6
Indications for use.....	6
Symbols Definitions for the Accutome.....	7
Safety Precautions.....	8
Sterilization.....	8
Disinfection and Cleaning.....	9
Electrical Hazard and Safety.....	10
Avoiding Equipment Damage.....	10
Avoiding Electromagnetic and Other Interference.....	11
ALARA Principle.....	11
<b>Chapter 3: Getting Started</b> .....	12
Assembling the Accutome A-Scan Plus.....	12
What you need.....	12
Probe.....	13
Footswitch.....	13
Battery Specification and Installation.....	13
Placing the Accutome A-Scan Plus.....	14
Quick-Close Kickstand.....	14
Mounting.....	15
Connecting the Components.....	15
Connecting the Footswitch.....	16
Connecting the Power.....	16
Connecting the Ethernet Connection.....	17

Connecting the USB Keyboard and USB disk.....	17
Connecting the RS232 Connector.....	17
Connecting the Probe.....	18
<b>Probe Setup.....</b>	<b>19</b>
Accutome Ultrasonic Probe Kit.....	20
Accutome Probe with Goldman Tonometer Adapter.....	21
Accutome Probe with Handle Extension.....	22
<b>Basic Operation.....</b>	<b>24</b>
How to Power On the Accutome A-Scan Plus.....	24
How to Adjust the Contrast.....	25
Using the Test Block.....	26
Preparation of Patient for Examination.....	27
How to Start a New Patient.....	27
How to Enter Text without a Keyboard.....	31
Screen Keyboard Features.....	32
Entering a Patient with the Screen Keyboard.....	33
How to Take a Measurement.....	34
How to Perform a Calculation.....	36
How to Print a Records.....	41
How to Save Patient Records.....	41

<b>Chapter 4: How to Use the Buttons and Screens.....</b>	<b>43</b>
Overview.....	43
<b>Accutome A-Scan Plus Buttons.....</b>	<b>44</b>
DedicatedButtons.....	44
MeasureButton.....	45
Patient Record Button.....	45
Calculate.....	45
Preferences.....	45
Print.....	46
Check or Affirmative ( ✓ ).....	46
Negative or Delete (X).....	46
Soft Menu Buttons.....	46
Buttons that Toggle between Two Selections.....	47
Buttons that Display Other Screens or Soft Menus.....	47
Accutome A-Scan Plus Knob.....	47
How the Knob Works.....	47
<b>Screens.....</b>	<b>47</b>
What the Screen Displays.....	48

Types of Information.....	48
Soft Menus.....	48
Tips.....	48
Sounds.....	48
Error Messages.....	49
Moving between Screens.....	49
Screen Hierarchy.....	49
High Level Screen Buttons.....	50
Top Level Screens.....	50
Associated Sub-Level Screens.....	50
From the Measure Screen.....	50
From the Patient Records Screen.....	51
From the Preferences Screen.....	51
How Buttons, Screens and Knob Work Together.....	51
Changing Fields and Table Cells.....	51
Changing Fields and Table Cells.....	51
Active Area.....	52
TextEntry.....	52
Selecting a New Active Area.....	52
Changing Fields in the Active Area.....	52
Pre-entered Fields.....	52
Fields Requiring Information.....	53
Numeric Fields.....	53
Keyboard Shortcuts.....	53
Using the Footswitch.....	55
Setting Up the Accutome A-Scan Plus.....	56

<b>Chapter 5: Preferences.....</b>	<b>56</b>
How to Access Preferences.....	57
Top Level of Preferences.....	58
How to Add a New Eye Type.....	59
Adding a New Lens Material.....	60
Assigning a Velocity to the New Lens Material.....	62
Adding the New Eye Type Information.....	63
Eye Type Screen Menu Selections.....	69
Reset Field to Factory.....	69
Reset All to Factory.....	72
More Settings.....	74
Setup Screen Fields.....	74

Setup Screen Soft Menu.....	75
How to Set the Printer.....	76
How to Set the Print Title.....	89
How to Select Automatic or Manual Network Address.....	93
How to Adjust the Contrast.....	96
How to Set the Default Patient Eye Type.....	100
How to Set the Default ID.....	103
How to Set the Default Gain.....	106
How to Set the Target Refraction.....	108
How to Set the K Index.....	111
How to Set the IOL Step.....	114
How to Activate the Network Folder.....	118
Configure Network Folder.....	119
Testing Network Connection on the A-Scan Plus.....	123
Connect to the PC folder.....	123
Troubleshooting the problems.....	123
How to Adjust the Date and Time.....	124
How to Set the Auto Mode.....	127
Sound On/Sound Off.....	133
Restart On/Restart Off.....	133
Scr Save On/Scr Save Off.....	133
Save and Restore Factory Default Gates and Threshold.....	134
About This Unit.....	134
Overview.....	136

<b>Chapter 6: Performing Measurements.....</b>	<b>136</b>
MeasureScreen.....	137
Information Displayed on the Measure Screen.....	138
Soft Menu Selections.....	138
Starting a New Patient.....	139
How to Set the Eye Type.....	139
Eye Types.....	139
Eye Type Materials and Velocities.....	140
Table 6-1 Eye Types.....	140
Table 6-2 Lens Materials and Velocities.....	140
Table 6-3 Anterior/Vitrous Materials and Velocities.....	140
Setting the Eye Type.....	141
<b>Probe Application Methods.....</b>	<b>143</b>
Immersion.....	143
Contact.....	144

Capture Modes.....	144
Auto Mode.....	144
Manual Mode.....	145
How to Capture a Waveform.....	145
Using the Footswitch.....	145
Using the Running/Frozen Button.....	145
Using the Measure Button.....	146
How to Select a Measurement.....	146
Selecting a Measurement with the Knob.....	146
Selecting a Measurement Using Waveform Review Menu.....	147
Selecting a Measurement with the Footswitch.....	148
How to Delete a Measurement.....	149
Deleting a Measurement with X Button or Keyboard.....	149
Deleting a Measurement with the Footswitch.....	149
How to Adjust Gates/Threshold.....	149
AvailableGates/Threshold.....	150
SelectingGates/Threshold.....	151
Waveform Review Menu.....	152
How to Adjust the Cornea Gate.....	152
How to Adjust the Anterior Lens Gate.....	153
How to Adjust the Posterior Lens Gate.....	155
How to Adjust the Retina Gate.....	156
How to Apply Gate Adjustments to All Wavefor.....	158
How to Adjust the Gain.....	159
How to Use Zoom.....	161
How to Scroll.....	162
Switching Eyes.....	164
Customize Eye Type.....	164
Overview.....	165
PatientCustomization.....	165
<b>Chapter 7: Customizing Eye Types.....</b>	<b>165</b>
Customize Eye Type Screen.....	166
Customize Fields and Menu Selections.....	166
OD.....	166
OS.....	166
Eye Type Table.....	166
AC.....	166
Lens.....	166

VC.....	166
How to Customize an Eye Type.....	167
Overview.....	174
Calculating the Lens.....	174
Calculation after Corneal Refractive Surgery .....	174

## **Chapter 8: Performing Calculations..... 174**

Calculate IOL Screen.....	176
Selecting an IOL Group.....	177
Selecting a Formula.....	177
Entering an ACD Value with the Haigis Formula.....	177
Changing the AXL Value.....	178
Selecting a Measurement.....	178
Entering an AXL Value.....	179
Entering the K1, K2 Values.....	179
Entering the K1, K2 Values.....	181
Calculation Results.....	181
Formula Compare Feature .....	182
Switching Between OD/OS.....	183
Calculating IOL Power After Corneal Refractive Surgery.....	184
Double K Method.....	184
Determining Corneal Power after Refractive Surgery.....	185
Post Rx Surg IOL Calculation Steps .....	185
Changing Rx Surg Field to Yes.....	186
Clinical History Method.....	187
Clinical History Fields.....	187
Contact Lens Method.....	188
Shammas Clinical Method .....	189
Calculation Results.....	190
Switching Between OD/OS.....	190

## **Chapter 9: Setting Up IOL Groups..... 191**

How are IOL Groups Used.....	191
How to Set Up an IOL Group.....	191
IOL Calculation Groups Screen.....	192
Entering IOL Group Names.....	193
Entering the Group's Lenses.....	194



<b>Chapter 10: Personalizing Lens Constants</b> .....	200
Overview.....	200
Personalizing Lens Constants.....	200
How to Personalize Constants.....	201
Accessing the Personalize IOLs Screen.....	201
Personalize IOLs Screen.....	202
Personalize IOLs Screen Soft Menus.....	203
Selecting an IOL Group and Lens.....	203
Next IOL/Group.....	203
Selecting IOL Group with the Knob.....	204
Entering Postoperative Results.....	204
Pasting Patient Information.....	205
Manually Entering Patient Information .....	206
Entering Remaining Postoperative Results.....	207
Deleting Postoperative Results.....	207
Deleting Current Postoperative Result.....	207
Deleting All Postoperative Results.....	208
How to View Individual Results for a Formula.....	208
How to Sort Postoperative Results.....	208
How to Update IOL Constants.....	209
Update IOL Constants Screen.....	210
Selecting an IOL Group and Lens.....	211
 <b>Chapter 11: Storing and Recalling Records</b> .....	 213
How to Recall a Record.....	215
How to Adjust Parameters on Saved Records.....	217
How to Update Calculations.....	217
How to Sort Patient Records.....	218
 <b>Chapter 12: Printing Records</b> .....	 219
How to Print a Record.....	219
Screen Printout Formats.....	219
How to Select the Right Printout Format.....	220
Sample Printouts.....	220
How to Batch Print.....	222
Required Printer.....	225

<b>Chapter 13: Maintenance</b> .....	226
General Maintenance.....	226
Safety Inspections.....	226
Visual Inspection.....	226
Ultrasound Inspection.....	226
Calibration of Accutome A-Scan Plus.....	227
<b>Battery Disposal</b> .....	227
Instructions for Disposal.....	227
Disposal in Europe.....	227
Disposal in US.....	228
<b>Chapter 14: Specifications</b> .....	230
Overview.....	230
Physical Specifications.....	230
Table 14-1 Accutome A-Scan Plus Physical Specifications.....	230
Table 14-2 Accutome A-Scan Plus Physical Specifications.....	231
Environmental Specifications .....	231
Table 14-3 Environmental Specifications.....	232
Measurement Accuracy.....	232
Table 14-4 Measurement Accuracy.....	232
Operating Modes.....	233
Table 14-5 Operating Mode(s).....	233
Formula References.....	234
Table 14-6 Formula References.....	234
Storage/Range Specifications.....	235
Table 14-7 Data Specifications.....	235
Table 14-8 Data Specifications.....	236
Acoustic Output.....	237
Table 14-9 Acoustic Output Reporting Table for Track 1.....	237
Non-Autoscanning Mode.....	237
Table 14-10 Acoustic Output Reporting Table for Track 1.....	238
Non-Autoscanning Mode.....	238
EMC Compliance Information.....	238
Table 14-11 electromagnetic emissions.....	240
Table 14-12 electromagnetic immunity .....	240
Table 14-12 electromagnetic immunity.....	241
Table 14-13 electromagnetic immunity.....	242
Table 14-14 Recommended separation distances .....	244

<b>Chapter 15: Warranty and Repairs</b> .....	245
Warranty.....	245
<b>Product Returns</b> .....	246
Service and Repair.....	246
All Other Returns.....	246
Non-Returnable Merchandise.....	246
<b>Replacement Parts</b> .....	247
Table 15-1 Accutome Replacement Parts.....	247
Documentation.....	247
NetworkAddendum.....	248

# List of Figures

Figure 1-1 Accutome A-Scan Plus.....	1
Figure 3-1 Accutome A-Scan Plus Components.....	12
Figure 3-2 Closed Kickstand.....	14
Figure 3-3 Open Kickstand.....	15
Figure 3-4 Component Connectors.....	16
Figure 3-5 Probe Connector.....	18
Figure 3-6 Probe Connected.....	19
Figure 3-7 Accutome Ultrasonic Probe Kit.....	20
Figure 3-8 Accutome Probe.....	20
Figure 3-9 Probe Setup with Immersion Shell.....	21
Figure 3-10 Probe with Goldman Tonometer Adapter.....	21
Figure 3-11 Inserting the Probe into the Handle Extension.....	22
Figure 3-12 Probe with Handle Extension and Insertion Tool.....	23
Figure 3-13 Probe with Handle Extension.....	23
Figure 3-14 Turning on the Accutome A-Scan Plus.....	24
Figure 3-15 Measure Screen Displayed.....	25
Figure 3-16 Accutome A-Scan Plus Test Block.....	26
Figure 3-17 Measure Screen, Main Menu.....	27
Figure 3-18 Patient Information Field.....	28
Figure 3-19 Patient Information Field Opened.....	29
Figure 3-20 Enter Patient's Last Name.....	29
Figure 3-21 Enter Patient Information.....	30
Figure 3-22 Screen Keyboard.....	31
Figure 3-23 Measurement Fields Selected.....	34
Figure 3-24 Measure Screen Displayed.....	36
Figure 3-25 Calculate IOL Screen.....	37
Figure 3-26 ACD Field Selected.....	38
Figure 3-27 K1, K2 Values.....	39
Figure 3-28 Calculation Completed.....	40
Figure 3-29 Patient Record Storage.....	42
Figure 3-30 Patient Record Stored.....	42
Figure 4-1 Accutome A-Scan Plus Buttons.....	44
Figure 4-2 Accutome A-Scan Plus Screen Hierarchy.....	50
Figure 5-1 Preferences Button.....	57
Figure 5-2 Eye Types Screen.....	58
Figure 5-3 Selecting the Lens Materials Table.....	60
Figure 5-4 Selecting a Cell to Enter New Lens Material.....	61
Figure 5-5 Entering the Name for New Lens Material.....	62
Figure 5-6 Adding New Material Velocity.....	63

Figure 5-7 Selecting the Eye Type Name Cell.....	64
Figure 5-8 Adding the New Eye Type Name.....	64
Figure 5-9 Activating the Area to Select New Lens Material.....	65
Figure 5-10 Lens Material Selected.....	66
Figure 5-11 Lens Thickness Entered.....	67
Figure 5-12 Anterior Chamber Material Selected.....	68
Figure 5-13 Vitreous Chamber Material Selected.....	69
Figure 5-14 Non-Factory Field.....	70
Figure 5-15 Restore Selected Field Prompt.....	71
Figure 5-16 Selected Field Restored.....	72
Figure 5-17 Non-Factory Fields Displayed.....	73
Figure 5-18 Restore All Fields Prompt.....	74
Figure 5-19 More Settings - Setup Screen.....	75
Figure 5-20 Printer Field Selected.....	76
Figure 5-21 Printer Field Open.....	77
Figure 5-22 Selecting the Printer.....	78
Figure 5-23 Printer Selected.....	79
Figure 5-24 Select Printer.....	80
Figure 5-25 Activate the Printer Field.....	81
Figure 5-26 Printer Selection “None”.....	82
Figure 5-27 New Patient Selected.....	83
Figure 5-28 Update Selected.....	84
Figure 5-29 Are You Sure?.....	85
Figure 5-30 Driver Update Complete.....	86
Figure 5-31 Select Printer Field.....	87
Figure 5-32 Selecting Custom Print Drives.....	88
Figure 5-33 Custom Print Drivers Selected.....	89
Figure 5-34 Print Title Field Selected.....	90
Figure 5-35 Print Title Field Activated.....	91
Figure 5-36 Entering the Print Title.....	92
Figure 5-37 Print Title Added.....	93
Figure 5-38 Selecting Automatic Network Address.....	94
Figure 5-39 Contrast Field Selected.....	97
Figure 5-40 Contrast Field Activated.....	98
Figure 5-41 Adjusting the Contrast.....	99
Figure 5-42 Contrast Adjusted.....	100
Figure 5-43 Default Eye Type Field Selected.....	101
Figure 5-44 Default Eye Type Field Activated.....	101
Figure 5-45 New Default Eye Type Selected.....	102
Figure 5-46 Default Eye Type Changed.....	103
Figure 5-48 Default ID Field Activated.....	105
Figure 5-49 Entering the Default ID.....	105

Figure 5-50 Default ID Added.....	106
Figure 5-51 Default Gain Field Selected.....	107
Figure 5-52 Default Gain Field Changed.....	108
Figure 5-53 Target Field Selected.....	109
Figure 5-54 Target Field Activated.....	109
Figure 5-55 Adjusting the Target.....	110
Figure 5-56 Target Adjusted.....	111
Figure 5-57 K Index Field Selected.....	112
Figure 5-58 K Index Field Activated.....	113
Figure 5-59 Adjusting the K Index.....	113
Figure 5-60 K Index Field Adjusted.....	114
Figure 5-61 IOL Step Field Selected.....	115
Figure 5-62 IOL Step Field Activated.....	115
Figure 5-63 Adjusting the IOL Step.....	116
Figure 5-64 IOL Step Adjusted.....	117
Figure 5-65 Selecting Network Folder On/Off.....	118
Figure 5-66 Configure Network Folder.....	119
Figure 5-67 Day Field Selected.....	124
Figure 5-68 Day Field Activated.....	125
Figure 5-69 Adjusting the Day.....	126
Figure 5-70 Day Adjusted.....	127
Figure 5-71 Auto Mode Sclera Selected.....	129
Figure 5-72 Auto Mode Sclera Field Activated.....	129
Figure 5-73 Changing the Auto Mode - Turning On Sclera.....	130
Figure 5-74 Auto Mode - “Sclera” On.....	131
Figure 5-75 Auto Mode - “Stable” Selected.....	132
Figure 5-76 Auto Mode Defined by “Stable” Measurement.....	132
Figure 5-77 About This Unit Screen.....	135
Figure 6-1 Measure Screen Displaying Current Settings.....	137
Figure 6-2 Eye Type Selected.....	141
Figure 6-3 Eye Type Active.....	142
Figure 6-4 Eye Type Changed.....	143
Figure 6-5 Measurement Selected.....	147
Figure 6-6 Measurement Activated with Waveform Review Menu.....	148
Figure 6-7 Current Measurement Waveform Selected.....	151
Figure 6-8 Waveform Review Menu Activated.....	152
Figure 6-9 Cornea Gate Selected.....	153
Figure 6-10 Anterior Lens Gate Selected.....	154
Figure 6-11 Posterior Lens Gate Selected.....	156
Figure 6-12 Retina Gate Selected.....	157
Figure 6-13 Threshold Gate Selected.....	158

Figure 6-14 Gain Selected .....	159
Figure 6-15 Gain Field Changed.....	160
Figure 6-16 Zoom Selected.....	161
Figure 6-17 Zoom Changed.....	162
Figure 6-18 Scroll Selected.....	163
Figure 6-19 Measurement Scrolling Changed.....	164
Figure 7-1 Customize Eye Type Screen.....	167
Figure 7-2 OS Materials Table Selected.....	168
Figure 7-3 OS Materials Table Activated.....	169
Figure 7-4 Changing VC Material.....	170
Figure 7-5 VC Material Cell Changed.....	171
Figure 7-6 Changing Velocity Field.....	172
Figure 7-7 OS Eye Type Customized.....	173
Figure 8-1 Calculate Button.....	175
Figure 8-2 Calculation Fields.....	176
Figure 8-3 Calculate IOL Screen - All Fields Entered.....	182
Figure 8-4 Compare On Selected.....	183
Figure 8-5 Post Rx Surgery Field (Rx Surg) Selected.....	186
Figure 8-6 Post Rx Surgery Calculation Activated - Clinical History.....	187
Figure 8-7 Post Rx Surgery Calculation with Contact Lens Method.....	188
Figure 8-8 Post Rx Surgery Calculation with Shammas Clinical Method.....	189
Figure 9-1 Select IOL Groups.....	192
Figure 9-2 IOL Groups Screen.....	193
Figure 9-3 Entering the IOL Group Name.....	194
Figure 9-4 Entering the IOL Description.....	195
Figure 9-5 Selecting the A-Constant Field.....	196
Figure 9-6 Entering the IOL Constant.....	197
Figure 9-7 First Lens Entered for Group 1.....	198
Figure 9-8 First IOL Group Complete.....	199
Figure 10-1 Calculate IOL Screen - IOL Groups Selection.....	201
Figure 10-2 Personalize IOLs Screen.....	202
Figure 10-3 Update IOL Constants Screen.....	210
Figure 11-1 Patient Record Screen.....	214
Figure 11-2 Patient Record Stored.....	215
Figure 11-3 Recalling a Patient Record.....	216
Figure 11-4 Recalled Patient Record.....	217
Figure 12-1 Measurement Printout.....	220
Figure 12-2 Calculation Printout and Patient Record Screen.....	221
Figure 12-3 Saved Patient Record Screen.....	222
Figure 12-4 Print Menu Screen.....	223
Figure 12-5 Saved Patient Records - Select for Batch Print.....	224

All Accutome A-Scan units are manufactured by Accutome Ultrasound at:

**3222 Phoenixville Pike  
Malvern, PA 19355  
USA**



# 1 Introduction

## Accutome A-Scan Plus Overview

The Accutome A-Scan Plus pictured below has all the features that make it easy to obtain extreme accuracy and improved patient outcomes.



*Figure 1-1 Accutome A-Scan Plus*

## Features

The Accutome A-scan Plus is designed for easy access to all screens and functions.

The advanced User Input Knob provides unsurpassed ease of use and the straightforward Graphical User Interface guides you through every operation.

What you can't see on the surface is also important. Industry-leading signal acquisition and processing helps you assure accurate measurements. Reliable design and efficient manufacturing provide fiscal value. Upgradeable software protects your investment. The Accutome A-Scan Plus lets you accomplish even the complex simply.

The A-Scan provides the following general features:

- Large 7.5 inch high resolution LCD screen with intuitive User Interface
- Rotary User Input knob and dedicated tactile buttons
- External, universal input, worldwide power supply
- Desktop, slit lamp, or wall mountable
- Provides a variety of printouts
- 1.9" thick, portable

## Measurements

The accuracy of the Accutome A-Scan Plus measurement is provided by the following:

- High-resolution, real-time waveform display with up to 8X zoom pinpoints tissue boundaries
- High-speed digitalization acquires over 4000 points per waveform
- Continuous display of Axial Length, ACD, Lens Thickness, and Vitreous dimensions
- Audible feedback of contact, signal quality, and capture
- Immersion mode yields improved accuracy - Contact mode also supported
- Automatically or Manually capture up to 5 waveforms for each eye
- Adjustable Gain, Time Gates, and Amplitude Thresholds
- Modify all waveform parameters using real-time or frozen waveforms
- On-the-Fly customization makes unique patients a breeze

- Predefined Eye Types and Velocities handle most situations such as phakic, dense cataract, three pseudo-phakic, aphakic, and even silicone oil filled eyes. All velocities are fully adjustable.
- Custom Eye Types and Material Velocities can be created to handle individual preferences, special pathologies, or future trends
- Highly sensitive 10MHz composite Broadband probe features fixation and multiple mounting options

### **IOL Calculations**

The Accutome A-Scan Plus is also a leader in IOL Calculations and provides the following:

- Modern formulas including Hoffer Q, Holladay, SRK/T, and Haigis
- Compare results of all formulas simultaneously on a single screen for selected lenses
- Instantly calculates emmetropic and targeted ametropic IOL powers for dozens of lenses, viewed three at a time, using the average of selected waveforms, a single waveform, or manually entered data
- Conveniently group lenses by favorite designation such as surgeon, user, type, manufacturer, etc.
- Personalization of IOL Constants is easy and straightforward, encouraging improved patient outcomes
- Maintains individual IOL Constants for each formula. Clearly identifies which IOL constant is used with the selected formula
- IOL Calculation for Post Refractive Surgery Patients

### **Components**

The components that are standard with each Accutome A-Scan Plus instrument are:

- Ultrasonic probe
- Power Supply
- Footswitch
- Keyboard

## Optional Components

There are also several optional components which further simplify the use of the Accutome A-Scan:

- External Printer
- Immersion Shell
- Mounting Options

## About this Manual

Section 2	Safety	Summarizes safety precautions, warnings, symbols, and terms.
Section 3	Getting Started	Provides assembly instructions, overview of Accutome A-Scan Plus basic operation.
Section 4	How to Use the Accutome Buttons and Screens	Describes the interface and how to use all the buttons and screens.
Section 5	Accutome A-Scan Preferences	Provides instructions on how to set up eye types and system operational functions.
Section 6	Performing Measurements	Provides detailed instructions on how to perform A-Scan measurements.
Section 7	Customizing Eye Types	Describes how to customize an eye type for an individual patient.

---

Section 8	Performing Calculations	Describes the steps necessary to calculate IOL Power.
Section 9	Setting Up IOL Groups	Describes how to set up groups of IOLs for easy access.
Section 10	Personalizing Lens Constants	Provides instructions on why and how to personalize lens constants.
Section 11	Storing and Recalling Patient Records	Provides instructions on how to save and recall patient records, and make adjustments to saved records.
Section 12	Maintenance	Provides general maintenance instructions.
Section 13	Specifications	Provides Accutome A-Scan physical and operational specifications.
Section 14	Warranty and Repairs	Describes Accutome A-Scan warranty information and repair procedures.
Section 15	Printing	
Section 16	A-Scan Manager	Describes use of A-Scan Manager-A program that connects print outs to post script format allowing easy file sharing.
Section 17	Networking	

Having read this manual you will be able to assemble the Accutome A-Scan, take measurements, calculate IOL power, customize IOL constants and eye types, and save Patient records.

# 2 Safety

## **Safety Information**

The section lists:

- Safety Precautions associated with the Accutome A-Scan Plus
- Safety Precautions of a general nature

Federal law restricts this device to sale by or on the order of a physician.

### **Safety Issues to Consider When Using the Accutome A-Scan Plus**

The Accutome A-Scan Plus is non-invasive. The ultrasonic biometry probe touches the surface of the anesthetized cornea during the scanning process. The probe must be cleaned before and after use.

### **Indications for use**

This instrument is used for measuring the axial length, anterior chamber depth and lens thickness of the eye. It also is used for calculating the optical power of the IOL to be implanted during cataract surgery.

**Symbols Definitions for the Accutome**

Statements, graphics and symbols listed below are used on components of the Accutome A-Scan Plus. Descriptions and meanings are listed to the right of the symbols.




“Attention! Consult instruction manual.”



Single phase alternating current



When pressed turns the power on and off.



Ethernet connector



USB connector



Footswitch input connector



Power connector



Disposal of Product within EU

## Safety Precautions

There are several areas in the use of the Accutome A-Scan that require special attention, as they may pose a safety threat.

### Sterilization

Sterilization issues are confined to the A-Scan probe that comes in contact with the patient's eye. In order to prevent the transmission of disease, OSHA and CDC guidelines are referenced for proper control of sterilization issues. These guidelines are frequently updated so be sure to contact OSHA, CDC, or your local disease control officer for the latest information and sterilization techniques.

Infection control techniques that are compatible with the Accutome A-Scan Plus probe include:

1. Immersion of the probe tip in an antibacterial solution, such as Sporicidin™ or Cidex™

Note:

*Please follow the manufacturer's written protocol when using any antibacterial solution.*



This instrument has no user operated controls or settings that affect the acoustic output.

When using this instrument, the ALARA (As Low As Reasonably Achievable) principle should be followed. This principle is used to reduce unnecessary, potentially hazardous exposure to individuals, by keeping doses and test repetition As Low As Reasonably Achievable to achieve the required diagnostic information.

### **Disinfection and Cleaning**

The recommended disinfection technique is to clean the probe membrane and tip assemblies with isopropyl alcohol (and no other substance). It is imperative that the alcohol be given time to evaporate before applying a probe to the patient's eye.

## **WARNING!! DO NOT AUTOCLAVE!**

Disinfection issues are confined to the Accutome probe that comes in contact with the patient's eye. In order to prevent the transmission of disease, refer to the OSHA and CDC guidelines for proper control of disinfection. These guidelines are frequently updated so be sure to contact OSHA, CDC, or your local disease control for the latest information and disinfection technique.

## **WARNING!! DO NOT IMMERGE THE PROBE'S CABLE OR METAL CONNECTOR. ALLOW TO DRY BEFORE USE.**

**CAUTION:** General indications for use of the Accutome probe, include; external, structurally intact areas of the eye globe and orbit areas only.

**Electrical Hazard and Safety**

The instrument, footswitch and probe of the Accutome A-Scan Plus are electrical/electronic devices. Reasonable care should be taken when making electrical connection and handling electrically powered devices. Avoid use of damaged electrical equipment or frayed electrical cords. If repair or maintenance is being performed on the Accutome, the equipment must be turned off and the power cord disconnected.

Covers must not be removed except by qualified personnel. To avoid injury, do not operate the Accutome without protective covers.

The system is intended to operate from a power source of 100 - 240 VAC, 50/60 Hz. Protective earth grounding through the grounding connection in the power cords is essential for safe system operations.

Use only hospital-grade power cords and the connectors supplied with the Accutome A-Scan Plus. Also, be sure the power cords and connectors are in good condition.

A ground cable can be provided if required; Accutome part number: 24-4045.

**Avoiding Equipment Damage**

Attach the Accutome A-Scan Plus only to medical grade IEC-601-1 Medically Approved equipment.

The Accutome A-Scan Plus provides no explosion protection from static discharge or arcing components. Do not operate the instrument in the presence of explosive gases such as flammable mixtures of anesthetic and air, or nitrous oxide.

To prevent overheating, keep ventilation holes, located on the back of the instrument, free from obstruction.

**Avoiding Electromagnetic and Other Interference**

Do not use a cellular telephone and other devices not complying with EMC Class B requirements, as its signals may cause the equipment to malfunction. The effect of radio signals on medical devices is dependent on various factors and therefore unpredictable.

To avoid electromagnetic interference, the device must be installed and put into operation in accordance with the user manual and using the components supplied by Accutome.

**ALARA Principle**

When using this instrument, the ALARA (As Low As Reasonable Achievable) principle should be followed. This principle is used to reduce unnecessary, potentially hazardous exposure to individuals, by keeping doses and test repetition As Low As Reasonably Achievable to achieve the required diagnostic information.

# 3

## Getting Started

### Assembling the Accutome A-Scan Plus

The Accutome A-Scan Plus is designed to be used in multiple environments and can be rested on a surface, mounted on a wall, or mounted on a pedestal, or camera mount. The instrument requires little assembly. All components, standard and optional, can be quickly and easily connected.

The instrument is built with connectors for each component that is part of the Accutome A-Scan Plus environment. There is also a serial port used to transfer data from the Accutome A-Scan Plus to a computer.

### What you need

For a complete Accutome A-Scan Plus environment you will need the following:

- Accutome A-Scan Plus instrument including display
- Ultrasonic Probe
- Power Supply
- Power Cord
- Footswitch
- Keyboard



*Figure 3-1 Accutome A-Scan Plus Components*

**Probe**

The probe provided with the Accutome A-Scan is an essential component. No other probes should be used with the instrument.

**Footswitch**

The footswitch can be used to capture, review and delete measurements.

**Battery Specification and Installation**

In addition to the external power supply a 3.0V Lithium button battery is installed on the PCB to continuously maintain the internal clock.

Use only one (1) 3.0 volt, Varta model CR2032 lithium battery, or an equivalent.

**CAUTION:** Replacing the battery can only be performed by Accutome authorized personnel. Opening of the unit by unauthorized individuals voids all warranties.

To install the battery in the Accutome A-Scan Plus:


1. Remove the back of the A-Scan Plus unit.
2. Remove the installed battery from the battery holder located in the corner of the PCB.
3. Install new battery so that the flat side, positive polarity is facing out. The round side, negative polarity will be facing towards the PCB.
4. Replace the back of the unit.

**Placing the Accutome A-Scan Plus**

The instrument is designed to be placed almost anywhere; it is equipped with a quick-close kickstand and several options for mounting. It can be placed on a surface, such as a counter or a desk, using the quick-close kickstand provided with the instrument, or it can be mounted on a wall, a pedestal, a camera mount, or a cell phone mount

**Quick-Close Kickstand**

The quick-close kickstand provided with the Accutome A-Scan Plus provides an easy, stable base for the instrument. To open the kickstand pull the kickstand away from the bottom of the instrument. When opening or closing the kickstand it is best to exert a small amount of outward pressure on the inner sides of the kickstand. Figure 3-2 shows the kickstand in the closed position and Figure 3-3 shows the kickstand opened.



*Figure 3-2 Closed Kickstand*



*Figure 3-3 Open Kickstand*

### **Mounting**

The Accutome A-Scan Plus is designed to be mounted with many types of hardware. The back of the Accutome has five threaded holes. Four of the holes are AMPS-NEC compatible and will accept any compatible mounting.

In the center of the four holes is one larger hole. The larger hole is designed to accept a camera tripod, pedestal, or wall mount.

Note:

*For more information on mounting the Accutome A-Scan Plus and purchasing mounting hardware, contact the Accutome Support Group*

### **Connecting the Components**

All of the connectors for the Accutome A-Scan Plus components, except for the probe, are located on the side, at the left of the instrument (facing the screen).

### Connecting the Footswitch

To connect the footswitch:

1. Locate the footswitch connector, on the side, at the left of the instrument (see Figure 3-5).
2. Insert the connector of footswitch cable into the footswitch connector.

### Connecting the Power

There are two components to connect power to the Accutome A-Scan Plus; there is a power supply which regulates the voltage going to the instrument, and there is a grounded power cable which connects from the power supply to an outlet.

To connect the power:

1. Locate the grounded power cord and insert it into the empty connector on the power supply.
2. Locate the power connector, on the side, at the left of the instrument (see Figure 3-4 below).
3. Insert the power supply connector into the power connector.



*Figure 3-4 Component Connectors (Left Side of Instrument)*



**Connecting the Ethernet Connection**

Locate a regular Ethernet cable (not provided with the unit) with RJ45 connectors. Plug one end of the Ethernet connector and the other end to a Ethernet wall outlet or Ethernet hub.

**Connecting the USB Keyboard and USB disk**

The USB A Connectors are used to connect USB stick, USB keyboard and USB printers.

**Connecting the RS232 Connector**

The RS232 Connector (Serial port) is reserved for developing and debug purposes.

### Connecting the Probe

The Accutome A-Scan Plus probe connector is located on the right side of the instrument (facing the instrument).

To connect the probe:

1. Locate the probe connector, on the side, at the right of the instrument, facing the screen (see Figure 3-5 below.)



***Figure 3-5 Probe Connector (Right Side of Instrument)***

1. The probe connector is keyed and has a red dot indicating the key.
2. Insert the probe with the red dot facing the back of the instrument. (Refer to Figure 3-6 on next page.)



**Figure 3-6 Probe Connected**


### **Probe Setup**

The Accutome A-Scan Plus probe is an integral component. There are several options available for probe use. The Accutome A-Scan Plus probe can be used:

1. With an immersion shell
2. Mounted into a Goldman Tonometer
3. With a probe handle extension

Note:

*You cannot operate the Accutome A-Scan Plus without the Accutome probe.*




**Figure 3-7 Accutome Ultrasonic Probe Kit (PN 24-4001)**

#### **Accutome Ultrasonic Probe Kit (PN 24-4001)**

The Accutome probe is designed to be used with an Immersion Shell. When using an immersion shell ensure that there is a distance of 5 - 14.5 mm between the bottom of the probe and the bottom of the immersion shell, as shown in Figure 3-9 on next page.



**Figure 3-8 Accutome Probe**




**Figure 3-9 Probe Setup with Immersion Shell**

### **Accutome Probe with Goldman Tonometer Adapter**

The Accutome probe is designed to be used with a Goldman Tonometer Adapter. When using the Tonometer Adapter:

1. Slide the adapter over the end of the probe as shown in Figure 3-10 below.
2. Mount the probe by inserting the Adapter into the Goldman Tonometer.




**Figure 3-10 Probe with Goldman Tonometer Adapter**

### Accutome Probe with Handle Extension

The Accutome probe is designed to be used with an handle extension to increase the length of the probe. When using the probe handle extension:

1. Insert the probe into the handle extension as shown in Figure 3-11 below.
2. Slide the insertion tool into the handle extension making sure that the probe cable runs through the notched channel of the insertion tool.
3. Push the probe through the handle extension until the tip of the probe emerges from the extension.
4. Remove the insertion tool by sliding it back away from the handle extension.



**Figure 3-11 Inserting the Probe into the Handle Extension**



*Figure 3-12 Probe with Handle Extension and Insertion Tool*



*Figure 3-13 Probe with Handle Extension*

## Basic Operation

The basic operation of the Accutome A-Scan Plus consists of the following steps:

1. Power on the instrument.
2. Adjust the LCD display contrast.
3. Take five measurements per eye.
4. Calculate the IOL power for desired result.
5. Print or save the Patient Record.

### How to Power On the Accutome A-Scan Plus

To power on the Accutome A-Scan Plus:

1. Push the power button located at the bottom left corner of the instrument (see Figure 3-14 below). When you power on the Accutome A-Scan Plus a splash screen will appear. The instrument will go through an initialization process and when completed will display the Measure Screen. The Accutome A-Scan Plus will also beep once indicating that the instrument is ready.



*Figure 3-14 Turning on the Accutome A-Scan Plus*



- The first screen you see will be the Measure Screen. Scanning mode preferences are maintained while the instrument is powered off.

### How to Adjust the Contrast

When you turn on the Accutome A-Scan Plus you may have to adjust the contrast of the display. The display is an LCD (Liquid Crystal Display) and depending upon the angle from which you are viewing the screen, the images displayed may not be bright enough or may be too bright.

To adjust the Accutome A-Scan Plus screen contrast:

- Press and hold the Preferences button.
- Rotate the knob while observing the change in grey/white contrast on the screen.
- When the contrast is properly adjusted release the Preferences button.

Note:

*When the contrast is properly adjusted release the Preferences button.*




Figure 3-15 Measure Screen Displayed

### Using the Test Block

The Accutome A-Scan Plus is equipped with a test block, located at the top, right side (facing the display) of the instrument. Refer to the Figure below for location. The test block is provided as a way to test the basic operation of the instrument and the probe.

To test the Accutome A-Scan Plus and probe:

1. Apply some immersion fluid (water or BSS) to the test block.
2. Place the probe on the test block.
3. You should receive a waveform and AXL measurement in the Measure Screen.

Note:

*If you cannot detect a waveform, call the Accutome Service Group at (610) 889-0200.*



***Figure 3-16 Accutome A-Scan Plus Test Block (Top of Instrument)***

### Preparation of Patient for Examination

Preparing a patient for an A-Scan exam consists of the following steps:

1. Anesthetizing the patient’s eye with a topical anesthetic such as Proparacaine. Please refer to the manufacturer’s instructions for proper use.
2. Cleaning the probe tip. Refer to Chapter 2, Safety of the user manual.

### How to Start a New Patient

Starting at the main menu screen:




Figure 3-17 Measure Screen, Main Menu

1. Press the button under the “Start New Patient” selection on the Measure, Calculate IOL or Patient Records Screens. Refer to Figure 3-18 below.
2. When you start a new patient the Accutome A-Scan Plus will clear all fields on the Measure Screen as follows:
  - Gain set to default
  - Gates/Threshold set to default
  - Waveforms deleted
  - K readings deleted
  - Entered AXL (if any) deleted.
  - Patient field deleted
3. If you wish to enter a Patient Name select the Patient field and press the knob or the  $\sqrt{\quad}$  button to activate the field as shown in Figure 3-19 on next page.

Patient Identification				Measure					
<div style="border: 1px dashed black; height: 100px; width: 100%;"></div>				<b>OD</b>					
				Phakic					
				<b>AXL</b>					
				?					
				ACD	?	mm			
Lens	?	mm							
VCD	?	mm							
5    10    15    20    25    30    35    40    mm									
Patient ID <input style="width: 150px; height: 20px;" type="text"/>				AXL    ACD    Lens    VCD					
				1					
				2					
				3					
				4					
				5					
				Avg	0.00	0.00	0.00	0.00	
Dev	0.00	0.00	0.00	0.00					
Running		Auto ( R )		Contact		OD		Start New	
Frozen		Manual		Immersion		OS		Patient	
								Customize Eye Type...	

*Figure 3-18 Patient Information Field*

Press the enter button, the knob or the check mark to activate the patient information field.

The screenshot shows a form titled "Patient Last Name" on the left and "Patient Data" on the right. The form contains the following fields: "\*Last Name" (text input), "\*First Name" (text input), "Date of Birth" (with sub-fields for Y, M, and D), "ID" (text input), and "Remark" (text input). At the bottom right, there are two buttons: "Start New Patient" and "Done...".

*Figure 3-19 Patient Information Field Opened*

4. The patient's last name will be highlighted, using the keyboard type in the last name.

The screenshot shows the same form as Figure 3-19, but with the title "Enter patient's last name" at the top left. The "\*Last Name" field now contains the text "Baldwin" and is highlighted with a dashed border. The other fields and buttons remain the same.

*Figure 3-20 Enter Patient's Last Name*

5. Press the tab key saves the entry and advances to the next entry in one step.

The screenshot shows a software interface for entering patient information. The window has a title bar with 'Patient First Name' on the left and 'Patient Data' on the right. The main area contains several input fields: '\*Last Name' with the text 'Baldwin' entered; '\*First Name' with an empty field; 'Date of Birth' with three separate boxes for 'Y', 'M', and 'D'; 'ID' with an empty field; and 'Remark' with a long empty text area. At the bottom right, there are two buttons: 'Start New Patient' and 'Done...'. The background is a light gray color.

**Figure 3-21** Enter Patient Information

6. Type in the patient's first name
7. Pressing the tab key saves the entry and advances to the next entry in one step.
8. Continue entering patient information until all necessary information is entered.

### How to Enter Text without a Keyboard

The keyboard is optional with the Accutome A-Scan Plus. The keyboard makes entering text very easy. When a field is active requiring text, and you have a keyboard, you simply have to enter the text.

The Accutome A-Scan Plus also provides a method of entering text that does not require a keyboard. If a field is activated that requires text, and the keyboard has not been used, the instrument displays a screen keyboard in the soft menu area, shown in Figure 3-22 below, that contains all the alphanumeric characters.

The screenshot shows a screen titled "Patient Data" with a header "Enter patient's last name". The form contains the following fields:

- \*Last Name: [Dotted text input field]
- \*First Name: [Text input field]
- Date of Birth: [Y] [M] [D] (with dropdown menus for Year, Month, and Day)
- ID: [Text input field]
- Remark: [Text input field]

At the bottom of the screen is a screen keyboard with the following layout:

A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z	.	#	()	-	/	0	1	2	3	4	5	6	7	8	9
Enter	Undo	Backspace	Space	Case	Done...																																			

*Figure 3-22 Screen Keyboard*

### Screen Keyboard Features

The screen keyboard is displayed at the bottom of the screen and is divided into a row of selectable alphanumeric characters and soft menu selections. The background of the selectable characters is white and has a border drawn around it to distinguish the characters from the active buttons.

The screen keyboard also has the following soft menu selections activated by buttons beneath the selection:

- Enter
- Undo - clears the active field.
- Backspace - deletes the character immediately to the left of the cursor.
- Space - inserts a space after the last character.
- Case - toggles the selectable characters between upper and lower case.
- Done - exits the screen keyboard and returns you to the Measure screen.  
The selected field will display the edited text.

Special characters are located in between alpha and the numeric letters. You can enter a space in a field by selecting the space between the alpha and numeric characters or by pressing the button below the "Space" soft menu selection.

If you would like to switch to lower case press the button below "Case". The Accutome A-Scan Plus automatically selects upper case for a blank field, unless the field has been previously edited in lower case and will then revert to lower case.

The Accutome A-Scan Plus allows you to switch between using the optional keyboard and the screen keyboard.

To quickly select characters on the screen keyboard turn the data knob quickly to accelerate the selection location.



**Entering a Patient with the Screen Keyboard**

To enter the Patient Name with the screen keyboard:


1. Select the Patient field by rotating the knob.
2. Press the knob or the  $\sqrt{\quad}$  button, to open the patient information screen field.
3. Using the knob, select the patient field.
4. Press the knob on  $\sqrt{\quad}$  button to activate the field. The screen keyboard will appear at the bottom of the screen.
5. Rotate the knob to select the first letter, or number of the Patient field.
6. Press the knob or the  $\sqrt{\quad}$  button, to enter the character in the field.
7. Rotate the knob to select the next character.
8. Press the knob or the  $\sqrt{\quad}$  button, to enter the character in the field.
9. Continue entering all the text characters in this manner.
10. If you would like to insert a space, press the button beneath the “Space” selection.
11. If you would like to change the case of the letters, press the button beneath the “Case” selection.
12. If you would like to remove a letter or more, press the button beneath the “Backspace” selection. If you have made an error and would like to erase the entire field, press the button beneath the “Undo” selection.
13. When you have completed the Patient field, press the button beneath the “Done” selection.
14. Use the knob to highlight additional entries.
15. Once all entries have been made, pressing the “done” will take you to the main menu.

**How to Take a Measurement**

After you have entered all the Patient information you should set the measurement selections to your liking.

The selections you can change are:

- Automatic/Manual - which method are you using to take the measurement automatic or manual? Automatic allows the Accutome to determine when the probe has acquired a measurement and manual allows the operator to determine when to capture the waveform.
- Contact/Immersion - which method of applying the probe are you using, contact or immersion?
- OD/OS which eye are you measuring, OD or OS?
- Eye type - which type of eye are you measuring; i.e. phakic, aphakic, dense cataract, etc.?



*Figure 3-23 Measurement Fields Selected*

To take a patient measurement:

1. Change the necessary measurement settings by pressing the buttons beneath the measurement selections. Each of the measurement selections toggle between one and the other.
2. Set the appropriate Eye Type (the field under OD or OS) for each eye, Phakic is the default and is fine for most cataractous eyes. If measuring an aphakic or pseudo phakic eye, the eye type must be set accordingly. To set the eye type, select the eye type field by rotating the knob, activate it and choose the appropriate type. The type is associated with each eye and is retained when the eye (OD or OS) selected. It is necessary to set the appropriate eye type for each eye if measuring each eye.
3. When all measurement settings for the current Patient are accurate apply the probe to the Patient's eye.
4. If you are not using the running mode, press the footswitch or the Running/Frozen selection. The Accutome A-Scan Plus will proceed to the next empty waveform (if available).
5. If you are using the Automatic mode, the Accutome A-Scan Plus will automatically freeze a measurement upon sclera detection, steep retina detection or upon capturing stable readings. (Auto Mode settings are defined in the Setup Screen.) The instrument will emit a high pitched chirp when you have automatically acquired a measurement.
6. If you are using the Manual mode, and you wish to capture the current waveform press the footswitch or the "Running/Frozen" selection.

Note:


*The user must review auto measurements for quality. For more information on taking measurements refer the "Performing Measurements" section of this manual.*

## How to Perform a Calculation

After you have completed a Patient's scans you can calculate the power of the IOL for the Patient. You can perform the calculation from the Calculate IOL Screen.

To calculate a lens:

1. Press the Calculate button, located at the right side of the front panel



*Figure 3-24 Measure Screen Displayed*

2. The Accutome will display the Calculate IOL Screen as shown in Figure 3-25 below

Note:

*For more information on Calculating IOLs refer to the “Performing Calculations” section of this manual.*

3. Select the IOL Group, if necessary, by pressing the button beneath the selection “Select IOL Group” until the appropriate IOLs are displayed.

K Reading										Calculate IOL	
Group	William Smith									<b>OD</b> Phakic Rx Surg <input type="checkbox"/> No <b>AXL</b> <input type="text"/> K1 <input type="text"/> K2 <input type="text"/> Target <input type="text"/> 0.00 D	
IOL	SN60WF			MA60AC			MTAU40				
Hof Q	5.37			5.20			3.39				
Hol	1.620			1.450			-0.306				
SRK/T	5.40			5.21			3.28				
Haig	1.714	0.400	0.100	1.527	0.400	0.100	-0.410	0.400	0.100		
	Power	Refr		Power	Refr		Power	Refr			
Target											
Emme											
Formula	<input type="checkbox"/> Hoffer Q <input checked="" type="checkbox"/> Holladay <input type="checkbox"/> SRK/T <input type="checkbox"/> Haigis									AXL <input type="text"/> 1 <input type="text"/> 2 <input type="text"/> 3 <input type="text"/> 4 <input type="text"/> 5 Avg 0.00 Dev 0.00	
Patient ID	Baldwin, Robert 123-456-7890										
Select IOL Group	Select Formula	Compare ON		Compare OFF		OD		OS		Start New Patient	IOL Groups...

Figure 3-25 Calculate IOL Screen

4. Select the Formula, if necessary, by pressing the button beneath the selection "Select Formula" until the appropriate formula is displayed.
5. If using the Haigis formula, and the ACD value needs to be changed, rotate the knob to select the ACD field and press the knob or the  $\sqrt{\phantom{x}}$  button to activate the field. When the field is active either rotate the knob or manually enter the ACD value in millimeters (mm). If you would like the Accutome to calculate the phakic ACD press the "Delete" key or the X button to remove the entered value and replace it with "Calc" for a calculated value.

Note:

*The ACD field is only active if you are using the Haigis formula. If you have selected another calculation formula the field will not appear.*

*Entered ACD should be a phakic ACD measurement. If this value is unknown, the ACD can be estimated by entering "0".*

Enter preoperative ACD, or delete to calc										Calculate IOL	
Group	William Smith									<b>OD</b>	
IOL	SN60WF			MA60AC			MTAU40			Phakic	
Hof Q	5.37			5.20			3.39			Rx Surg <input type="checkbox"/>	
Hof	1.620			1.450			-0.306			<b>AXL</b>	
SRK/T	5.40			5.21			3.28			<b>24.62</b>	
Haig	1.714	0.400	0.100	1.527	0.400	0.100	-0.410	0.400	0.100	ACD <input type="text" value="3.17"/> mm	
	Power	Refr		Power	Refr		Power	Refr		K1 <input type="text"/>	
										K2 <input type="text"/>	
Target										Target <input type="text" value="0.00"/> D	
Emme											
Formula	<input type="checkbox"/> Hoffer Q <input type="checkbox"/> Holladay <input type="checkbox"/> SRK/T <input checked="" type="checkbox"/> Haigis									AXL ACD 1 24.61 3.15 2 24.68 3.26 3 24.60 3.20 4 24.62 3.17 5 24.57 3.09 Avg 24.62 3.17 Dev 0.04 0.06	
Patient	smith-1, D DOB 1960.01.01										
Select IOL Group	Select Formula	Compare ON	Compare OFF	OD	OS	Start New Patient	IOL Groups...				

Figure 3-26 ACD Field Selected

6. Enter the K1 value in the designated area as shown in Figure 3-27 below. Rotate the knob to select the K1 field and press the knob or the  $\checkmark$  button to activate the field. When the field is active enter the K1 values in Diopters or mm.
7. Enter K2 value in the same manner as K1.

Note:

*When you first receive the Accutome A-Scan Plus the IOL Groups are empty. If there are no IOL Groups present on the Calculate IOL Screen you will not be able to perform a calculation. Refer to the "Setting Up IOL Groups" section for further information.*

K Reading										Calculate IOL	
Group	William Smith									<b>OD</b> Phakic Rx Surg <input type="checkbox"/> No <b>AXL</b> <b>24.62</b> K1 <input type="text" value="45.00"/> D K2 <input type="text" value="45.50"/> D Target <input type="text" value="0.00"/> D	
IOL	SN60WF			MA60AC			MTAU40				
Hof Q	5.37			5.20			3.39				
Hof	1.620			1.450			-0.306				
SRK/T	5.40			5.21			3.28				
Haig	1.714	0.400	0.100	1.527	0.400	0.100	-0.410	0.400	0.100		
	Power	Refr		Power	Refr		Power	Refr			
	14.00	0.76		14.00	0.62		12.00	0.57			
	14.50	0.45		14.50	0.31		12.50	0.20			
	15.00	0.14		15.00	-0.01		13.00	-0.17			
	15.50	-0.18		15.50	-0.34		13.50	-0.55			
	16.00	-0.50		16.00	-0.66		14.00	-0.92			
Target	<b>15.22</b>			<b>14.98</b>			<b>12.77</b>				
Emme	15.22			14.98			12.77				
Formula	<input type="checkbox"/> Hoffer Q <input checked="" type="checkbox"/> <b>Holladay</b> <input type="checkbox"/> SRK/T <input type="checkbox"/> Haigis									AXL 1 24.61 2 24.68 3 24.60 4 24.62 5 24.57 Avg <b>24.62</b> Dev 0.04	
Patient	smith-1, D DOB 1960.01.01										
Select IOL Group	Select Formula	Compare ON		<b>OD</b>		Start New Patient		IOL Groups...			
		Compare OFF		OS							

Figure 3-27 K1, K2 Values

8. After entering the K1 and K2 values, the emmetropic power is calculated and displayed for each IOL.
9. Enter the Ametropic Target value in the designated area as shown in Figure 3-28 below. Rotate the knob to select the Target field and press the knob or the  $\sqrt{\phantom{x}}$  button to activate the field. When the field is active enter the Target value in Diopters.
10. The Calculate IOL Screen will display the ametropic power of the lens, for each lens, with the bold, large, black numbers. These values are the optimal lens, and do not necessarily exist in the real world. The Accutome A-Scan Plus also provides you with the power of the IOL that would achieve emmetropia. The emmetropic power is calculated and displayed under the ametropic power in a smaller font.

Target Refraction										Calculate IOL	
Group	William Smith									<b>OD</b> Phakic Rx Surg <input type="checkbox"/> No <b>AXL</b> <b>24.62</b> K1 45.00 D K2 45.50 D Target <input type="checkbox"/> -0.50 D	
IOL	SN60WF			MA60AC			MTAU40				
Hof Q	5.37			5.20			3.39				
Hol	1.620			1.450			-0.306				
SRK/T	5.40			5.21			3.28				
Haig	1.714	0.400	0.100	1.527	0.400	0.100	-0.410	0.400	0.100		
	Power	Refr		Power	Refr		Power	Refr			
	15.00	0.14		14.50	0.31		12.50	0.20			
	15.50	-0.18		15.00	-0.01		13.00	-0.17			
	<b>16.00</b>	<b>-0.50</b>		<b>15.50</b>	<b>-0.34</b>		<b>13.50</b>	<b>-0.55</b>			
	16.50	-0.82		16.00	-0.66		14.00	-0.92			
	17.00	-1.15		16.50	-1.00		14.50	-1.31			
Target	<b>16.00</b>			<b>15.75</b>			<b>13.44</b>				
Emme	15.22			14.98			12.77				
Formula	<input type="checkbox"/> Hoffer Q <input checked="" type="checkbox"/> > Holladay <input type="checkbox"/> SRK/T <input type="checkbox"/> Haigis									AXL 1 24.61 2 24.68 3 24.60 4 24.62 5 24.57 <b>Avg 24.62</b> Dev 0.04	
Patient	smith-1, D										
DOB	1960.01.01										
Select IOL Group	Select Formula	Compare ON	Compare OFF	OD	OS	Start New Patient	IOL Groups...				

Figure 3-28 Calculation Completed



**How to Print a Records**

After you have calculated the lens you will want to print the Patient record. When you print from the Calculate IOL Screen, the printout displays the waveform selected for the calculation, lens and formula information, and the calculations for both eyes (OD and OS).

To print a record:

1. With the appropriate Patient record active, press the “Print” button, located at the right side of the front panel.
2. The Accutome A-Scan Plus will print the calculation record.

**How to Save Patient Records**

The Accutome A-Scan Plus allows you to save patient records at any time to either internal memory, USB stick or network drive. You can save the record after you have taken all the desired measurements or, after you have taken the measurements and performed the calculation.

You can recall a saved patient record and re-scan any of the patient waveforms. You can also adjust the gates/threshold on any of the waveforms and recalculate the IOL power.

To save a Patient’s record:

1. Press the “Patient Records” button located to the right of the instrument. The instrument will display the Patient Record Screen as shown in Figure 3-29 on the next page.




Figure 3-29 Patient Record Storage

2. Press the button below “Save to List”. The Accutome A-Scan Plus will store the Patient record. The “Not Saved” prompt Patient ID will be changed to “Saved” and a new entry will appear in the Patient List.




Figure 3-30 Patient Record Stored

# 4

## How to Use the Buttons and Screens

### Overview

The Accutome A-Scan Plus consists of a screen display with buttons located beneath the screen and buttons located to the right of the screen. The A-Scan allows you to control every feature for capturing waveforms and calculating IOL powers including waveform display, adding lens materials and eye types, adding IOLs, setting up IOL groups, and setting preferences. Any task performed with the Accutome A-Scan Plus is performed using the buttons and screens.

The buttons located to the right of the screen are dedicated to specific functions and display other screens or execute printing. The buttons located beneath the screen are soft menu buttons and provide functions that change within each screen. The buttons have been designed to provide complete functionality with ease of use.

There is also a large knob with an indented push-button area located to the right of the screen, below the dedicated function buttons. The knob is the central component of the Accutome A-Scan Plus user interface. The knob allows you to select and change fields on every instrument screen.




Figure 4-1 Accutome A-Scan Plus Buttons

## Accutome A-Scan Plus Buttons

There are two types of buttons available on the Accutome A-Scan Plus front panel, dedicated buttons and soft menu buttons.

### Dedicated Buttons

The dedicated buttons, located at the side of the front panel, in the same area as the knob, all perform a dedicated function. All of the dedicated buttons except the Print button, display other high level screens.

The buttons are as follows:

- Measure
- Calculate
- Patient Records
- Preferences
- Print

Note:

*Two of the dedicated buttons, Calculate and Preferences, can be pressed multiple times to scroll through lower level linked screens.*

### **Measure Button**

The Measure button displays the Measure Screen where the user can acquire patient waveforms and adjust waveform parameters. The Measure Screen can also display stored Patient waveforms, in the state in which the waveform was originally captured. From the Measure Screen you can also access the Customize Eye Type Screen.

The Measure button can also be used to replace the footswitch. Pressing the measure button is the same as pressing the footswitch.

### **Patient Record Button**

The Patient Record button displays the Patient Record Screen where you save and recall patient measurements and calculations.

### **Calculate**

The Calculate button displays the Calculate Screen where IOL calculations are performed. From the Calculate Screen you can also access the IOL Groups Screen.

If you press the Calculate button multiple times the Accutome will scroll and display the lower level logically linked screens; i.e. IOL Groups Screen and Personalize IOLs Screen.

### **Preferences**

The Preferences button displays the Eye Types Screen where you can define eye types and velocities. From the Eye Types Screen you can access the Setup screen where you define default settings.

If you press the Preferences button a second time the instrument will display the lower level logically linked screen; i.e. Setup Screen.

**Print**

The Print button prints the information displayed on the current screen. When pressed from the Measurement Screen the print button will print up to five current eye waveforms (if five exist). When pressed from the Calculate IOL Screen or the Patient Record Screen, the print button will print the calculations for both eyes including all measurements, lens and formula information.

**Check or Affirmative (√)**

The Affirmative button acts like pressing the knob. Whenever you have selected a field and press the Affirmative button the field becomes active. If you press the Affirmative button a second time, on an active field the field is deactivated.

The Affirmative button also acts as “Yes” any time you are required to confirm an action; e.g. do you want to delete a record? Press the Affirmative button to continue with deleting the record.

**Negative or Delete (X)**

The Negative button will clear the contents of a selected field when pressed. For example, if the Patient field is active, when you press the Negative button the current Patient name will be wiped out.

The Negative button also acts as “No” any time you are required to confirm an action; e.g. do you want to delete a record? Press on the Negative button to cancel deleting the record.

**Soft Menu Buttons**

There is a series of buttons directly below the Accutome display. The buttons offer soft menu selections and change from screen to screen.

There are three types of soft menu selection:

- Buttons that perform a single action
- Buttons that toggle
- Buttons that display other screens or soft menus

**Buttons that Toggle between Two Selections**

Soft menu buttons that toggle cause the Accutome to switch between one state and another; e.g. on the Measure Screen the button under the Running/Frozen selection toggles the waveform between active and frozen. The active choice is highlighted in reverse video.

**Buttons that Display Other Screens or Soft Menus**

Soft menu buttons that have an ellipsis (...) to the right of the selection will display another screen or soft menu.

**Accutome A-Scan Plus Knob**

The large knob, located at the bottom of the right side of the Accutome A-Scan Plus is for selecting and activating fields and changing the parameters of the active field.

**How the Knob Works**

When a field on any screen requires data, you move around on the screen and select the field by rotating the knob until you have arrived at the appropriate field. When a field is selected there will be a solid black border around it. Also, when you move from one field to another, the field that is to become active flashes.

Once you have selected a field and you want to enter or change the data in the field, press on the knob. Pressing the knob causes an action. In this case it activates the field. After you have entered or changed data in a field, if you press the knob again it will save the changes to the field and deactivate it.

If you are in a soft menu, requiring a user response, and you turn the data knob or press another ignored button the active soft menu will flash and beep.

**Screens**

The Accutome A-Scan Plus is set up as a series of high level screens with logically linked lower level screens. Each of the high level screens is accessed by pressing one of the dedicated function buttons. Two of the dedicated function buttons, Calculate and Preferences allow you to scroll through the lower level screens through the dedicated button.

It is in the various screens that you perform all operations; measuring patients, calculating lens replacements, setting up the Accutome A-Scan Plus, setting up IOL groups, personalizing lens constants, etc. The name of each screen is displayed in the top right corner.

### **What the Screen Displays**

Each screen displays tips for the active area, soft menus at the bottom of the screen and tables of information related to the screens function. For example, the Calculate Screen displays the Patient name and ID, the IOLs for the selected IOL Group, the calculation formulas and the K1, K2 and Target values.

### **Types of Information**

The information displayed on each screen is determined by the screen's function. For example, the Patient Records Screen displays all saved patient records. Screen items that have a white background may be selected and modified using the knob.

Any item on a screen followed by an asterisk \* indicates that the value has been changed and that it is non-standard, or, custom.

Any menu item followed by an ellipsis .... will take you to another screen when you push button beneath the menu item.

### **Soft Menus**

Each screen has selections that will perform functions that change according to the screen.

### **Tips**

One of the features that makes the Accutome A-Scan Plus so intuitive to use is the tips available on every screen. The tips are displayed at the top left of each screen. The message displayed describes the currently selected screen element.

### **Sounds**

The Accutome A-Scan Plus will also provide you with audio cues.

There is a beeping tone initiated when the probe contacts the eye. The frequency of the tone increases the closer the waveform is to being acceptable according to the criteria established in the Auto Mode.



A high continuous tone indicates valid measurements. No tone is emitted if the waveform cannot be measured. A quick double beep is emitted when the waveform is automatically captured. When you have completed capturing five waveforms the instrument will emit a high pitched chirp, indicating completion.

A confirmation beep sounds after a patient is saved and after a patient is recalled.

### **Error Messages**

There are certain situations where the Accutome A-Scan Plus will provide an error message, as well as the tones indicating error. Error messages will be displayed when there is a problem with printing or any condition that requires user attention.

### **Moving between Screens**


When moving from a high level to a lower level screen you only have to press the button beneath the menu item that indicates the lower level screen.

You can get to the IOL Groups Screen and subsequently the Personalize IOLs screen by pressing the dedicated Calculate button a second and third time. You can also access the Setup Screen by pressing the dedicated Preferences button a second time.

### **Screen Hierarchy**

Figure 4-2 on the next page illustrates the hierarchy of the Accutome A-Scan Plus screens. Notice how each high level screen is logically associated with the screens linked at a lower level.

## High Level Screen Buttons



**Figure 4-2 Accutome A-Scan Plus Screen Hierarchy**

### Top Level Screens

The top level screens are:

- Measure - for performing measurements
- Calculate - for calculating IOL power
- Patient Records - for saving, retrieving, deleting and batch printing patient records
- Preferences - for defining eye types, velocities and Accutome settings

### Associated Sub-Level Screens

Each of the high level screens has associated lower level screens that are accessed by pressing a soft menu button on the high level screen.

The associated high level and sub-level screens are as follows.

#### From the Measure Screen

From the Calculate Screen you can access the IOL Groups Screen. From the IOL Groups Screen you can access the Personalize IOLs Screen. From the Personalize IOLs Screen you can access the Update IOL Constants Screen.

**From the Patient Records Screen**

There are four lower level screens available from the Patient Records Screen. They include save/recall, print, delete and transfer.

**From the Preferences Screen**

From the top level of the Preferences Screen, which is Eye Types, you can access the Setup Screen. From the Setup Screen you can access the About This Unit Screen.

**How Buttons, Screens and Knob Work Together**

The buttons, screens and knob work together in the following manner:

1. Select a high level screen by pressing one of the dedicated function buttons.
2. In the selected screen rotate the knob to select a field requiring change.
3. Press the knob, or the Affirmative button to activate the field.
4. Make the appropriate changes to the field either by selecting a pre-entered value or entering the required information.
5. Press the knob, or the Affirmative button to save the changes made to the field.
6. Rotate the knob to select the next field requiring change.

**Changing Fields and Table Cells**

When you are in any screen every field that is in a white box can be changed. Anything not in a white box can not be changed.

When you are moving around in tables, such as the IOL Group table, and you are making changes to a selected cell, press once and the cell becomes active. Pressing the same cell twice escapes the table.

**Changing Fields and Table Cells**

When you are in any screen every field that is in a white box can be changed. Anything not in a white box can not be changed.

When you are moving around in tables, such as the IOL Group table, and you are making changes to a selected cell, press once and the cell becomes active. Pressing the same cell twice escapes the table.

**Active Area**

The active area on any screen is surrounded by a dashed border.

**Text Entry**

Certain screens require text entry. The Accutome A-Scan Plus will automatically provide you with a new soft menu of alphanumeric characters. You select the various characters by rotating the knob and enter the characters into the text field by pressing on the knob or the Affirmative button. When you have completed the text entry you can return to the screens by pressing the button beneath the selection "Done".

**Selecting a New Active Area**

To select a new active area, you must first deactivate the current active area by pressing the knob, or the Affirmative button.

**Changing Fields in the Active Area**

There are two primary types of fields; pre-entered fields that have been set up at the factory and that can not be manually changed and fields that require information to be entered.

**Pre-entered Fields**

There are many fields that contain pre-entered information that cannot be changed. For example, in the Setup Screen there is a number of elections available for the Printer and selections available that include networking, new patient defaults, date and time and auto-mode.

To change the value of a pre-entered field:

1. Select the field by rotating the knob.
2. Activate the field by pressing the knob or the Affirmative button.
3. When the field is active, rotate the knob to select one of the pre-entered values.

### **Fields Requiring Information**

There are several fields that require the input of information. For example, the Patient name field.

To enter information in a field:

1. Select the field by rotating the knob.
2. Activate the field by pressing the knob or the Affirmative button.
3. When the field is active, enter the appropriate information.

### **Numeric Fields**

Fields that require a numeric value can be selected and adjusted with the knob. To enter a numeric value in a field:

1. Select the field by rotating the knob.
2. Activate the field by pressing the knob or the Affirmative button.
3. When the field is active, rotate the knob until you reach the appropriate value.

### **Keyboard Shortcuts**

The Accutome A-Scan Plus allows you to perform operations from the keyboard. There is no need to push buttons to acquire patient measurements; all measurement functions can be executed using the keyboard shortcuts given in Table 4-1 on the next page.

**Table 4-1 Keyboard Shortcuts**

<b>Action</b>	
F1 - F6	Correlate to the soft menu keys, functions change according to selected screen
F7	Same as Print key
F8	Operates like the footswitch, will display the Measure Screen from other screens, can be used to capture, select and recapture waveforms
F9	Same as Measure key
F10	Same as Calculate IOL key
F11	Same as Patient key
F12	Same as Setup key
Tab	Selects fields in forward direction, like the knob
Shift - Tab	Selects fields in reverse, like the knob
Ctrl - P	Same as print key.
Alt - P	Print screen shot (depends on current printer. If print to file, saves as BMP)
Ctrl - N	Start new patient
Ctrl - K	Show the on screen keyboard if editing a text field
↑, ↓, ←, →	Left, right selects the previous or next field on the screen, or the previous or next column in a table, or selects the previous or next value for an active field. Up, down selects the previous or next row in a table, or selects the next value for an active field
Enter	Executes an action, operates like the knob or the √ button
Delete	Operates like the "X" button, will delete the contents of an active field, used to cancel an operation
Page Up	Scrolls the table one page up
Page Down	Scrolls the table one page down
Ctrl - Home	Go to top of list
Ctrl-O	Switch to OD or OS
Home	Goes to first cell in current column
On Measure Screen:	
G	Select Gain
C	Select Cornea Gate
A	Select Anterior Lens Gate
P	Select Posterior Lens Gate
R	Select Retina Gate

T	Select Threshold Gate
Z	Select Zoom (press and hold for default)
S	Select Scroll (press and hold for default)
V	Select View
1,2,3,4	Select waveform

## Using the Footswitch

The footswitch performs four functions:

1. When you are acquiring measurements, the footswitch will capture a waveform.
2. Will select one of the five waveforms on the Measure Screen.
3. Will delete the current waveform on the Measure Screen.
4. Will access the Measure Screen from any other screen.

If you are in a screen, other than the Measure Screen, pressing the footswitch will bring you to the Measure Screen. In the Measure Screen the footswitch allows you to capture, select, or reject a waveform.

When on the eye and running, pressing the footswitch captures the data.

The footswitch can be used to select a waveform on the Measure Screen. If you want to scroll through the list of (up to) five waveforms, step on the footswitch. If you would like to recapture that waveform, step on the footswitch and keep pressing, for approximately one second, until the selected waveform clears from the measurements table.

When on the eye, and the unit is set to auto restart, holding the foot pedal down will prevent autocapture until released.

# 5

## Preferences

### **Setting Up the Accutome A-Scan Plus**

The Accutome A-Scan Plus is equipped with personal preference options, and provides the flexibility necessary to customize your machine. You can not only add eye types and lens materials, but you can also set many operational defaults. All preferences are set on the eye types or setup screen.

Preference options include:

- Adding new anterior/vitreous chamber and lens materials and assigning velocities
- Adding new eye types
- Setting Print Title
- Setting the Printer
- Adjusting the contrast
- Setting the New Patient Defaults, including Eye Type, ID, Gain and Target
- Setting the K Index
- Setting the IOL Power Table Step
- Setting the Date and Time
- Turning the sound on and off
- Setting the Auto Restart option
- Turning the screen saver on and off
- Saving Default Gate/Threshold locations



### How to Access Preferences

To access the Accutome A-Scan Plus Preferences, press the Preferences button, located on the right side of the front panel (see Figure 5-1 below).



**Figure 5-1 Preferences Button**

Note:

*If you press the Preferences button a second time the Accutome A-Scan Plus will scroll to the Setup Screen, which is the next lower level linked screen.*

### Top Level of Preferences

When you press the Preferences button the Accutome A-Scan Plus will display the Eye Types screen (see Figure 5-2 below). In the Eye Types screen you can add a new Eye Type, new lens material, new Anterior/Vitreous material and assign velocities to each of these materials.

The Eye Types screen also has the following soft menu selections activated by buttons beneath the selection:

- Reset Field to Factory - resets the current field to the factory default.
- Reset All to Factory - resets all fields to the factory defaults. Fields labeled with \* will be reset.
- More Settings... - displays the Setup screen.

Custom Eye Type		Default Eye Types		
Eye Types				
Eye Type Name	Lens	Thickness	AC	VC
Phakic	Phakic	Measured	Aqueous	Vitreous
Silicone Filled	Phakic	Measured	Aqueous	Silicone Oil
Dense Cataract	Phakic	4.70	Aqueous	Vitreous
Pseudo PMMA	PMMA	0.70	Aqueous	Vitreous
Pseudo Silicone	Silicone	1.40	Aqueous	Vitreous
Pseudo Acrylic	Acrylic	0.70	Aqueous	Vitreous
		Measured		
		Measured		
Aphakic	[none]	[none]		1532

Materials			
Lens		Anterior/Vitreous	
Material	Velocity [m/s]	Material	Velocity [m/s]
Phakic	1641	Aqueous	1532
PMMA	2680	Vitreous	1532
Silicone	980	Silicone Oil	980
Acrylic	2120		

[All eye types include an assumed cornea] [\*not factory default]

Reset Field to Factory   
 Reset All to Factory   
 More Settings...

Figure 5-2 Eye Types Screen

## How to Add a New Eye Type

The Accutome A-Scan Plus provides the ability to customize the current patient eye type for unique or rare eye types using the Customize Eye Type screen.

When you add a new eye type, you will add the eye type to the Eye Types table shown in the Figure on next page. Prior to adding the eye type to the table, you must define all materials that may constitute the new eye type. You must first, if necessary, add a new Lens Material and Velocity, and new Anterior/Vitreous Material and Velocity.

Note:

*It is also possible to edit existing Eye Type information in the Accutome A-Scan Plus. To edit eye type information follow the same procedure as adding eye type information.*

**CAUTION:** Changing eye type and velocity information does not affect the eye type information for current and saved patients.

The changes will be in effect the next time the changed eye type is selected or a new patient is started.

Current patient eye types that do not match the settings on the Eye Types Screen are indicated with \* on the Measure and Calculate screens.

### Adding a New Lens Material

Before using a material in the definition of an Eye Type, the lens material must exist in the lens material table.

To add a new lens material:

1. Rotate the knob and select the Lens Material table. The table is selected when it is surrounded by a solid black border.

The screenshot shows a software interface with two main tables: 'Eye Types' and 'Materials'. The 'Eye Types' table is at the top, and the 'Materials' table is at the bottom. The 'Materials' table is highlighted with a solid black border, indicating it is the selected table for editing.

Lens		Anterior/Vitreous		
Material	Velocity [m/s]	Material	Velocity [m/s]	
Phakic	1641	Aqueous	1532	
PMMA	2680	Vitreous	1532	
Silicone	980	Silicone Oil	980	
Acrylic	2120			

[All eye types include an assumed cornea]

[not factory default]

Reset Field to Factory    Reset All to Factory    More Settings...

Figure 5-3 Selecting the Lens Materials Table

2. Press the knob to activate the Lens Material table. The table is activated when it is surrounded by a dashed border as shown in Figure 5-4 below.
3. When the table is activated rotate the knob until an empty cell in the Material column is selected. The cell will be selected when it is surrounded by a solid black border.
4. Activate the cell by pressing the knob.

Material
Default Eye Types

Eye Types

Eye Type Name	Lens	Thickness	AC	VC
Phakic	Phakic	Measured	Aqueous	Vitreous
Silicone Filled	Phakic	Measured	Aqueous	Silicone Oil
Dense Cataract	Phakic	4.70	Aqueous	Vitreous
Pseudo PMMA	PMMA	0.70	Aqueous	Vitreous
Pseudo Silicone	Silicone	1.40	Aqueous	Vitreous
Pseudo Acrylic	Acrylic	0.70	Aqueous	Vitreous
		Measured		
		Measured		
Aphakic	[none]	[none]		1532

Materials

Lens	
Material	Velocity [m/s]
Phakic	1641
PMMA	2680
Silicone	980
Acrylic	2120

Anterior/Vitreous	
Material	Velocity [m/s]
Aqueous	1532
Vitreous	1532
Silicone Oil	980

[\*not factory default]

[All eye types include an assumed cornea]

Reset Field to Factory
Reset All to Factory
More Settings...

*Figure 5-4 Selecting a Cell to Enter New Lens Material*

5. Enter the name of the new Lens Material.
6. Press the knob or the  $\sqrt{\quad}$  button to save the Material name and to deactivate the cell.

Enter material name		Default Eye Types		
<b>Eye Types</b>				
Eye Type Name	Lens	Thickness	AC	VC
Phakic	Phakic	Measured	Aqueous	Vitreous
Silicone Filled	Phakic	Measured	Aqueous	Silicone Oil
Dense Cataract	Phakic	4.70	Aqueous	Vitreous
Pseudo PMMA	PMMA	0.70	Aqueous	Vitreous
Pseudo Silicone	Silicone	1.40	Aqueous	Vitreous
Pseudo Acrylic	Acrylic	0.70	Aqueous	Vitreous
		Measured		
		Measured		
Aphakic	[none]	[none]		1532
<b>Materials</b>				
Lens		Anterior/Vitreous		
Material	Velocity [m/s]	Material	Velocity [m/s]	
Phakic	1641	Aqueous	1532	
PMMA	2660	Vitreous	1532	
Silicone	980	Silicone Oil	980	
Acrylic	2120			
Cell				
[not factory default]				
[All eye types include an assumed cornea]				
Reset Field to Factory	Reset All to Factory	More Settings...		

**Figure 5-5 Entering the Name for New Lens Material**

### Assigning a Velocity to the New Lens Material

The Accutome A-Scan Plus is set up at the factory with default sonic velocities for the most common types of lens materials. The Accutome A-Scan Plus knows which velocity to use for each eye type. Whenever possible you should use one of the default lens materials and velocities.

If you need to modify the velocity of a new lens material:

1. Rotate the knob and select the Velocity cell for the newly added Lens Material, indicated by the solid black border.
2. Press the knob or the  $\sqrt{\quad}$  button, to activate the Velocity cell, indicated by the dashed border.
3. Enter the value of the new Velocity.
4. Press the knob or the  $\sqrt{\quad}$  button, to save the Velocity value and to deactivate the cell.
5. Press the knob or the  $\sqrt{\quad}$  button, a second time to deactivate the Lens Materials table.




Figure 5-6 Adding New Material Velocity

**Adding the New Eye Type Information**

1. Rotate the knob and select the Eye Types table.
2. Press the knob or the  $\sqrt{\quad}$  button, to activate the Eye Types table.
3. Within the Eye Types table, rotate the knob to select an empty cell, indicated by a solid black border, for entering the new eye type name.




Figure 5-7 Selecting the Eye Type Name Cell

4. Enter the name of the new Eye Type.
5. Press the knob or the  $\checkmark$  button, to save the Eye Type Name and to deactivate the cell.




Figure 5-8 Adding the New Eye Type Name



6. Within the Eye Types table, rotate the knob to select the Lens cell associated with the Eye Type Name you just entered.
7. Press the knob or the  $\checkmark$  button, to activate the cell, indicated by the dashed border.

Select lens material
Default Eye Types

### Eye Types

Eye Type Name	Lens	Thickness	AC	VC
Phakic	Phakic	Measured	Aqueous	Vitreous
Silicone Filled	Phakic	Measured	Aqueous	Silicone Oil
Dense Cataract	Phakic	4.70	Aqueous	Vitreous
Pseudo PMMA	PMMA	0.70	Aqueous	Vitreous
Pseudo Silicone	Silicone	1.40	Aqueous	Vitreous
Pseudo Acrylic	Acrylic	0.70	Aqueous	Vitreous
Pseudo Collamer		Measured		
		Measured		
Aphakic	[none]	[none]		1532

### Materials


Lens		Anterior/Vitreous	
Material	Velocity [m/s]	Material	Velocity [m/s]
Phakic	1641	Aqueous	1532
PMMA	2660	Vitreous	1532
Silicone	980	Silicone Oil	980
Acrylic	2120		
Collamer	1180		

[All eye types include an assumed cornea]
[\*not factory default]

Reset Field to Factory
Reset All to Factory
More Settings...

**Figure 5-9 Activating the Area to Select New Lens Material**

8. Within the Lens cell, rotate the knob to select one of the pre-entered Lens Materials. In the example below, Collamer is the newly added and selected lens material. (If you previously added new lens materials, they should appear in this list.)
9. Press the knob or the  $\checkmark$  button, to save the Lens Material and to deactivate the cell.



**Figure 5-10 Lens Material Selected**

10. Within the Eye Types table, rotate the knob to select the Lens Thickness Cell associated with the current Eye Type Name, and Lens.
11. Press the knob or the  $\checkmark$  button, to activate the cell, indicated by the dashed border.
12. If the Lens thickness can be measured using ultrasound the entry should be “Measured”. If the value for Lens Thickness is not “Measured” (and it’s possible to measure the thickness), press the X button to remove the entered thickness and display “Measured”.
13. If the Lens thickness can not be measured using ultrasound, enter an assumed lens thickness for this type of lens by turning the knob. In the example given, the thickness that has been entered is “44”.




Figure 5-11 Lens Thickness Entered

14. Within the Eye Types table, rotate the knob to select the AC cell associated with the current Eye Type Name, and Lens.
15. Press the knob or the  $\checkmark$  button, to activate the cell, indicated by the dashed border.
16. Within the AC cell, rotate the knob to select one of the pre-entered Anterior Materials. (If you previously added new anterior chamber materials, they should appear in this list.)
17. Press the knob or the  $\checkmark$  button, to save the selected Anterior Material and to deactivate the cell.

Select chamber material Default Eye Types

### Eye Types

Eye Type Name	Lens	Thickness	AC	VC
Phakic	Phakic	Measured	Aqueous	Vitreous
Silicone Filled	Phakic	Measured	Aqueous	Silicone Oil
Dense Cataract	Phakic	4.70	Aqueous	Vitreous
Pseudo PMMA	PMMA	0.70	Aqueous	Vitreous
Pseudo Silicone	Silicone	1.40	Aqueous	Vitreous
Pseudo Acrylic	Acrylic	0.70	Aqueous	Vitreous
Pseudo Collamer	Collamer	0.44	Aqueous	
		Measured		
Aphakic	[none]	[none]		1532

### Materials

Lens		Anterior/Vitreous	
Material	Velocity [m/s]	Material	Velocity [m/s]
Phakic	1641	Aqueous	1532
PMMA	2660	Vitreous	1532
Silicone	980	Silicone Oil	980
Acrylic	2120		
Collamer	1180		

[All eye types include an assumed cornea] [\*not factory default]

Reset Field to Factory   
 Reset All to Factory   
 More Settings...

**Figure 5-12 Anterior Chamber Material Selected**

18. Within the Eye Types table, rotate the knob to select the VC cell associated with the current Eye Type Name, Lens, and Anterior Chamber.
19. Press the knob or the  $\sqrt{\quad}$  button, to activate the cell, indicated by the dashed border.
20. Within the VC cell, rotate the knob to select one of the pre-entered Vitreous Materials. (If you previously added new vitreous chamber materials, they should appear in this list.)
21. Press the knob or the  $\sqrt{\quad}$  button, to save the selected Vitreous Material and to deactivate the cell.
22. Press the knob or the  $\sqrt{\quad}$  button, a second time to deactivate the Lens Materials table.




Figure 5-13 Vitreous Chamber Material Selected

### Eye Type Screen Menu Selections

There are three menu selections available for execution at the bottom of the Eye Types Screen. Two of the selections, “Reset Field to Factory” and “Reset All to Factory” can be used to restore eye type information.


Any information that is displayed in a white field on the Eye Type screen can be changed. Most of these fields (excluding the empty fields for adding eye type information) contain default values that have been pre-entered at the factory.

#### Reset Field to Factory

The Reset Field to Factory selection provides you with the ability to return any pre-entered field on the Eye Types Screen to its default factory value.

If you have already changed, or are editing a pre-entered field on the Eye Type screen, and you would like to reset it:

1. Rotate the knob until the field you would like to reset is selected with a solid black border as shown in Figure 5-14 below.



**Figure 5-14 Non-Factory Field**

2. Press the button beneath the “Reset Field to Factory” selection.
3. The Accutome A-Scan Plus will prompt you with the message “Are you sure?” as shown in Figure 5-15 on the next page. You must select either “Cancel” or “Yes”.
4. Press the button beneath the selection “Yes”. (You can also press the Affirmative button located on the right side of the front panel.)

Assumed Lens Thickness [mm]			Default Eye Types	
<b>Eye Types</b>				
Eye Type Name	Lens	Thickness	AC	VC
Phakic	Phakic	Measured	Aqueous	Vitreous
Silicone Filled	Phakic	Measured	Aqueous	Silicone Oil
Dense Cataract	Phakic	4.62	Aqueous	Vitreous
Pseudo PMMA	PMMA	0.70	Aqueous	Vitreous
Pseudo Silicone	Silicone	1.40	Aqueous	Vitreous
Pseudo Acrylic	Acrylic	0.70	Aqueous	Vitreous
		Measured		
		Measured		
Aphakic	[none]	[none]		1532
<b>Materials</b>				
Lens		Anterior/Vitreous		
Material	Velocity [m/s]	Material	Velocity [m/s]	
Phakic	1641	Aqueous	1532	
PMMA	2660	Vitreous	1532	
Silicone	980	Silicone Oil	980	
Acrylic	2120			
[All eye types include an assumed cornea]				
Are you sure?			X	
Reset ALL fields to factory default			Cancel Yes	

Figure 5-15 Restore Selected Field Prompt

- The Accutome A-Scan Plus will reset the selected field to its factory default as shown in Figure 5-16 on the next page.




Figure 5-16 Selected Field Restored

### Reset All to Factory

The Reset All to Factory selection provides you with the ability to return all pre-entered fields on the Eye Types Screen to their default factory values.

If you have already changed several pre-entered fields on the Eye Type screen and you would like to reset them:

1. Press the button beneath the selection “Reset All to Factory”.



Lens Materials					Default Eye Types
<b>Eye Types</b>					
Eye Type Name	Lens	Thickness	AC	VC	
Phakic	Phakic	Measured	Aqueous	Vitreous	
Silicone Filled	Phakic	Measured	Aqueous	Silicone Oil	
Dense Cataract	Phakic	4.56'	Aqueous	Vitreous	
Pseudo PMMA	PMMA	0.65'	Aqueous	Vitreous	
Pseudo Silicone	Silicone	1.40	Aqueous	Vitreous	
Pseudo Acrylic	Acrylic	0.70	Aqueous	Vitreous	
Pseudo Collamer	Collamer	0.44	Aqueous	Vitreous	
		Measured			
Aphakic	[none]	[none]		1532	
<b>Materials</b>					
Lens		Anterior/Vitreous			
Material	Velocity [m/s]	Material	Velocity [m/s]		
Phakic	1641	Aqueous	1532		
PMMA	2660	Vitreous	1532		
Silicone	980	Silicone Oil	980		
Acrylic	2120				
Collamer	1180				
[All eye types include an assumed cornea]					
Reset Field to Factory			Reset All to Factory		
				More Settings...	

**Figure 5-17 Non-Factory Fields Displayed**

2. The Accutome A-Scan Plus will prompt you with the message “Are you sure?” as shown in Figure 5-18 on the next page. You must either cancel or continue.
3. Press the button beneath the selection “Yes”. (You can also press the Affirmative button located towards the right side of the front panel.)
4. The Accutome A-Scan Plus will reset all fields to their factory default.




Figure 5-18 Restore All Fields Prompt

Note:

At this point, if you would like to continue with the setting preferences, press the button beneath the selection “More Settings...” or press the dedicated Preferences button a second time.

### More Settings

From the high level Eye Types Screen you can access the remainder of the preference options. When you press the button beneath the selection “More Settings” the Accutome A-Scan Plus will display the Setup Screen as shown in Figure 5-19 on the next page.

### Setup Screen Fields

In the Setup screen you can change the following fields:


- Printer
- Update Printer
- Print Title
- Network Address
- Contrast
- New Patient Defaults including; Eye Type, ID, Gain and Gates/Threshold

- Default K Index
- IOL Step for IOL Calculation Power Table
- Network folder
- Date
- Time
- Auto Mode

**Setup Screen Soft Menu**

The Setup screen has the following soft menu selections activated by the buttons beneath the selection:

- Sound On/Sound Off - toggles the measurement quality sound on and off
- Restart On/Restart Off - toggles automatic restart on and off
- Scr Save On/Scr Save Off - toggles the 30 minute inactivity screen saver on and off
- Save Gates - saves the location of the gates/threshold as they are currently set, as the new patient default
- About This Unit - displays the “About Screen”
- Done... - exits the Setup Screen and returns you to the Eye Types Screen



*Figure 5-19 More Settings - Setup Screen*

## How to Set the Printer

In order to obtain the best print out possible from the Accutome A-Scan Plus, it is recommended that all records be printed to a HP, or HP compatible printer. The Accutome A-scan plus has over 200 HP drivers included in the software. We support all HP PCL3, PCL5 or postscript based printers.

In addition, as new printers are released by HP, the A-Scan has the ability to load the new drivers using the USB port and a memory stick.

To set the printer:

1. Within the Setup Screen, rotate the knob to select the Printer field, indicated by a solid black border as shown in figure 5-20.

The screenshot shows the 'Printer' setup screen. The 'Printer' field is highlighted with a solid black border and contains the text 'Print to pdf file (Network Folder)'. Other fields include 'Print Title', 'K Index' (1.3375), 'IOL Step' (0.50), 'Network Address' (Automatic), 'IP Address' (10.2.1.213), 'Subnet Mask' (255.255.255.0), 'Gateway Address' (10.2.1.1), 'Host' (Accutome-PC), 'Folder' (netshare), 'User' (ascanshare), 'Pword' (\*\*\*\*\*), 'Contrast', 'New Patient Defaults' (Eye Type: Phakic, ID, Gain: 15 dB, Target: 0.00 D), 'Date/Time' (2011.03.01 13:53:35), and 'Auto Mode' (Sclera: Off, Retina: On, Stable: Off). At the bottom, there are buttons for 'Sound ON/OFF', 'Restart ON/OFF', 'Scr Save ON/OFF', 'Save Gates', 'About This Unit...', and 'Done...'.

*Figure 5-20 Printer Field Selected*

2. Press the knob or the  $\sqrt{\phantom{x}}$  button, to activate the field, indicated by the dashed border as shown in 5-21.




Figure 5-21 Printer Field Open

3. Within the Printer field, rotate the knob to select one of the pre-entered options as shown in 5-22.




Figure 5-22 Selecting the Printer

4. Press the knob or the  $\sqrt{\quad}$  button, to save the selected Printer and to deactivate the field as shown in figure 5-23.




Figure 5-23 Printer Selected

The Accutome A-Scan has the ability to update the printer driver as new releases become available from Accutome.

To Update printer drivers:

1. Install the USB stick provided by Accutome into any USB port.

2. Within the setup screen, rotate the knob and select printer, indicated by the solid black border as shown in figure 5-24.




Figure 5-24 Select Printer



- 3. Press the knob or the check mark, to activate the printer field, indicated by the dashed border as shown in figure 5-25.




Figure 5-25 Activate the Printer Field

4. Rotate the knob until “none” is selected as shown in figure 5-26.





Figure 5-26 Printer Selection “None”

5. Press the knob or the check mark to confirm selection of none as shown in figure 5-27.



*Figure 5-27 New Patient Selected*

6. Within the setup screen, rotate the knob to select “Update...” field, indicated by a solid black border.





Figure 5-28 Update Selected

7. Press the knob or the check mark button, to activate the field, indicated by the dashed border as shown in figure 5-29.



*Figure 5-29 Are You Sure?*

8. The screen will prompt: “Are you sure? Update Custom printer drivers from USB Disk?”
9. Press yes,  $\checkmark$  or the knob.

10. Upon completion of the updating of the files, the system will prompt you, "Driver update complete." Press OK as shown in figure 5-30.

Update Custom printer driver from USB Disk Setup

Printer  Update...

Print Title

K Index

IOL Step  D

Network Address

IP Address  Host

Subnet Mask  Folder

Gateway Address  User

Network Folder  Off

Contrast

Pword

**New Patient Defaults**

Eye Type

ID

Gain  dB

Target  D

Date/Time

Y M D

2011 - 03 - 02

H M S

08 : 39 : 10

Auto Mode (SR)

Sclera  On

Retina  On

Stable  Off

Driver update complete OK

*Figure 5-30 Driver Update Complete*

- 11. Within the set up screen, rotate the knob and select printer, indicated by the solid black border as shown in figure 5-31.





Figure 5-31 Select Printer Field

- Press the knob or the check mark, to activate the printer field, indicated by the dashed border as shown in figure 5-32.




*Figure 5-32 Selecting Custom Print Drives*

- Rotate the knob until “custom” is selected.



14. Press the knob or the check mark to confirm selection of custom as shown in figure 5-33.




*Figure 5-33 Custom Print Drivers Selected*

### How to Set the Print Title

The Accutome A-Scan Plus provides you with the ability to have a title appear on every patient printout. For example, you may want to have a clinic name printed at the top of every page.

To set a Print Title:

1. Within the Setup Screen, rotate the knob to select the Print Title field, indicated by a solid black border as shown in figure 5-34.



*Figure 5-34 Print Title Field Selected*

2. Press the knob or the  $\sqrt{\quad}$  button, to activate the field, indicated by the dashed border as shown in figure 5-35.




Figure 5-35 Print Title Field Activated

3. Within the Print Title field, enter the title you would like printed on every record as shown in figure 3-36.

Enter title for printouts, such as clinic name Setup

Printer

Print Title

Network Address

IP Address

Subnet Mask

Gateway Address

Contrast

**New Patient Defaults**

Eye Type

ID

Gain  dB

Target  D

Date/Time

Y M D  
2011 . 03 . 01

H M S  
15 : 35 : 05

Auto Mode  
( R )

Sclera

Retina


Stable

Sound ON  Restart ON  Scr Save ON  Save Gates  Done...

Sound OFF  Restart OFF  Scr Save OFF

*Figure 5-36 Entering the Print Title*

4. Press the knob or the  $\checkmark$  button, to save the entered Print Title and to deactivate the field as shown in figure 5-37.



**Figure 5-37 Print Title Added**

**How to Select Automatic or Manual Network Address**

The network address allows you to receive the IP address automatically or enter static address manually. When set to automatic, the IP address is automatically provided by the network server. In most cases, it is the preferred method.

When set to manual, please refer to the site’s network manager for information pertaining to the address.

1. To select the automatic or manual network address, rotate the knob until the network address is highlighted as shown in figure 5-38.
2. Press the knob or the check mark to activate box.
3. Rotate knob to select manual or automatic.

4. Press the knob or check mark to confirm the selection.

Network address selection method		Setup
Printer	Print to postscript file (USB Disk)	Update...
Print Title	Andersen Eye Clinic	K Index 1.3375
		IOL Step 0.25 D
Network Address	Automatic	Network Folder On
IP Address	10.2.1.213	Host Accutome-PC
Subnet Mask	255.255.255.0	Folder netshare
Gateway Address	10.2.1.1	User ascanshare
		Pword *****
Contrast	<input type="range"/>	
<b>New Patient Defaults</b>		Date/Time
Eye Type	Phakic	Y 2011 . M 03 . D 10
ID	<input type="text"/>	H 11 : M 53 : S 53
Gain	15 dB	Auto Mode (SRS)
Target	-0.25 D	Sclera On
		Retina On
		Stable On
Sound ON	Restart ON	Scr Save ON
Save Gates	About This Unit...	Done...
Sound OFF	Restart OFF	Scr Save OFF

*Figure 5-38 Selecting Automatic Network Address*

When set to manual, please refer to the site’s network manager for the following information: Static IP address, Subnet mask, and Gateway address.

The following steps will guide you through entering data in “Manual” mode:

- a. Press “**Enter**” or “**√**” button to activate the box to allow changes.

Network Address: Automatic  
IP Address: 10.2.1.156  
Subnet Mask: 255.255.255.0  
Gateway Address: 10.2.1.1

- b. Press “**→**” or “**←**” key or turn the knob to change from “Automatic” to “Manual”.

Network Address: Manual  
IP Address:  
Subnet Mask:  
Gateway Address:

- c. Press the “**Enter**” key to set to “**Manual**” mode.

*Note: Make sure to restart the unit after the mode changes.*

Network Address: Manual  
IP Address:  
Subnet Mask:  
Gateway Address:

- d. Use the “**Tab**” key or the rotary knob to select the three entry boxes.

Network Address: Manual  
IP Address:  
Subnet Mask:  
Gateway Address:

- e. Press the “**Enter**” or “**√**” button to activate the box and allow the **static IP** to be entered.

Network Address: Manual  
IP Address:  
Subnet Mask:  
Gateway Address:

- f. Type in the **static IP** of the site. Press the “**Enter**” key when finished and press “**Tab**” to move to the **Subnet Mask** field.

Network Address: Manual  
IP Address: 10.2.1.251  
Subnet Mask:  
Gateway Address:

- g. Type in the network mask to the site and press “**Enter**” when finished. Press “**Tab**” to move to **Gateway Address**.

Network Address	Manual
IP Address	10.2.1.251
Subnet Mask	255.255.255.0
Gateway Address	

- h. Type in the address of the gateway computer and press “**Enter**” when finished. Restart the unit to make those changes effective.

Network Address	Manual
IP Address	10.2.1.251
Subnet Mask	255.255.255.0
Gateway Address	10.2.1.1

### How to Adjust the Contrast

You may need to adjust the contrast because the optimal contrast setting varies with viewing angle and temperature. The Contrast feature in the Setup Screen allows you to adjust the contrast of the instrument's display screen.

Note:

*The contrast can be adjusted at any time, on any screen, by pressing and holding the preferences button while turning the knob.*

To adjust the Accutome A-Scan Plus Contrast:

1. Within the Setup Screen, rotate the knob to select the Contrast field, indicated by a solid black border as shown in figure 5-39.








Figure 5-39 Contrast Field Selected

2. Press the knob or the  $\sqrt{\quad}$  button, to activate the field, indicated by the dashed border as shown in figure 5-40.



*Figure 5-40 Contrast Field Activated*

3. With the Contrast field active, rotate the knob to adjust the white/grey contrast of the screen. The amount of grey vs. white is indicated in the Contrast field by a solid grey bar, that increases or decreases as you adjust the contrast as shown in figure 5-41.



*Figure 5-41 Adjusting the Contrast*

4. Press the knob or the  $\sqrt{\quad}$  button, to save the altered Contrast and to deactivate the field as shown in figure 5-42.

The screenshot displays the 'Screen Contrast' setup window. At the top, there are fields for 'Printer' (Print to postscript file (Network Folder)), 'Print Title' (Andersen Eye Clinic), 'K Index' (1.3375), and 'IOL Step' (0.50). Below these are network settings: 'Network Address' (Automatic), 'IP Address' (10.2.1.213), 'Subnet Mask' (255.255.255.0), and 'Gateway Address' (10.2.1.1). A 'Network Folder' section is set to 'On' with 'Host' (Accutome-PC), 'Folder' (nc\share), 'User' (ascanshare), and 'Pword' (\*\*\*\*\*). A 'Contrast' slider is visible. The 'New Patient Defaults' section includes 'Eye Type' (Phakic), 'ID', 'Gain' (15 dB), and 'Target' (0.00 D). A 'Date/Time' section shows '2011-03-01 15:48:32'. An 'Auto Mode' section has 'Sclera' (Off), 'Retina' (On), and 'Stable' (Off). At the bottom, there are buttons for 'Sound ON/OFF', 'Restart ON/OFF', 'Scr Save ON/OFF', 'Save Gates', 'About This Unit...', and 'Done...'.

*Figure 5-42 Contrast Adjusted*

### How to Set the Default Patient Eye Type

The Accutome A-Scan Plus has a default eye type setting so that every time you start a new patient you do not have to select an eye type. When you start a new patient the eye type displayed on the Measure Screen will be the default eye type selected in the Setup Screen.

To change the default eye type:

1. Within the Setup Screen, rotate the knob to select the Default Eye Type field, indicated by a solid black border as shown in figure 5-43.




Figure 5-43 Default Eye Type Field Selected

2. Press the knob or the  $\sqrt{\quad}$  button, to activate the field, indicated by the dashed border as shown in figure 5-44.




Figure 5-44 Default Eye Type Field Activated

3. Within the Default Eye Type field, rotate the knob to select one of the pre-entered Eye Types as shown in Figure 5-45 below

**Select default eye type** Setup

Printer

Print Title  K Index

IOL Step  D

Network Address

Network Folder  On

IP Address  Host

Subnet Mask  Folder

Gateway Address  User

Pword

Contrast

**New Patient Defaults**

Eye Type

ID

Gain  dB

Target  D

Date/Time

Y M D

2011 . 03 . 01

H M S

15 : 59 : 17

Auto Mode

( \_ R )

Sclera  Off

Retina  On


Stable  Off

Sound ON  Restart ON  Scr Save ON  Save Gates

Sound OFF  Restart OFF  Scr Save OFF

*Figure 5-45 New Default Eye Type Selected*

4. Press the knob or the  $\checkmark$  button, to save the selected Default Eye Type and to deactivate the field as shown in figure 5-46.



*Figure 5-46 Default Eye Type Changed*

**How to Set the Default ID**

The Accutome A-Scan Plus provides you with the ability to have a Default ID appear whenever you start a new patient. For example, you may want to have a doctor’s name, or a clinic’s name as a Default ID.

To set a Default ID:

1. Within the Setup Screen, rotate the knob to select the Default ID field, indicated by a solid black border as shown in figure 5-47.

Default ID used for new patient Setup

Printer

Print Title  K Index

IOL Step  D

Network Address

IP Address  Host  Network Folder

Subnet Mask  Folder

Gateway Address  User

Contrast  Pword

**New Patient Defaults**

Eye Type  Date/Time Y M D  
2011 . 03 . 01

ID  H M S  
16 : 08 : 43

Gain  dB Auto Mode ( \_ R \_ )

Target  D Sclera

Retina

Stable

Sound ON Restart ON Scr Save ON Save Gates About  
Sound OFF Restart OFF Scr Save OFF This Unit... Done...

*Figure 5-47 Default ID Field Selected*

2. Press the knob or the  $\sqrt{\quad}$  button, to activate the field, indicated by the dashed border as shown in figure 5-48.






Figure 5-48 Default ID Field Activated

3. Within the Default ID field, enter the default ID as shown in figure 5-49.




Figure 5-49 Entering the Default ID

4. Press the knob or the  $\checkmark$  button, to save the entered Default ID and to deactivate the field as shown in figure 5-50.

Default ID used for new patient

Printer  Update...

Print Title  K Index

IOL Step  D

Network Address

IP Address  Host  Network Folder  On

Subnet Mask  Folder

Gateway Address  User

Contrast  Pword

**New Patient Defaults**

Eye Type

ID

Gain  dB

Target  D

Date/Time

Y M D  
2011 . 03 . 01

H M S  
16 : 10 : 53

Auto Mode ( R )

Sclera  Off

Retina  On

Stable  Off

Sound ON Restart ON Scr Save ON Save Gates About This Unit... Done...

Sound OFF Restart OFF Scr Save OFF


**Figure 5-50 Default ID Added**

### How to Set the Default Gain

The Default Gain parameter allows you to adjust the new patient ultrasound gain. You can adjust the gain for any waveform from the Measure Screen, but when you adjust the gain value on the Setup Screen the adjusted gain becomes the default gain for all new patients. The gain can be adjusted throughout the range of 0dB to 23 dB in increments of 1dB.

To adjust the gain:

1. Within the Setup Screen, rotate the knob to select the gain field, indicated by a solid black border.
2. Press the knob or the  $\checkmark$  button, to activate the field, indicated by the dashed border as shown in figure 5-51.



**Figure 5-51 Default Gain Field Selected**

3. Rotate the knob to select one of the pre-entered gain values, or manually enter the new value. The gain is adjustable in increments of 1 dB from 0- 23 dB.
4. When the gain is at the appropriate level, press either the knob or the  $\sqrt{\quad}$  button, to save the adjusted value and to deactivate the field as shown in figure 5-52.

The screenshot shows the 'Setup' screen for the Accutome A-Scan Plus. The title bar reads 'Default Gain used for new patient' and 'Setup'. The interface includes several sections:

- Printer:** Print to postscript file (Network Folder) [Update...]
- Print Title:** Andersen Eye Clinic
- K Index:** 1.3375
- IOL Step:** 0.50 D
- Network Address:** Automatic
- Network Folder:** On
- IP Address:** 10.2.1.213
- Subnet Mask:** 255.255.255.0
- Gateway Address:** 10.2.1.1
- Host:** Accutome-PC
- Folder:** netahare
- User:** ascanshare
- Pword:** \*\*\*\*\*
- Contrast:** [Knob]
- Date/Time:** Y: 2011, M: 03, D: 01; H: 16, M: 26, S: 35
- Auto Mode (R):** Sclera: Off, Retina: On, Stable: Off
- New Patient Defaults:** Eye Type: Phakic, ID: [Field], Gain: 15 dB, Target: 0.00 D (highlighted with a solid black border)
- Bottom Bar:** Sound ON/OFF, Restart ON/OFF, Scr Save ON/OFF, Save Gates, About This Unit..., Done...

*Figure 5-52 Default Gain Field Changed*

### How to Set the Target Refraction

When you are calculating IOLs, one of the values you need to enter is the desired target refraction. The Accutome A-Scan Plus allows you to specify the default target refraction that is most common for patients. It is also possible to modify the target refraction on a per patient basis.

To set the Target Refraction:

1. Within the Setup Screen, rotate the knob to select the Target field of the New Patient Defaults, indicated by a solid black border as shown in figure 5-53.




Figure 5-53 Target Field Selected

2. Press the knob or the  $\sqrt{\quad}$  button, to activate the field, indicated by the dashed border as shown in figure 5-54.




Figure 5-54 Target Field Activated

- With the Target field active, rotate the knob until you reach the appropriate value or enter the target number on the keyboard as shown in figure 5-55.

The screenshot shows the 'Enter default post-op target refraction' setup screen. The 'New Patient Defaults' section is highlighted with a box, showing the following values:

- Eye Type: Phakic
- ID: [Empty]
- Gain: 15 dB
- Target: 25.00 D

Other visible fields include:

- Printer: Print to postscript file (Network Folder) [Update...]
- Print Title: Andersen Eye Clinic
- K Index: 1.3375
- IOL Step: 0.50 D
- Network Address: Automatic
- IP Address: 10.2.1.213
- Subnet Mask: 255.255.255.0
- Gateway Address: 10.2.1.1
- Host: Accutome-PC
- Folder: netshare
- User: ascanshare
- Pword: \*\*\*\*\*
- Date/Time: Y: 2011, M: 03, D: 01; H: 16, M: 28, S: 28
- Auto Mode (R): Sclera: Off, Retina: On, Stable: Off

At the bottom, there are buttons for Sound ON/OFF, Restart ON/OFF, Scr Save ON/OFF, Save Gates, About This Unit..., and Done...

*Figure 5-55 Adjusting the Target*

- Press the knob or the  $\sqrt{\quad}$  button, to save the entered Default ID and to deactivate the field as shown in figure 5-56.




Figure 5-56 Target Adjusted

### How to Set the K Index

The keratometer index of refraction, used to convert corneal radius to diopter power is not the same for all keratometers. In North America, most units have an index of refraction of 1.3375. European keratometers may have an index of refraction of 1.3315. The factory default is 1.3375.

The K Index value is only used when entering keratometer readings in diopters. K readings can be entered on the Calculate IOL screen as well as the Personalize IOL screen. The K index associated with diopter entries is not explicitly shown. When a keratometer reading is entered in diopters the default K index is copied from the setup screen. If the K index of an entry is different than the Setup screen default K Index, a \* appears beside the entry. To change or view the K index, change or reenter the diopter entry. The Accutome A-Scan Plus will prompt you with the default and current K indexes and ask which one you want associated with the entry.

To set the K index:

1. Within the Setup Screen, rotate the knob to select the K Index field, indicated by a solid black border as shown in figure 5-57.

The screenshot shows the 'Default keratometer index of refraction (nc)' setup screen. The 'K Index' field is highlighted with a solid black border and contains the value '1.3375'. Other fields include 'Printer' (Print to postscript file), 'Print Title' (Andersen Eye Clinic), 'Network Address' (Automatic), 'IP Address' (10.2.1.213), 'Subnet Mask' (255.255.255.0), 'Gateway Address' (10.2.1.1), 'Contrast' (slider), 'Host' (Accutome-PC), 'Folder' (netshare), 'User' (ascanshare), 'Pword' (\*\*\*\*\*), 'Date/Time' (2011-03-01 16:41:46), 'Auto Mode (R)' (Sclera Off, Retina On, Stable Off), 'Eye Type' (Phakic), 'ID' (empty), 'Gain' (15 dB), and 'Target' (-0.25 D). The bottom status bar shows 'Sound ON', 'Restart ON', 'Scr Save ON', 'Save Gates', 'About This Unit...', and 'Done...'.

*Figure 5-57 K Index Field Selected*

2. Press the knob or the  $\sqrt{\quad}$  button, to activate the field, indicated by the dashed border as shown in figure 5-58.






Figure 5-58 K Index Field Activated

3. Rotate the knob to adjust the K index , or manually enter the new value. The maximum value is 1.5000 and the minimum is 1.2500 as shown in figure 5-59.




Figure 5-59 Adjusting the K Index

- Press the knob or the  $\sqrt{\quad}$  button, to save the entered Default ID and to deactivate the field as shown in figure 5-60.

The screenshot shows the 'Setup' screen of the Accutome A-Scan Plus. The title is 'Default keratometer index of refraction (nc)'. The 'K Index' field is highlighted with a solid black border and contains the value '1.3315'. Other fields include 'Print Title' (Andersen Eye Clinic), 'Network Address' (Automatic), 'IP Address' (10.2.1.213), 'Subnet Mask' (255.255.255.0), 'Gateway Address' (10.2.1.1), 'Contrast', 'New Patient Defaults' (Eye Type: Phakic, ID, Gain: 15 dB, Target: -0.25 D), 'Date/Time' (2011.03.01 16:44:50), and 'Auto Mode' (Sclera: Off, Retina: On, Stable: Off). The bottom status bar shows 'Sound ON', 'Restart ON', 'Scr Save ON', 'Save Gates', 'About This Unit...', and 'Done...'.

*Figure 5-60 K Index Field Adjusted*

### How to Set the IOL Step

The Accutome A-Scan Plus allows you to modify the diopter step used when calculating IOL power.

To adjust the IOL Step:

- Within the Setup Screen, rotate the knob to select the IOL Step field, indicated by a solid black border as shown in figure 5-61.




Figure 5-61 IOL Step Field Selected

2. Press the knob or the  $\sqrt{\quad}$  button, to activate the field, indicated by the dashed border as shown in figure 5-62.




Figure 5-62 IOL Step Field Activated

3. Rotate the knob to select one of the pre-entered step values, or manually enter the new value. The IOL power step is adjustable in increments of 0.05 D from 0.05 - 5.00 D as shown in figure 5-63.

Enter IOL calculation power table step size Setup

Printer

Print Title  K Index

IOL Step:  D

Network Address  Network Folder  On

IP Address  Host

Subnet Mask  Folder

Gateway Address  User

Pword

Contrast

**New Patient Defaults**

Eye Type

ID

Gain  dB

Target  D

Date/Time

Y  M  D

H  : M  : S

Auto Mode (R)

Sclera  Off

Retina  On

Stable  Off

Sound ON  Restart ON  Scr Save ON  Save Gates  About This Unit...

Sound OFF  Restart OFF  Scr Save OFF

*Figure 5-63 Adjusting the IOL Step*

4. When the IOL Step is at the appropriate value, press either the knob or the  $\checkmark$  button, to save the adjusted value and to deactivate the field as shown in figure 5-64.

IOL calculation power table step size Setup

Printer

Print Title  K Index

IOL Step  D

Network Address

IP Address  Host   
 Subnet Mask  Folder   
 Gateway Address  User   
 Pword

Network Folder  On

Contrast

**New Patient Defaults**

Eye Type

ID

Gain  dB

Target  D

Date/Time

Y	M	D
2011	03	01
H	M	S
16	48	19

Auto Mode (R)

Sclera	Off
Retina	On
Stable	Off


Sound ON  Restart ON  Scr Save ON  Save Gates

Sound OFF  Restart OFF  Scr Save OFF

Figure 5-64 IOL Step Adjusted

## How to Activate the Network Folder

1. Within the set up screen, rotate the knob to select the Network folder on/off field, indicated by a solid black border as shown in figure 5-65.




*Figure 5-65 Selecting Network Folder On/Off*

2. Press the knob or the check mark, to activate the field, indicated by the dashed border.
3. Within the network on/off field, select the appropriate selection, on or off.
4. Press the knob or  $\surd$  to confirm the selection.

**Configure Network Folder:**

1. Move the selection to the “**Network Folder**” section. The first entry is the “**On/Off**” toggle. The default is “**On**”. In case networking is not available or users do not intend to use the networking features, it can be turned to “**Off**”. When it is set to “**Off**”, the “**Network Folder**” location in “**Patient Records**” menu will stop functioning. In this set-up, we will leave it “**On**” and focus on how to set up the folder sharing as shown in figure 5-66.



*Figure 5-66 Configure Network Folder*

2. Set up an account and share a folder from a windows PC and collect the following information. The following are required fields:
  - Computer name (**Host**).
  - Shared folder name (**Folder**).
  - User name of an account on the PC (**User**).
  - Password of the account (**Pword**).

Here is an example of a data list is below:

Computer name ( <b>Host</b> ):	BSCANWIN7PRO5
Shared folder name ( <b>Folder</b> ):	netshare
User name of an account on PC ( <b>User</b> ):	ascanshare
Password of the account ( <b>Pword</b> ):	accutome/2011

Note:

*The data above is an example only. You must enter your own data from your own computer.*

3. The following steps show how to enter above data into each entry.

Note:

*Except the "Computer name" field, all other data are case sensitive and have to be typed in exactly the same case as in the PC.*

1. Move from "On/Off" toggle to next four entries box.

Network Folder  On

Host

Folder

User

Pword

2. Press "Enter" or press " $\sqrt{\phantom{x}}$ " button to activate the box. The border of the entire box turns to a dashed line and **Host** will be selected automatically.

Network Folder  On

Host


Folder

User


Pword




3. Type in the **computer name** and press “**Enter**” when finished. The border of the box will turn to a dashed line when you start typing and turn back to solid after you press “**Enter**”.




4. Press “**Tab**” key to move to the “**Folder**” box.




5. Type in the “**Shared folder name**” and press “**Enter**” when finished.



6. Press the “**Tab**” key to move to the “**User**” box and type in “**Name of the account**” and press “**Enter**”.



7. Press the “**Tab**” key to move to the “**Pword**” box.



Note:

*You need to use “Backspace” to remove “\*\*\*\*\*” characters before typing in the password.*

8. Type in the “**Password of the account**” and press “**Enter**”.

Network Folder		On
Host	BSCANWIN7PRO5	
Folder	netshare	
User	ascanshare	
Pword	accutome/2011	

Note:

*The password will turn back to “\*\*\*\*\*” characters after you press “Enter”.*

9. Press “**Enter**” again to turn the border of the entire box to solid and you can move to another section.

Network Folder		On
Host	BSCANWIN7PRO5	
Folder	netshare	
User	ascanshare	
Pword	*****	

10. If we need to make any changes or found any errors in data, press “**Enter**” again and it will activate the entire box and use the “**Tab**” key to move up and down.

Network Folder		On
Host	BSCANWIN7PRO5	
Folder	netshare	
User	ascanshare	
Pword	*****	

Note:

*The A-Scan Plus won't start making any connection until we press the “Done” button. Please follow the next section for making and testing connections.*

**Testing Network Connection on the A-Scan Plus**

After we configure the network folder connection on the A-Scan Plus, we can start testing the connection. Make sure the network and the PC are up and running before we can start testing the connection.

**Connect to the PC folder:**

Press the “**Done**” button on the unit and the following message will be displayed on the top left corner of the screen “**Changing network folder setting**”. If connecting was successful, the screen will change to the “**Default Eye Types**” menu. You can now start using the network folder in the “**Patient Records**” menu.

**Troubleshooting the problems:**

If something goes wrong, the unit will generate an error sound and the following message will show up: “**Network folder not found. Please check setting**”. Press “**OK**” to clear error message and go back to “**Setup**” menu. Please double check the data you entered to “Network Folder” section and check the PC settings and try again.

Note:

*If you press “Done” again without making any changes to the Network Folder settings, it will bypass the error message and the network folder will remain unfound.*

## How to Adjust the Date and Time

The Measure Screen displays the date and time that a waveform is captured. When you first set up the Accutome A-Scan Plus you can adjust the date and time as appropriate for your time zone. Both the date and time are divided into three separate fields. You adjust each field individually. The date is set up as: Year (Y), Month (M), and Day (D). The time is set up as: Hour (H), Minute (M), and Second (S). In the example given below the day of the date is adjusted.

To adjust the Date and Time:

1. Within the Setup Screen, rotate the knob to select the Day field of the date, indicated by a solid black border as shown in figure 5-67.

The screenshot shows the 'Setup' screen with various configuration options. The 'Date/Time' section is highlighted, showing the date as 2011-03-01 and the time as 17:17:34. The 'Day' field (01) is selected, indicated by a solid black border. Other fields include Printer, Print Title, Network Address, IP Address, Subnet Mask, Gateway Address, Contrast, New Patient Defaults (Eye Type, ID, Gain, Target), and Auto Mode (Sclera, Retina, Stable).

Date/Time	
Y	2011
M	03
D	01
H	17
M	17
S	34

Figure 5-67 Day Field Selected

2. Press the knob or the  $\sqrt{\quad}$  button, to activate the field, indicated by the dashed border as shown in figure 5-68.




Figure 5-68 Day Field Activated

- With the Day field active, rotate the knob until you reach the appropriate day number or enter the number with the keyboard as shown in figure 5-69.

Enter day (1 to 31) Setup

Printer

Print Title  K Index

IOL Step  D

Network Address

IP Address  Host

Subnet Mask  Folder

Gateway Address  User

Pword

Network Folder  On

Contrast

**New Patient Defaults**

Eye Type

ID

Gain  dB

Target  D

Date/Time

Y	M	D
2011	03	09
H	M	S
17	18	54

Auto Mode (R)

Sclera	Off
Retina	On
Stable	Off

Sound ON  Restart ON  Scr Save ON  Save Gates  About This Unit...

Sound OFF  Restart OFF  Scr Save OFF

*Figure 5-69 Adjusting the Day*

- Press the knob or the  $\checkmark$  button, to save the adjusted Day and to deactivate the field as shown in figure 5-70.




Figure 5-70 Day Adjusted

5. If necessary, adjust the Month (M) and Day (D) fields of the date in the same manner.
6. If necessary, adjust the Hour (H), Minute (M), and Seconds (S) fields of the time in the same manner.

### How to Set the Auto Mode

The Accutome A-Scan Plus allows you to define the Automatic measurement mode by specifying how a measurement is automatically captured. There are a total of three criteria available and each can be turned off or on by the user on the Setup screen. The criteria are:

- Sclera - automatic capture determined by sclera detection
- Retina - automatic capture determined by retina detection
- Stable - automatic capture determined by measurement stability

The Auto Mode setting is displayed in the soft menu on the Measure Screen as 'Auto (SRS), where (SRS) means Sclera, Retina, Stable. If the feature is ON, the first letter appears in its place, otherwise a placeholder '\_' is displayed.

The default is 'Sclera', displayed as 'Auto (S\_)'. Sclera must have a distinct sclera echo after the retina, above the threshold. Between the Retina and Sclera the signal must go below the threshold.

"Retina", displayed as 'Auto (\_R\_)', must begin at the base line, have no data greater than 10% of the threshold in front it (for 1.5 mm), and be steeply rising.

"Stable", displayed as 'Auto (\_S)', means the measurement needs to be within a tolerance for a certain amount of time.

Note:

*The Stable Auto Mode setting is not recommended for contact method measurements. The measurement variance caused by hand or eye movements may make the stable auto lock requirement difficult to achieve.*

Note:

*Sound, if enabled, reflects the quality of the measurement with respect to the current auto mode settings, even if you are using the Manual capture mode.*

To specify the Auto Mode:

1. Within the Setup Screen, rotate the knob to select the Sclera field of the Auto Mode, indicated by a solid black border as shown in figure 5-71.






Figure 5-71 Auto Mode Sclera Selected

- Press the knob or the  $\sqrt{\quad}$  button, to activate the field, indicated by the dashed border as shown in figure 5-72.






Figure 5-72 Auto Mode Sclera Field Activated

- With the Sclera field active, rotate the knob until you the word "On" is displayed. Automatic mode will no longer be triggered by sclera detection as shown in figure 5-73.



*Figure 5-73 Changing the Auto Mode - Turning On Sclera*

Press the knob or the  $\checkmark$  button, to save the adjusted setting and to deactivate the field as shown in figure 5-74.



**Figure 5-74 Auto Mode - “Sclera” On**

1. If you would like to define the Auto Mode by Retina signal quality, rotate the knob to select the “Retina” field.
2. Press the knob or the  $\checkmark$  button, to activate the field, indicated by the dashed border.
3. Rotate the knob to switch from “Off” to “On”
4. Press the knob or the  $\checkmark$  button, to save the adjusted Retina and to deactivate the field.
5. If you would like to define the Auto Mode by a stable measurement, rotate the knob to select the “Stable” field as shown in figure 5-75.
6. Press the knob or the  $\checkmark$  button, to activate the field, indicated by the dashed border.
7. Rotate the knob to switch from “Off” to “On”
8. Press the knob or the  $\checkmark$  button, to save the adjusted Stable and to deactivate the field.




Figure 5-75 Auto Mode - "Stable" Selected

9. Press the knob or the  $\checkmark$  button, to save Stable as On and to deactivate the field.




Figure 5-76 Auto Mode Defined by "Stable" Measurement

10. Select and turn on or off all the Auto Mode criteria until you have accurately defined how a measurement will be automatically captured.

### **Sound On/Sound Off**

The Sound On/Sound Off selection toggles between the two. When “Sound On” is selected there will be sound during measurement. When “Sound Off” is selected there will be no sound during measurement.

The audible feedback is a constant tone initiated when the probe contacts the eye. The frequency of the tone increases as the waveform is closer to being acceptable according to the criteria associated with the Auto Mode

### **Restart On/Restart Off**

The Restart On/Restart Off selection toggles between the two and will prompt the Accutome A-Scan Plus, when operated in the “Automatic” mode, to automatically restart measuring after a successful reading or to stop after each successful reading.

When “Restart On” is selected the Accutome A-Scan Plus will automatically restart for up to five automatic readings. When “Restart Off” is selected the

### **Scr Save On/Scr Save Off**

The Scr Save On/Scr Save Off selection toggles between the two and will display the screen saver or not.

The screen saver feature is provided to protect the LCD from unnecessary wear. If the screen saver is enabled and the Accutome A-Scan Plus is unused for 30 minutes, the instrument will display the screen saver and the display will go dark.

When “Scr Save On” is selected the screen saver will be displayed when the instrument is not in use. When “Scr Save Off” is selected the screen saver will not be displayed at all.

To restore the screen after the screen saver has been on, press any key and the first key press will be ignored and the screen will be restored.

### **Save and Restore Factory Default Gates and Threshold**

You may find, after using the Accutome A-Scan Plus for a while, that you frequently have to adjust one or several gates and threshold. If you continually make the same adjustments to gates/threshold, you may want to save the adjusted settings as the default for gates/threshold. When you save gates/threshold, the current locations of the gates and threshold become the new patient default locations.

To save gate/threshold settings as the default:


1. After you made gate adjustments to the current waveform in the Measure Screen, return to the Setup Screen (press the Preferences button, press more settings...). Refer to the “How to Adjust Gates/Threshold” section of this manual for more information.
2. Press the button beneath the selection “Save Gates”. The Accutome A-Scan Plus will cue with a message displayed at the top of the screen indicating you have saved the current location of the gates and threshold as the default.

To restore the locations of the gate and threshold to the factory default:

1. Press and hold Save Gates button for approximately 1 sec. You will be prompted if you want to restore gates/threshold to the factory default.

### **About This Unit**

When you press the button beneath the “About This Unit...” selection, the Accutome A-Scan Plus displays another screen, the “About This Unit Screen” as shown in Figure 5-77 on next page. This screen is informational only and lists the software version, boot version, and the status of the probe. When you press the button beneath the “Done...” selection you will return to the More Settings screen.



**Figure 5-77 About This Unit Screen**

Note:

*If setup is complete, press the button beneath the selection “Done” and you will return to the Eye Types Screen.*

# 6

## Performing Measurements

### Overview

The Accutome A-Scan Plus is very simple to operate, and has advanced features to help you obtain the best possible measurements.

The Accutome A-Scan Plus takes measurements by sending a signal through the eye through the ultrasonic probe. The signal echoes off the various parts of the eye (cornea, lens, retina) and returns a signal through the probe. The returned signal is translated and displayed as a waveform. The Accutome A-Scan Plus examines each of the echoes in the waveform and calculates the measurements from one echo to the next. All measurements are then displayed on the Measure Screen. The number of echoes detected is determined by a user selectable eye type, including Phakic, Aphakic, and Pseudophakic.

Five waveforms can be captured for each eye. Review and gate adjustment can be done after waveform capture to ensure proper measurement.

The Accutome A-Scan Plus provides many user controls to obtain accurate measurements. These include the support for contact or immersion method, individual velocities, automatic capture of readings, gain control, manual and automatic gate adjustment, and zoom.

During measurement, the instrument will provide audible feedback of contact, signal quality, and capture.

This chapter provides you with information to control, capture, and review waveforms.



### Measure Screen

When you power on the Accutome A-Scan Plus the Measure Screen is displayed as shown in Figure 6-1 below. You can get to the Measure Screen at any time by pressing the Measure button located at the right side of the front panel or pressing the footswitch.

When you power on the instrument, or start a new Patient, all settings are set to predetermined values. The patient eye type, gain, gates/threshold, and ID are set as determined by the Setup Screen. The patient name field and all measurements are cleared.

Capture mode (automatic or manual), and probe coupling method (contact or immersion) remain as last set by the user and are retained while the Accutome A-Scan Plus is turned off.




Figure 6-1 Measure Screen Displaying Current Settings

### **Information Displayed on the Measure Screen**

The Measure Screen provides the continuous display of Axial Length, ACD, Lens Thickness, and Vitreous dimensions for the active patient.

The top, left side of the screen displays the active patient waveform. Within the waveform display are time gates and amplitude threshold to control the capture and measurement of the waveforms.

Below the waveform is a scale in millimeters (mm) that displays the location of detected echoes within the eye. Located to the immediate right of the current waveform is the current eye indicator, OD or OS, and its associated eye type. Below the eye type is the current waveform's live Axial Length, ACD, Lens Thickness, and Vitreous dimensions. These dimensions will change as you acquire data or change waveform parameters.

The bottom left corner displays the Patient name and ID. The bottom right corner displays the measurements for the currently selected eye of the patient.

### **Soft Menu Selections**

The Measure Screen displays one of two soft menus at the bottom of the screen, the Main menu and the Waveform Control menu.

The Waveform Control menu is displayed when the waveform is actively selected, otherwise the main menu is displayed.

The Measure Screen Main Menu has the following soft menu selections located at the bottom of the screen:

- Running/Frozen - toggles between the live and frozen captured waveform
- Auto ( \_ \_ )/Manual - toggles between the automatic and manual mode of capturing patient waveforms
- Contact/Immersion - toggles between the contact and immersion methods of coupling the probe
- OD/OS - toggles between the OD and OS eye; selecting OD or OS displays the waveforms for that eye. OD/OS must be set accordingly before capturing waveforms.

- Start New Patient - clears the current patient information and measurements and resets gain, gate, and ID to default values.
- Customize Eye Type... - displays the Customize Eye Type screen where you can customize the eye type for the current patient or review the current eye type definition. Custom Eye Types are associated with the current patient only and are not available to other patients. Permanent changes to eye types can be made on the Eye Types Screen.

### **Starting a New Patient**

You can start a new patient from either the Measure Screen, Calculate IOL Screen, or from the Patient Records Screen. Once you start a new patient, the Accutome A-Scan Plus will clear all previous patient information and set gain, gate and ID to the default values.

After starting a new patient, select the eye to be measured, OD or OS, and verify the eye type for that eye.

### **How to Set the Eye Type**

When the Accutome A-Scan Plus is set up at the factory, it is equipped with predefined eye types and specific velocities for the predefined eye types. Descriptions of the factory installed eye types and their characteristics are given below, followed by instructions on modifying eye types on a per patient basis.

### **Eye Types**

The following eye types are preset at the factory:

- Phakic - Setting for most patients.
- Silicone Filled - Phakic eye with Silicone Oil in the Vitreous.
- Dense Cataract - Use this setting when a dense cataract prevents measurement of lens thickness.
- Aphakic - Patient with no lens, lens is not measured or assumed.
- Pseudo PMMA - Patient with Pseudophakic PMMA IOL
- Pseudo Silicone - Patient with Pseudophakic Silicone IOL
- Pseudo Acrylic - Patient with Pseudophakic Acrylic IOL

Note:

*All eye types, including Aphakic, have an assumed cornea of 0.55 mm at a velocity of 1641 m/sec. This assumption is included in the ACD measurement.*

### Eye Type Materials and Velocities

The tables below list the preset eye types and define the materials and velocities for each eye type.

**Table 6-1 Eye Types**

Eye Type Name	Lens	Thickness	AC	VC
Phakic	Phakic	Measured	Aqueous	Vitreous
Silicone Filled	Phakic	Measured	Aqueous	Silicone Oil
Dense Cataract	Phakic	4.70	Aqueous	Vitreous
Pseudo PMMA	PMMA	0.70	Aqueous	Vitreous
Pseudo Silicone	Silicone	1.40	Aqueous	Vitreous
Pseudo Acrylic	Acrylic	0.70	Aqueous	Vitreous
Aphakic	(none)	(none)	1532	

**Table 6-2 Lens Materials and Velocities**

Material	Velocity (m/s)
Phakic	1641
PMMA	2660
Silicone	980
Acrylic	2120

**Table 6-3 Anterior/Vitreous Materials and Velocities**

Material	Velocity (m/s)
Aqueous	1532
Vitreous	1532
Silicone	980

### Setting the Eye Type

The patient’s OD or OS eye type may not match the default provided by the Accutome A-Scan Plus default preferences.

To set the eye type:

1. Within the Measurement Screen, rotate the knob to select the eye type located at the top right side of the screen. Selection is indicated by a solid black border. (See Figure 6-2 below.)

**Tip:**

You can use CTRL+E to select the next eye type directly from the keyboard. You can use CTRL+SHIFT+E to select the previous eye type directly from the keyboard.




Figure 6-2 Eye Type Selected

- Press the knob or the  $\checkmark$  button, to activate the field, indicated by the dashed border. (See Figure 6-3 below.).




Figure 6-3 Eye Type Active

- Within the eye type field, rotate the knob to scroll through the list of eye types. Select the appropriate eye type. Press the knob or the  $\checkmark$  button to save the new eye type as shown in figure 6-4.




Figure 6-4 Eye Type Changed

### Probe Application Methods

The Accutome A-Scan Plus supports two different methods of applying the probe to the cornea, contact and immersion.

Select the method you will be using by pressing the Contact/Immersion soft menu button.

#### Immersion

The Accutome A-Scan Plus makes it easy to use the Immersion method. The immersion method yields improved accuracy by allowing direct detection of the corneal echo and eliminating compression of the ACD associated with the contact method.

The immersion probe application method is used in conjunction with an immersion shell or Hansen shell with fluid. While using the immersion method, the probe should be placed at or behind the scored line on the shell. Placing it closer to the eye could negatively impact the measurement.

**Contact**

The Contact method allows you to apply the probe directly to the anesthetized cornea.

**CAUTION:** When using the contact method, care should be taken to minimize corneal compression. Corneal compression will result in a shorter axial length measurement and will affect IOL calculations.

**Capture Modes**

The Accutome A-Scan Plus provides two methods of capturing measurements; Automatic, or 'Auto', and Manual. The Automatic mode allows the instrument to determine, based upon user established criteria, when a measurement is captured. The Manual mode allows the user to determine when a measurement is captured.

**Auto Mode**

When you are using the Auto mode, the Accutome A-Scan Plus uses the definition of automatic measurement that has been set up in the unit's preferences.

The user is allowed to define the Automatic measurement mode by specifying how a measurement is automatically captured. There are a total of three criteria available and each can be turned off or on by the user on the Setup screen. The criteria are:

- Sclera - automatic capture determined by sclera detection
- Retina - automatic capture determined by retina detection
- Stable - automatic capture determined by measurement stability

The Auto Mode setting is displayed in the soft menu on the Measure Screen as 'Auto (SRS)', where (SRS) means Sclera, Retina, Stable. If the feature is ON, the first letter appears in its place, otherwise a placeholder '\_' is displayed.

The default is 'Sclera', displayed as 'Auto (S\_)'. Sclera must have a distinct sclera echo after the retina, above the threshold. Between the Retina and Sclera the signal must go below the threshold.



'Retina', displayed as 'Auto (\_R\_)', must begin at the base line, have no data greater than 10% of the threshold in front of it (for 1.5 mm), and be steeply rising.

"Stable", displayed as 'Auto (\_S)', means the measurement needs to be within a tolerance for a certain amount of time.

Note:

*For more information on setting the Auto mode refer to the "How to Set the Auto Mode" section of this manual.*

Another aspect of the Auto Mode that is established in the Accutome A-Scan Plus setup is the Restart feature. If 'Restart' is set to 'ON' and less than five measurements have been taken, the Auto mode restarts measurement after automatic capture. The Restart setting is available on the Setup screen, by pressing the Preferences button and then the More Settings... soft menu selection, or by pressing the Preferences button twice.

Note:

*For more information on setting the Auto mode refer to the "Restart On/Restart Off" section of this manual.*

### **Manual Mode**

Using the manual mode of capture you determine when a waveform is good and capture it manually using the footswitch.

## **How to Capture a Waveform**

You can "freeze" or, capture, the waveform with the optional footswitch or by pressing the button beneath the Run/Frozen selection on the front panel, or by pressing the Measure button at the top right corner.

### **Using the Footswitch**

When you want to capture a waveform simply press on the footswitch. The Accutome A-Scan Plus will switch from "Running" to "Frozen".

### **Using the Running/Frozen Button**

When you want to capture a waveform press the button beneath the Running/Frozen selection. The Accutome A-Scan Plus will switch from Running to Frozen.

### **Using the Measure Button**

When you want to capture a waveform, press the Measure button at the top right corner. The Accutome A-Scan Plus will switch from Running to Frozen.

### **How to Select a Measurement**

After you have taken measurements you may want to go back and review one of the captured waveforms. There are two ways to select a previous measurement; using the knob and button, or by using the footswitch.

#### **Selecting a Measurement with the Knob**

To select a measurement using the knob:

1. Within the Measurement Screen, rotate the knob to select the measurements table located at the bottom right corner of the screen. Selection is indicated by a solid black border.
2. Press the knob or the  $\sqrt{\quad}$  button, to activate the table, indicated by the dashed border.
3. Within the measurements table, rotate the knob to scroll through the list of measurements. You can also just press the number (1 - 5) of the measurement on the keyboard. The measurement outlined with white text against a black background is the active measurement as shown in figure 6-5.





Figure 6-5 Measurement Selected

### Selecting a Measurement Using Waveform Review Menu

The Waveform Review Menu will be displayed at the bottom of the Measure Screen when the waveform area is active.

To select a measurement using the Waveform Review Menu:

1. Within the Measurement Screen, rotate the knob to select the waveform area. Selection is indicated by a solid black border.
2. Press the knob or the  $\sqrt{\quad}$  button, to activate the waveform area, indicated by the dashed border. (See Figure 6-6 on next page.) The soft menu selections on the Measure Screen will change from the Main menu to the Waveform Review Menu.



*Figure 6-6 Measurement Activated with Waveform Review Menu*

- Press the button beneath the “View” selection. The measurement outlined with white text against a black background in the Measurement Table is the active measurement. The View button will scroll through all the measurements in the Measurement Table.

**Tip:**

You can use V to scroll through the measurements directly from the keyboard.

**Selecting a Measurement with the Footswitch**

If you are in a screen, other than the Measure Screen, pressing the footswitch will bring you to the Measure Screen. In the Measure Screen the footswitch allows you to capture, select, or delete a waveform.

To select a measurement with the footswitch:

1. Within the Measure Screen, press and release the footswitch to select a measurement. The footswitch will scroll through the table of measurements each time you press it. Scrolling proceeds from top to bottom and then back to the top of the table again.

## How to Delete a Measurement

You may want to delete one of the captured patient measurements. You can delete a measurement with the “X” button, the keyboard delete key or by using the footswitch.

### Deleting a Measurement with X Button or Keyboard

To delete a selected waveform press on the “X” button or the delete key on the keyboard when the waveform or measurement table is selected.

### Deleting a Measurement with the Footswitch

You can also press on the footswitch to delete the active measurement and start a new measurement. With the measurement you would like to delete selected, press on the footswitch and hold for approximately one second. The line in the measurement table will clear and you can recapture the waveform.

#### Tip:

You can use DELETE on the keyboard to delete the active measurement.

## How to Adjust Gates/Threshold

The Accutome A-Scan Plus takes measurements by sending a signal through the eye via the ultrasonic probe. The various parts of the eye have different velocities. The signal passes through each part of the eye at different speeds depending upon the acoustic velocity of the eyes' components. (If there is already an IOL in the eye, the signal will travel at a different speed than it would through a natural lens.)

Each time the signal encounters a change in velocity, due to the difference in material, the signal echoes off that part of the eye and is transmitted through the probe as a vertical spike in waveform. The vertical spikes in the waveforms are events, or the point in time when the signal encountered the different material. The Accutome A-Scan Plus measures the distances between these spikes and calculates the AXL value by summing all pieces of the waveform.

The events the Accutome A-Scan Plus seeks when scanning are:

- Cornea
- Anterior Lens (if eye is not Aphakic)
- Posterior Lens (if lens thickness is measurable)
- Retina

There is also unnecessary information captured in a waveform. There is a threshold for echoes to meet to be included as part of the measurement.

Accuracy depends upon the location of the gates and threshold along the waveform. The purpose of the gates/threshold is to delimit events. The gates/threshold tell the Accutome A-Scan Plus when to start looking for the different events in the waveform. Events will be detected to the right of the gate and above the threshold. The location of detected events are displayed in the scale below the waveform as indicated by solid black triangles.

If an event is not detected or is associated with an anomalous echo, the user must reposition the gates/threshold to properly measure the waveform.

The process of adjusting gates/threshold consists of:

- Selecting the gates/threshold
- Repositioning the gate location

#### **Available Gates/Threshold**

A gate delimits an event, such as the detection of the cornea. There are four vertical gates and one horizontal threshold along the horizontal and vertical axis of the waveform. The gates/threshold are as follows:

- Cornea Gate
- Anterior Lens Gate (visible if the eye type is not Aphakic)
- Posterior Lens Gate (visible if lens thickness is measurable)
- Retina Gate
- Threshold

The event being measured should be located to the right of the gate and above the threshold. You can reposition the gates/threshold if the events, gates and threshold do not align properly.

### Selecting Gates/Threshold

All gates/threshold are visible in the current waveform. Each gate should be situated to the left of the event it is indicating.

To select a gate:

1. Within the Measure Screen, rotate the knob to select the current waveform area, indicated by a solid black border as shown in figure 6-7.





Figure 6-7 Current Measurement Waveform Selected

2. Press the knob or the  $\sqrt{\quad}$  button, to activate the current waveform area, indicated by the dashed border as shown in figure 6-8.
3. When the current waveform is active, the Accutome A-Scan Plus will display a new soft menu at the bottom of the Measure screen.

## Waveform Review Menu

The Waveform Review menu has selections for adjusting gates/threshold, gain, zoom, scrolling, selecting a waveform and for exiting the menu.

To select an item from the menu for adjustment, press the button beneath the selection and then rotate the knob to make the adjustment.



*Figure 6-8 Waveform Review Menu Activated*

### How to Adjust the Cornea Gate

The cornea gate should be located **before** the start of the cornea echo. The active gate is displayed with dashed line while gates/threshold are indicated by dotted lines.

To adjust the cornea gate:


1. Press the button beneath the Gate selections until the "Gate Cornea" is displayed as shown in figure 6-8.



**Tip:**

You can use C to select the Cornea Gate directly from the keyboard, or hold to select cornea gates for all measurements.

2. Rotate the knob to move the cornea gate close to the cornea echo.
3. When the gate is in the proper position, either press the button beneath the gate selections to select another gate for adjustment or press the button beneath “Done”, the knob or the  $\sqrt{\phantom{x}}$  button to deactivate the menu.



*Figure 6-9 Cornea Gate Selected*

**How to Adjust the Anterior Lens Gate**

The anterior lens gate should be located before the start of the first lens echo.

**Note:**

You can use A to select the Anterior Lens Gate directly from the keyboard, or hold to select Anterior lens gates for all measurements.

To adjust the anterior lens gate:

1. Press the button beneath the Gate selections until the “Gate Ant Lens” is visible.

**Tip:**

You can use A to select the Anterior Lens Gate directly from the keyboard, or hold to select Anterior lens gates for all measurements.

2. Rotate the knob to move the posterior lens gate before the last lens echo.
3. When the gate is in the proper position, either press the button beneath the gate selections to select another gate for adjustment or press the button beneath “Done”, the knob or the  $\sqrt{\quad}$  button to deactivate the menu.




Figure 6-10 Anterior Lens Gate Selected

**How to Adjust the Posterior Lens Gate**

The posterior lens gate should be located before the start of the last lens echo.

Note:

*The Posterior Lens Gate is visible only if the eye type requires the lens thickness to be Measured and not assumed.*


To adjust the posterior lens gate:

1. Press the button beneath the Gate selections until the “Gate Post Lens” is visible.

**Tip:**

You can use P to select the Posterior Lens Gate directly from the keyboard, or hold to select posterior lens gates for all measurements.

2. Rotate the knob to move the posterior lens gate before the last lens echo.
3. When the gate is in the proper position, either press the button beneath the gate selections to select another gate for adjustment or press the button beneath “Done”, the knob or the  $\sqrt{\quad}$  button to deactivate the menu.



**Figure 6-11** Posterior Lens Gate Selected

### How to Adjust the Retina Gate

The retina gate should be located before the start of the retina echo.

To adjust the retina gate:

1. Press the button beneath the Gate selections until the “Gate Retina” is visible.

#### Tip:

You can use R to select the Retina Gate directly from the keyboard, or hold to select retina gates for all measurements.

2. Rotate the knob to move the retina gate before the start of the retina echo.
3. When the gate is in the proper position, either press the button beneath the gate selections to select another gate for adjustment or press the button beneath “Done”, the knob or the  $\sqrt{\quad}$  button to deactivate the menu.




Figure 6-12 Retina Gate Selected

The threshold gate should be located at the minimum echo height or amplitude.


To adjust the threshold gate:

1. Press the button beneath the Gate selections until the “Gate Threshold” is visible.

**Tip:**

You can use T to select the Threshold Gate directly from the keyboard, or hold to select threshold gates for all measurements.

2. Rotate the knob to move the threshold below the minimum height of the echo.
3. When the gate is in the proper position, either press the button beneath the gate selections to select another gate for adjustment or press the button beneath "Done", the knob or the  $\sqrt{\quad}$  button to deactivate the menu.



*Figure 6-13 Threshold Gate Selected*

### How to Apply Gate Adjustments to All Waveforms

You may want to apply a gate adjustment to all current eye waveforms.

To apply a gate adjustment:

1. Press and hold the button beneath the Gate selections for approximately one second. The text on the Gate menu selection will then read "Gate (All)..." for whichever gate is selected. For example, you just completed selecting the anterior lens gate and you hold the Gate menu button; the selection will then read "Gate (All) Ant Lens Gate".

2. Move the gate to the desired location. The gate is moved in all waveforms for the current eye. For each movement, each waveform is re-evaluated and new measurements are updated in the measurement table.

### How to Adjust the Gain

The Gain parameter on the Measure Screen allows you to adjust the gain of the signal received from the ultrasonic probe that is displayed as the waveform. The waveform must be selected and active to display the waveform review to adjust the gain:

1. Press the button beneath the “Gain” selection.




Figure 6-14 Gain Selected

2. Rotate the knob to select one of the pre-entered gain values.

Note:

*To return the gain to the new patient default value, press and hold the gain button for approximately 2 second.*

**Tip:**

You can use G to increase the gain 1dB directly from the keyboard, or hold to set the gain to the default.




Figure 6-15 Gain Field Changed




**How to Use Zoom**

The zoom feature allows you to zoom in on a selected waveform. The height of the waveform remains the same, only the width changes. Zoom expands the distance scale. The waveform must be selected and active to display the waveform Review menu. Zoom can be useful if you are having difficulty detecting all the events in a reading, or if you are scanning an abnormal eye type. Zoom has eight preset values of multiplication; 8.0, 4.0, 2.7, 2.0, 1.6, 1.3, 1.1, and 1.0. Zoom value of 1.6 is typical setting.

To use the Zoom feature:

1. Press the button beneath the “Zoom” selection.




*Figure 6-16 Zoom Selected*

2. Rotate the knob to select one of the preset zoom values.

**Tip:**

You can use CTRL+Z to increase the zoom with wrap directly from the keyboard, or hold to set the zoom to the default 1.6X.



*Figure 6-17 Zoom Changed*

## How to Scroll

The Scroll feature moves the active waveform from left to right and from right to left. Scroll allows you to view the horizontal dimension of a waveform. This feature can be useful if you are zooming in on a certain area of the measurement and you would like to look at another area of the waveform.

To scroll an image:

1. Press the button beneath the "Scroll" selection.




Figure 6-18 Scroll Selected

2. Rotate the knob to move the waveform.


**Tip:**

You can use CTRL+ S to scroll the waveform increasing 1mm directly from the keyboard, or hold to set the scroll to 0.

3. When the waveform is in the correct position, either press another waveform menu selection or press the button beneath “Done”, the knob or the √ button to deactivate the menu.

**Note:**

To scroll to the start of the waveform, press and hold the scroll button for approximately 1 second.



*Figure 6-19 Measurement Scrolling Changed*

## Switching Eyes

It is very simple to switch between eyes using the Accutome A-Scan Plus. To switch from OD to OS, or from OS to OD press the button beneath the selection OD/OS. The waveforms and eye type for the selected eye will be displayed.

### Tip:

You can use O or CTRL+O to switch between OD and OS.

## Customize Eye Type

You can also customize a Patient's eye type on the fly. The soft menu selection "Customize Eye Type..." launches the Customize Eye Type Screen where customizing on a per patient basis occurs.

Refer to section "Customizing Eye Types" for customizing eyes.

# 7

## Customizing Eye Types

### Overview

The Accutome A-Scan Plus not only allows you to create and store custom eye types, you can also customize eye types on-the-fly for an individual patient.

### Patient Customization

If you have a patient with a unique situation, you can specify the eye type, materials, and velocities for either the OD or OS while performing live measurements. A Custom Eye Type is linked to a patient eye, and is not a machine setting available for other patients.

All on-the-fly customization is performed at the Customize Eye Type Screen. Customization features include:

- Creating a new OD/OS eye type
- Changing/creating AC material and velocity for new eye type
- Changing/creating Lens material and velocity for new eye type
- Changing/creating Vitreous material and velocity for new eye type

### Note:

*An eye type is considered 'custom' if its definition, as displayed on the Customize Eye Type Screen, does not match an eye type definition displayed in the Eye Types Screen. This will occur if you customize the eye type directly. An eye type will be displayed as custom if its definition is permanently changed on the Eye Types screen and the current patient's eye type no longer matches. If you change the Eye Type definition on the Eye Type screen, and you wish to use that definition for the current patient, reselect the eye type from the Measure Screen. An eye type that is considered custom will have a \* beside its name on all patient data screens.*

## **Customize Eye Type Screen**

The Accutome A-Scan Plus provides access to the Customize Eye Type screen through the Measure screen. When you power on the instrument it starts up at the Measure screen. When you press the button beneath the selection “Customize Eye Type” the Customize Eye Type screen will be displayed.

In the Customize Eye Type screen you can create and define new eye types or review the current eye type definition. You can select pre-entered selections in each field, or you can create your own.

### **Customize Fields and Menu Selections**

The Customize Eye Type screen displays the following fields.

#### **OD**

The OD eye type name.

#### **OS**

The OS eye type name.

### **Eye Type Table**

Located to the right of each eye type name is a table with fields defining the material and velocity for AC, Lens, and VC. You can change all the fields that are white. You cannot change any field that is filled grey.

#### **AC**

The AC (Anterior Chamber) material name and velocity.

#### **Lens**

The Lens material name and velocity and thickness setting. Thickness can be measured or assumed. Press the Delete key to change the Lens Thickness field from assumed to measured.

#### **VC**

The VC (Vitreous Cavity) name material and velocity

The Customize Eye Type screen also has the following soft menu selections activated by the buttons beneath the selection:

- Edit Text - allows you to enter your own field names; you don't have to select pre-entered values.
- Done... - exits the Customize Eye Type Screen and returns you to the Measure Screen.

Note:

*If there is an \* (asterisk) to the right of any field in the Customize Eye Type Screen, it indicates that a value has been changed and that it is non-standard, or, custom.*

## How to Customize an Eye Type

1. In the Measure Screen, press the button beneath the selection
2. "Customize Eye Type...". The Customize Eye Type screen as shown in Figure 7-1 below will be displayed.

The screenshot shows the 'Customize Eye Type' screen with two sections for 'OD' and 'OS'. Each section contains a table with columns for Material, Velocity, and Lens Thickness. The 'Phakic' lens thickness is marked as 'Measured'.

Material	Velocity	Lens Thickness
AC Aqueous	1532	
Lens Phakic	1641	Measured
VC Vitreous	1532	


Material	Velocity	Lens Thickness
AC Aqueous	1532	
Lens Phakic	1641	Measured
VC Vitreous	1532	

[All eye types include an assumed cornea] [custom]

Edit Text Done...

*Figure 7-1 Customize Eye Type Screen*

2. Within the Custom Eye Type Screen, rotate the knob to select the Material/Velocity table, indicated by a solid black border. There are two material/velocity tables on the screen. You should select the one to the right of the patient's eye that you are customizing.



**Figure 7-2 OS Materials Table Selected**

3. Press the knob or the  $\sqrt{\quad}$  button, to activate the table, indicated by the dashed border.
4. Within the Material/Velocity table, rotate the knob to select the table cell you would like to change. In the example given in Figure 7-3 on the next page the cell selected is the VC Material cell.








Figure 7-3 OS Materials Table Activated

- 5. Within the VC Material cell, rotate the knob to select one of the pre-entered materials as shown in Figure 7-4 on the next page.
- 6. You can also press the button beneath the selection “Edit Text” and enter the material name; the material doesn’t have to be pre-entered.




**Figure 7-4 Changing VC Material**

7. Press the knob or the  $\checkmark$  button, to save the selected VC Material and to deactivate the field. Notice that the eye type name in Figure 7-5 on the next page is now followed by an \* indicating that is a custom eye type.



**Figure 7-5 VC Material Cell Changed**

8. Within the OS Material/Velocity table, rotate the knob to select the VC Velocity cell. The velocity may need to be changed to correlate to the change in material.
9. Within the VC Velocity cell, rotate the knob to adjust the velocity.
10. You can also press the button beneath the selection “Edit Text” and enter the material name; the material doesn’t have to be pre-entered.



**Figure 7-6 Changing Velocity Field**

11. All the custom changes to the Patient Eye Type will be followed by an asterisk (\*), as shown in Figure 7-7 on the next page.
12. Adjust any other eye type fields following the same procedures.
13. When you have completed customizing the patient eye, press the button beneath the selection "Done..." to deactivate the Custom Eye Type Screen. You will return to the Measure Screen and the new eye type information will be displayed for the patient.




Figure 7-7 OS Eye Type Customized

# 8

## Performing Calculations

### **Overview**

Performing IOL calculations with the Accutome A-Scan Plus can be as simple as pressing the Calculate button. There are numerous features available to enhance the calculation process.

The Accutome A-Scan Plus instantly calculates emmetropic and targeted ametropic IOL powers for dozens of lenses, viewed three at a time, using the axial length from the average of valid waveforms, a single waveform, or manually entered AXL.

### **Calculating the Lens**

The IOL calculation provides the required power of IOLs using a measured or entered axial length, entered K1 and K2 values, and entered desired post operative refraction.

All calculations are made on the Calculate IOL Screen. To access the Calculate IOL Screen, press the Calculate button, located on the right side of the instrument.

### **Calculation after Corneal Refractive Surgery**

The A-Scan also has the advanced capability to calculate IOLs for patients that have had corneal refractive surgery.

For patients who have had corneal surgery, the characteristics and power of the cornea have been altered.

Calculations for post surgery patients are made using the Double K method, which uses both the pre and post corneal refractive surgery K values.



*Figure 8-1 Calculate Button*

### Calculate IOL Screen

The Calculate IOL Screen shown in Figure 8-2 below displays the average of the five measurements for the selected eye (if there are five measurements available), the calculation for the currently selected formula and the three lenses of the current IOL Group.

The Accutome A-Scan Plus allows the user to fine tune the calculation by providing the ability to change the AXL value, the lens, formula and desired postoperative result refraction (the target).

The process for calculating the power of a lens is to select or enter an AXL value, select an IOL Group, select a formula, and enter the K1, K2 and Target values.

Note:

*The Rx Surg (Post Refractive Corneal Surgery) field should be left at "No". Change the field to "Yes" to calculate IOLs for patients that have had corneal refractive surgery. Refer to the "Calculating IOL Power After Corneal Refractive Surgery" section of this manual for instructions on changing the Rx Surg field.*

Target Refraction							Calculate IOL		
Group	William Smith						OD		
IOL	SN60WF	MA60AC	MTAU40				Phakic		
Hof Q	5.37	5.20	3.39				Rx Surg No		
Hof	1.620	1.450	-0.306				AXL		
SRK/T	5.40	5.21	3.28				K1		
Haig	1.714	0.400	0.100	1.627	0.400	0.100	-0.416	0.400	0.100
	Power	Refr	Power	Refr	Power	Refr	K2		
							Target		
							0.00 D		
Target							Emme		
Formula	<input type="radio"/> Hoffer Q <input checked="" type="radio"/> Holladay <input type="radio"/> SRK/T <input type="radio"/> Haigis						AXL		
							1		
							2		
							3		
							4		
							5		
Patient	macqueen, john						Avg 0.00		
ID	sn10G4222						Dev 0.00		
Select IOL Group	Select Formula	Compare ON	Compare OFF	OD	OS	Start New Patient	IOL Groups...		

Figure 8-2 Calculation Fields



### Selecting an IOL Group

You may want to select lenses from a different group. To access one of the available IOL groups, press the button beneath the “Select IOL Group” selection. You can then scroll through the list of IOL Groups. Stop when you have reached the correct group. (Refer to the “How to Set Up an IOL Group” section of this manual for further information.)

### Selecting a Formula

You may want to change the formula used to calculate the IOL. To scroll through the list of available formulas, press the button beneath “Select Formula” selection. The IOL constant used by the currently selected formula is highlighted as white text on black background for each IOL.

### Entering an ACD Value with the Haigis Formula

The Haigis formula uses the measured ACD or calculated ACD value, as well as the axial length (AXL). The ACD is shown in the measurement history list, and an ACD field is added where the user can specify a calculated or manually entered ACD. ACD should be calculated for Aphakic and Pseudophakic eye types. The other formulas do not use the measured ACD field in any way and the field is only shown when Haigis is selected or the formula compare mode is on.

Specify the ACD value by allowing the Accutome A-Scan Plus to calculate (Calc) the value or manually enter the value.

To manually enter the ACD value:

1. Rotate the knob to select the ACD field and press the knob or the  $\sqrt{\quad}$  button to activate the field. When the field is active, either rotate the knob, if necessary, to select “Calc” for a calculated value, or manually enter the ACD value in millimeters (mm).
2. If you would like the A-Scan to calculate the ACD press the “Delete” key or the X button to remove the entered value and replace it with “Calc” for a calculated value.

Note:

*The ACD field is only active if you are using the Haigis formula. If you have selected another calculation formula, the field will not appear.*

*Entered ACD should be a phakic ACD measurement. The ACD can be estimated by entering "0".*

### **Changing the AXL Value**

The Accutome A-Scan Plus allows the user to fine tune the calculation by providing the ability to change the AXL value. You can select the AXL from any of the five measurements, the average of the measurements, or you can enter your own axial length.

### **Selecting a Measurement**

You may want to select a particular measurement with which to perform the calculation.

To select one of the available measurements:

1. Within the Calculate IOL Screen, rotate the knob to select the "AXL" list, located in the bottom right corner of the screen. Selection is indicated by a solid black border.
2. Press the knob or the  $\sqrt{\quad}$  button, to activate the list, indicated by the dashed border.
3. Within the AXL list, rotate the knob to select one of the AXL measurement values or the average.
4. Press the knob or the  $\sqrt{\quad}$  button, to save the selected AXL value and to deactivate the field.

**Entering an AXL Value**

You may not be satisfied with the average measurement of any of the five acquired measurements, or you may want to enter the axial length from a previous measurement. The Accutome A-Scan Plus allows you to manually enter an AXL value.

To enter an AXL value:

1. Within the Calculate IOL Screen, rotate the knob to select the “AXL” field, located in the top right side of the screen. Selection is indicated by a solid black border.
2. Press the knob or the  $\sqrt{\quad}$  button, to activate the field, indicated by the dashed border.
3. Within the AXL field, enter the new AXL value.
4. Press the knob or the  $\sqrt{\quad}$  button, to save the entered AXL value and to deactivate the field.
5. The A-Scan will indicate that the AXL value is entered with the text “[entered]” below the AXL field.

**Entering the K1, K2 Values**

The keratometer index of refraction, used to convert corneal radius to diopter power is not the same for all keratometers. In North America, most units have an index of refraction of 1.3375. European keratometers may have an index of refraction of 1.3315. The factory default is 1.3375.

The K Index value is only used when entering keratometer readings in diopters. K readings can be entered on the Calculate IOL screen as well as the Personalize IOL screen. The K index associated with diopter entries is not explicitly shown. When a keratometer reading is entered in diopters the default K index is copied from the setup screen. If the K index of an entry is different than the Setup screen default K Index, a \* appears beside the entry. To change or view the K index, change or reenter the diopter entry. The Accutome A-Scan Plus will prompt you with the default and current K indexes and ask which one you want associated with the entry.

Keratometer data can be entered in mm as well as diopters. The ranges for these two units are mutually exclusive. Values less than 20 are assumed to be mm. Values 20 or greater are assumed to be diopters. Units are displayed with all entries. Diopter entries have a keratometer index of refraction associated with them to allow for conversion to mm as needed by some of the formulas.

Enter the optical power of the cornea in diopters or mm, as measured on a keratometer or corneal topographer, as K1, K2.

To enter K1, K2 values:

1. Within the Calculate IOL Screen, rotate the knob to select the "K1" field, located in the middle right side of the screen. Selection is indicated by a solid black border.
2. Press the knob or the  $\sqrt{\quad}$  button, to activate the field, indicated by the dashed border.
3. Within the K1 field, enter the K1 value or rotate the knob until you arrive at the value.
4. Press the knob or the  $\sqrt{\quad}$  button, to save the entered K1 value and to deactivate

### Entering the K1, K2 Values

To enter the Target value:

1. Within the Calculate IOL Screen, rotate the knob to select the “Target” field, located in the middle right side of the screen. Selection is indicated by a solid black border.
2. Press the knob or the  $\sqrt{\quad}$  button, to activate the field, indicated by the dashed border.
3. Within the Target field, enter the target value or rotate the knob until you arrive at the value. The Target Value changes in 0.25 D steps. You can use the keyboard to enter a value within 0.01 D.
4. Press the knob or the  $\sqrt{\quad}$  button, to save the entered Target Value and to deactivate the field.

### Calculation Results

After all fields have been entered, the Calculate IOL Screen will display the power of the IOL, for each lens with bold, large, black numbers. These values are the optimal powers for the specified target refraction, and do not necessarily exist in the real world.

A list of five IOL powers and their expected refraction, in 0.5 D increments and centered on the result closest to the target power, is displayed for each IOL.

The Accutome A-Scan Plus also provides you with a lens value for a zero target (Emmetropic). The zero target values are listed below the optimal IOL powers in small numbers.

Measure List. ? Indicates data not measured										Calculate IOL			
Group William Smith										<b>OD</b> Phakic Rx Surg <input type="checkbox"/> No <b>AXL</b> <b>24.08</b> K1 44.50 D K2 44.25 D Target 0.00 D			
IOL SN60WF			MA60AC			MTAU40							
Hol Q 5.37			5.20			3.39							
Hol 1.620			1.450			-0.306							
SRK/T 5.40			5.21			3.28							
Haig 1.714 0.460 0.160			1.527 0.460 0.160			-0.416 0.460 0.160							
Power		Refr		Power		Refr		Power				Refr	
17.50		0.34		17.25		0.32		14.75				0.30	
17.75		0.18		17.50		0.16		15.00				0.11	
18.00		0.01		17.75		-0.01		15.25				-0.08	
18.25		-0.15		18.00		-0.18		15.50		-0.27			
18.50		-0.32		18.25		-0.35		15.75		-0.46			
Target 18.02			17.73			15.15							
Emme 18.02			17.73			15.15							
Formula <input type="checkbox"/> Hoffer Q										AXL 1 24.11 2 24.06 3 24.07 4 24.05 5 24.08 Avg 24.08 Dev 0.02			
<input checked="" type="checkbox"/> Holladay													
<input type="checkbox"/> SRK/T													
<input type="checkbox"/> Haigs													
Patient macqueen, john													
ID sn10G4222													
Select IOL Group	Select Formula	Compare ON		OD		Start New Patient		IOL Groups...					
		Compare OFF		OS									

Figure 8-3 Calculate IOL Screen - All Fields Entered

### Formula Compare Feature

The Formula Compare feature allows the comparison of all formulas for each calculation. When Compare is On, it displays the closest matching IOL power that will achieve the target refraction with the expected postoperative refraction as calculated by each formula.

To compare calculations for all formulas, press on the button beneath “Compare On/Compare Off”. This button toggles between the two and will display the calculations for one formula or all formulas as the button is toggled.

Target Refraction										Calculate IOL	
Group		William Smith								OD	
IOL	SN60WF		MAG0AC			MTAU40			Phakic		
Hof Q	5.37		5.20			3.39			Rx Surg <input type="checkbox"/> No		
Hof	1.620		1.450			-0.306			AXL		
SRK/T	5.40		5.21			3.28			24.08		
Haig	1.714	0.400	0.100	1.527	0.400	0.100	-0.410	0.400	0.100	ACD	4.39 mm
	Power	Refr	Power	Refr	Power	Refr					
Hof Q	17.75	-0.02	17.50	-0.04	14.75	0.05					
Hof	18.00	0.01	17.75	-0.01	15.25	-0.08					
SRK/T	18.25	-0.01	18.00	-0.05	15.00	0.06					
Haig	19.50	-0.01	19.25	-0.07	16.00	0.05					
							Target		0.00 D		
Formula		<input type="checkbox"/> Hoffer Q			<input type="checkbox"/> Holladay			AXL ACD			
		<input type="checkbox"/> SRK/T			<input type="checkbox"/> Haigis			1 24.11 4.43			
Patient		macqueen, john						2 24.06 4.33			
ID		sn10G4222						3 24.07 4.38			
								4 24.05 4.36			
								5 24.09 4.43			
								Avg 24.08 4.39			
								Dev 0.02 0.04			
Select IOL Group	Select Formula	Compare ON		Compare OFF		OD	OS	Start New Patient	IOL Groups...		

Figure 8-4 Compare On Selected

Switching Between OD/OS

To perform a calculation for the current Patient’s other eye, press on the button beneath “OD/OS”. This button toggles between the two eyes and will display the readings for either OD or OS as the button is switched.

## Calculating IOL Power After Corneal Refractive Surgery

The Accutome A-Scan Plus also provides the ability to calculate IOLs for patients who have had corneal refractive surgery.

Corneal refractive surgery alters the characteristics and power of the cornea.

Note:

*Calculating IOL powers for post refractive surgery patients is an evolving topic and requires research and careful planning on the part of the ophthalmologist. The methods and formulas presented by the Accutome A-Scan Plus for this type of patient should only be used by a qualified individual who has done due diligence to determine the best method, and how to execute that method, for each patient. If a more appropriate formula or method for determining the current corneal power is available, the result of this formula can be used by selecting the 'Entered' Kpost formula and entering the power manually.*

### Double K Method

All IOL formulas, except for the Haigis formula, use the K measurement in two ways: to know the power of the cornea, and to help estimate the position of the IOL.

The power of the cornea needs to be the current K of the patient (post refractive surgery). Estimating the position of the IOL should be based on the pre refractive surgery K of the patients. Using both the post and pre corneal refractive K is called the Double K Method.

When the Rx Surg field is set to Yes, indicating corneal refractive surgery, the Kpre and Kpost fields are displayed in the place of K1/K2. Both of these fields must have data for the formulas to calculate the IOL power.

When using the Haigis formula, the Kpre field is not shown. The Haigis formula does not use Kpre to determine the IOL position, the Haigis formula uses the measured ACD.



### **Determining Corneal Power after Refractive Surgery**

The K value (corneal power or corneal curvature) for patients that have had corneal refractive surgery cannot be determined using common methods. Four K Post formulas, or methods, are available in the Accutome A-Scan Plus to determine the current corneal power for refractive patients (Kpost).

Note:

*If you do not know the patients prerefractive surgery corneal power, you may want to consider using the Haigis formula which does not require this information.*

### **Post Rx Surg IOL Calculation Steps**

The steps to complete a post refractive surgery IOL Calculation are almost the same as non refractive surgery eye calculations with the addition of selecting a Post K method.

To complete a post refractive surgery calculation:

1. Set the Rx Surg field to “Yes”.
2. Select an IOL Group (see the “Selecting an IOL Group” section of this manual).
3. Select or enter an AXL value (see the “Changing the AXL Value” section of this manual).
4. Enter the applicable averaged K1 and K2 readings, Sphere, and Cylinder values.
5. Enter the target value (see the “Entering the Target Value” section of this manual).

The K Post calculation methods are:

1. Clinical History method - Calculates Kpost based on Kpre, refraction before and after refractive surgery.
2. Contact Lens method - Calculates Kpost based on refraction after refractive surgery with and without a hard contact lens of a known curve and power.
3. Shammass Clinical method - Calculates Kpost by adjusting on manual K reading after refractive surgery using simple formula  $K_{post} = 1.14 * K_{measured} - 6.8$
4. Entered - This allows the user to calculate the Kpost value in some other manner than listed above and then enter the value accordingly.

The Kpost calculation methods are listed in order of preference, with the Clinical History method widely accepted as the most accurate. The Clinical History method is the default for new patients.

For the refractions entered, the vertex of the refraction is stored and becomes the default for the next patient.

### Changing Rx Surg Field to Yes

Note:

*The only time the Rx Surg field should be changed to yes is for a patient that has had corneal refraction surgery.*

In Figure 8-5 below the Rx Surg field is selected. To activate the Rx Surg field and change the field:

1. Rotate the knob to select the Rx Surg field and press the knob or the  $\sqrt{\quad}$  button to activate the field. When the field is active either rotate the knob to change "No" to "Yes".
2. Press the knob or the  $\sqrt{\quad}$  button to activate the Post Surgery function.

Indicates eye has had refractive surgery

Group	William Smith						Calculate IOL		
IOL	SN60WF		MA60AC		MTAU40		OD		
Hof Q	5.37		5.20		3.39		Phakic		
Hof	1.620		1.450		-0.306		Rx Surg <input checked="" type="checkbox"/> No		
SRK/T	5.40		5.21		3.28		AXL		
Halg	1.714	0.400	0.100	1.527	0.400	0.100	24.08		
	Power	Refr	Power	Refr	Power	Refr	K1 42.00 D		
	21.75	-0.15	21.50	-0.21	18.50	-0.19	K2 40.94 D		
	22.00	-0.33	21.75	-0.38	18.75	-0.39	Target -0.50 D		
	22.25	-0.51	22.00	-0.57	19.00	-0.60			
	22.50	-0.68	22.25	-0.75	19.25	-0.80			
	22.75	-0.86	22.50	-0.93	19.50	-1.01			
Target	22.24		21.91		18.88				
Emme	21.53		21.21		18.26				
Formula	<input type="checkbox"/> Hoffer Q <input checked="" type="checkbox"/> Holladay <input type="checkbox"/> SRK/T <input type="checkbox"/> Halgis						AXL 1 24.11 2 24.06 3 24.07 4 24.05 5 24.09 Avg 24.08 Dev 0.02		
Patient	Chandler, Brian								
ID	sn10G4222								
Select IOL Group	Select Formula	Compare ON	Compare OFF	OD	OS	Start New Patient	IOL Groups...		

Figure 8-5 Post Rx Surgery Field (Rx Surg) Selected

When the Rx Surg field is set to Yes, the K1/K2 fields are replaced with Kpre and Kpost and the Kpost methods and associated fields appear in the middle, bottom of the screen. PLEASE NOTE: the Kpre field is an average of the measured K1 and K2 prior to corneal refractive surgery.

**Clinical History Method**

When using the Clinical History method, the default and preferred method, the Calculate IOL screen displays Kpre and Kpost fields and all fields associated with the Clinical History method.

**Clinical History Fields**

When using the Clinical History method for post refractive surgery IOL calculations, you must enter the value in the following fields:

- Kpre - the average K value before refractive surgery
  - Sphere and Cylinder before refractive surgery and the current refraction
1. Rotate the knob to select each field and press the knob or the  $\sqrt{\quad}$  button to activate the field. When the field is active, either rotate the knob to change the value or manually enter the value with the keyboard.

Post refractive surgery K calculation formula										Calculate IOL	
Group	William Smith									OD	
IOL	SN60WF			MA60AC			MTAU40			Phakic	
Hof Q	5.37			5.20			3.39			Rx Surg Yes	
Hof	1.620			1.450			-0.306			AXL	
SRK/T	5.40			5.21			3.28			24.08	
Halg	1.714	0.400	0.100	1.527	0.400	0.100	-0.410	0.400	0.100	Kpre 44.01 D	
	Power	Refr		Power	Refr		Power	Refr		Kpst 40.93 D	
	23.25	-0.19		22.75	-0.09		19.50	-0.04		Target -0.50 D	
	23.50	-0.37		23.00	-0.26		19.75	-0.24			
	23.75	-0.54		23.25	-0.44		20.00	-0.44			
	24.00	-0.72		23.50	-0.62		20.25	-0.64			
	24.25	-0.89		23.75	-0.80		20.50	-0.84			
Target	23.69			23.33			20.08				
Emme	22.97			22.62			19.45				
Formula	Hoffer Q			Kpost Clinical History						AXL	
	> Holladay									1 24.11	
	SRK/T									2 24.06	
	Halgis									3 24.07	
										4 24.05	
										5 24.09	
										Avg 24.08	
										Dev 0.02	
Patient	Chandler, Brian										
ID	sn10G4222										
Select IOL Group	Select Formula	Compare ON	Compare OFF	OD	OS	Start New Patient	IOL Groups...				

Figure 8-6 Post Rx Surgery Calculation Activated - Clinical History

**Contact Lens Method**

The Contact Lens method requires you to enter the following fields:

- Kpre-the average K value before refractive surgery
  - Current refraction in sphere and cylinder.
  - Refraction with contact lens on in sphere and cylinder.
  - Base Curve (of the contact lens)
  - Power (of the contact lens)
1. Rotate the knob to select each field and press the knob or the  $\sqrt{\quad}$  button to activate the field. When the field is active, either rotate the knob to change the value or manually enter the value with the keyboard.

Patient Identification										Calculate IOL	
Group	William Smith									<b>OD</b>	
IOL	SN60WF			MA60AC			MTAU40			Phakic	
Hof Q	5.37			5.20			3.39			Rx Surg <b>Yes</b>	
Hof	<b>1.620</b>			<b>1.450</b>			<b>-0.306</b>			<b>AXL</b>	
SRK/T	5.40			5.21			3.28			<b>24.08</b>	
Haig	1.714	0.400	0.100	1.627	0.400	0.100	-0.410	0.400	0.100	Kpre	44.01 D
	Power	Refr		Power	Refr		Power	Refr		Kpst	39.82 D
	24.75	-0.14		24.50	-0.22		21.00	-0.13		Target	-0.50 D
	25.00	-0.32		24.75	-0.40		21.25	-0.33			
	<b>25.25</b>	<b>-0.48</b>		<b>25.00</b>	<b>-0.58</b>		<b>21.50</b>	<b>-0.53</b>			
	25.50	-0.67		25.25	-0.76		21.75	-0.74			
	25.75	-0.85		25.50	-0.94		22.00	-0.94			
Target	<b>25.26</b>			<b>24.89</b>			<b>21.46</b>				
Emme	24.55			24.18			20.83				
Formula	Hoffer Q			Kpost			Contact Lens			AXL	
	> Holladay						Sph Cyl Vx			1 24.11	
	SRK/T						RxPost			2 24.06	
	Haigis						RxPostCL			3 24.07	
										4 24.05	
Patient	Chandler, Brian			Curve			35.00 D			5 24.09	
ID	sm10G4222			Power			0.00 D			<b>Avg 24.08</b>	
										Dev 0.02	
Select	Select	Compare ON		<b>OD</b>		Start New		IOL			
IOL Group	Formula	Compare OFF		OS		Patient		Groups...			

*Figure 8-7 Post Rx Surgery Calculation with Contact Lens Method*

**Shammas Clinical Method**

The Shammas Clinical method requires you to enter the following fields:

- Kpre-the average K value before refractive surgery
- K1 (measured)\*
- K2 (measured)\*

\*Measured - using a manual keratometer on the post refractive surgery cornea.

1. Rotate the knob to select each field and press the knob or the  $\sqrt{\quad}$  button to activate the field. When the field is active, either rotate the knob to change the value or manually enter the value with the keyboard.

Post refractive surgery K calculation formula										Calculate IOL	
Group	William Smith									OD	
IOL	SN60WF			MA60AC			MTAU40			Phakic Rx Surg Yes	
Hof Q	5.37			5.20			3.39			AXL	
Hof	1.920			1.450			-0.306			24.08	
SRK/T	5.40			5.21			3.28			Kpre 44.01 D	
Haig	1.714	0.460	0.100	1.527	0.400	0.100	-0.410	0.460	0.100	Kpst 40.48 D	
	Power	Refr		Power	Refr		Power	Refr		Target -0.50 D	
	23.75	-0.09		23.50	-0.17		20.25	-0.19			
	24.00	-0.27		23.75	-0.34		20.50	-0.38			
	24.25	-0.44		24.00	-0.52		20.75	-0.58			
	24.50	-0.62		24.25	-0.70		21.00	-0.79			
	24.75	-0.79		24.50	-0.88		21.25	-0.99			
Target	24.34			23.97			20.64				
Emme	23.62			23.26			20.02				
Formula	Hoffer Q			Kpost Shammas Clinical			AXL			1 24.11	
	Holladay			Measured						2 24.06	
	SRK/T			K1 42.00 D						3 24.07	
	Haigis			K2 40.94 D						4 24.05	
Patient	Chandler, Brian									5 24.09	
ID	sn10G4222									Avg 24.08	
										Dev 0.02	
Select IOL Group	Select Formula	Compare ON	Compare OFF	OD	OS	Start New Patient	IOL Groups...				

Figure 8-8 Post Rx Surgery Calculation with Shammas Clinical Method

**Calculation Results**

After all fields have been entered, the Calculate IOL Screen will display the power of the IOL, for each lens with bold, large, black numbers. These values are the optimal powers for the specified target refraction, and do not necessarily exist in the real world.

A list of five IOL powers and their expected refraction, in 0.5 D increments and centered on the result closest to the target power, is displayed for each IOL.

The Accutome A-Scan Plus also provides you with a lens value for a zero target (Emmetropic). The zero target values are listed below the optimal IOL powers in small numbers.

**Switching Between OD/OS**

To perform a calculation for the current Patient's other eye, press on the button beneath "OD/OS". This button toggles between the two eyes and will display the readings for either OD or OS as the button is switched.

# 9 Setting Up IOL Groups

## How are IOL Groups Used

IOLs can be grouped by type, manufacturer, physician, location, patient pathology, or other criteria. IOLs are organized in groups of three. Each group can be given a custom name to distinguish its purpose. Any IOL group can be selected directly from the Calculate IOL Screen for quick selection of the desired IOLs for the current patient. You can setup 15 IOL Groups, each with up to 3 IOLs, for a total system of 45 IOLs.

When you set up IOL groups you set them up in the IOL Groups Screen. The IOL Groups Screen is the only location within the Accutome A-Scan Plus for entering IOL information.

## How to Set Up an IOL Group

The process for setting up an IOL Group consists of:

- Entering an IOL Group Name
- Entering lens information associated with each group

All entry of IOL Groups takes place at the IOL Groups Screen. The IOL Groups screen is accessed from the Calculate IOL Screen.

To access the Calculate IOL Screen press the Calculate button, located at the right side of the instrument. The Calculate IOL Screen shown in Figure 9-1 on the next page will then be displayed.

## Accessing the IOL Groups Screen

In the Calculate IOL Screen:

1. Press the button beneath the selection "IOL Groups...". The IOL
2. Calculation Groups Screen will then be displayed.

IOL Group Name		IOL Calculation Groups						
<b>Group 1</b>		Hof Q	HoI	SRK/T	Haigis			
<input type="text" value="Dr. Williams"/>	ACD	SF	ACD	a0	a1	a2	A-Con	
<input type="text" value="Collamer"/>	6.06	2.214	6.06	2.370	0.400	0.100	119.75	
<input type="text" value="MA60AC"/>	5.21	1.450	5.21	1.527	0.400	0.100	118.40	
<input type="text" value="AC IOL"/>	3.28	-0.306	3.28	-0.410	0.400	0.100	115.30	
<b>Group 2</b>								
<input type="text" value="Dr. Mckenzie"/>								
<input type="text" value="MA60AC"/>	5.21	1.450	5.21	1.527	0.400	0.100	118.40	
<input type="text" value="SI 40"/>	4.78	1.059	4.78	1.096	0.400	0.100	117.71	
<input type="text" value="AC21B"/>	3.00	-0.555	3.00	-0.684	0.400	0.100	114.86	
<b>Group 3</b>								
<input type="text" value="Dr. Petersen"/>								
<input type="text" value="Sensor Acrylic"/>	5.20	1.439	5.20	1.514	0.400	0.100	118.38	
<input type="text" value="Chiron 88 TI"/>	4.96	1.223	4.96	1.277	0.400	0.100	118.00	
<input type="text" value="Iolab LI41U"/>	4.65	0.940	4.65	0.965	0.400	0.100	117.50	
<b>Group 4</b>								
<input type="text"/>								
<input type="text"/>								
<input type="text"/>								
<input type="text"/>								

Scroll Groups Down
Scroll Groups Up
Delete IOL
Personalize IOLs...
Done...

Figure 9-1 Select IOL Groups

### IOL Calculation Groups Screen

The IOL Groups Screen as shown in Figure 9-2 on the next page, displays a listing of all the IOL Groups and their associated lenses. The Accutome A-Scan Plus has a capacity to store 15 groups.

The left side of the screen displays a field for the group name. To the right of the group name field is the lens table for that group.

The screen can display four groups at a time. If you would like to view another of the possible 15 groups, press the button beneath the “Scroll Groups Down” or “Scroll Groups Up” selections.

The Delete IOL selection allows you to delete a selected IOL. The Personalize IOLs selection displays the Personalize IOL screen for personalizing the constants used with selected IOLs.



IOL Group Name		IOL Calculation Groups						
<b>Group 1</b>		Hof Q	Hol	SRK/T		Haigis		
<input type="text" value="Dr. Williams"/>	ACD	SF	ACD	a0	a1	a2	A-Con	
Collamer	6.06	2.214	6.06	2.370	0.400	0.100	118.75	
MA60AC	5.21	1.450	5.21	1.527	0.400	0.100	118.40	
AC IOL	3.28	-0.306	3.28	-0.410	0.400	0.100	115.30	
<b>Group 2</b>								
<input type="text" value="Dr. Mckenzie"/>								
MA60AC	5.21	1.450	5.21	1.527	0.400	0.100	118.40	
SI 40	4.78	1.059	4.78	1.096	0.400	0.100	117.71	
AC21B	3.00	-0.555	3.00	-0.684	0.400	0.100	114.86	
<b>Group 3</b>								
<input type="text" value="Dr. Petersen"/>								
Sensar Acrylic	5.20	1.439	5.20	1.514	0.400	0.100	118.38	
Chiron 88 TI	4.96	1.223	4.96	1.277	0.400	0.100	118.00	
ToIab LI41U	4.65	0.940	4.65	0.965	0.400	0.100	117.50	
<b>Group 4</b>								
<input type="text"/>								
<input type="text"/>								
<input type="text"/>								
<input type="text"/>								
Scroll Groups Down		Scroll Groups Up		Delete IOL	Personalize IOLs...	Done...		

Figure 9-2 IOL Groups Screen

**Entering IOL Group Names**

To enter an IOL Group Name:

1. In the IOL Groups screen, rotate the knob to select an empty Group field (selection is indicated by a solid black border). You can also press the buttons beneath the “Scroll Groups Up” and Scroll Groups Down” selections to locate an empty space.
2. Press the knob or the √ button, to activate the field, indicated by the dashed border.
3. Within the Group field enter the name of the Group for which you are entering lenses.
4. Press the knob or the √ button, to save the selected Group name and to deactivate the field.

Enter group name		IOL Calculation Groups						
Group 1	Hof Q	Ho1	SRK/T		Haig1s			
Gr.1	ACD	SF	ACD	a0	a1	a2	A-Con	
Group 2								
Group 3								
Group 4								

Scroll Groups Down    Scroll Groups Up    Delete IOL    Personalize IOLs...    Done...

**Figure 9-3 Entering the IOL Group Name**

### Entering the Group's Lenses

To enter an IOL Group's Lenses:

1. Select the lens table located to the right of the Group field (selection is indicated by a solid black border).
2. Press the knob to activate the table, indicated by the dashed border.
3. Within the lens table, rotate the knob and select the Description cell (selection is indicated by a solid black border).
4. Enter the description of the first lens you are entering.
5. Press the knob or the  $\checkmark$  button, to save the description and to deactivate the field.

Enter IOL description		IOL Calculation Groups						
Group 1	Hof Q	Ho1	SRK/T	Haigis			A-Con	
Dr. Williams	ACD	SF	ACD	a0	a1	a2		
Collamer								
Group 2								
Group 3								
Group 4								

Scroll Groups Down    Scroll Groups Up    Delete IOL    Personalize IOLs...    Done...

**Figure 9-4 Entering the IOL Description**

Note:

*This procedure uses the A-Constant as the IOL constant. You can enter the ACD or SF as the first constant entered also. When entering a lens constant, the three constants for the Hoffer, Holladay and SRK/T are calculated if they are all empty. At the same time, the Haigis constants a0, a1 and a2 are calculated. a1 is always 0.4, and a2 is always 0.1 unless specified by the user as a result of triple optimization. a0 is the IOL factor, a1 is the measured ACD factor, and a2 is the axial length factor for determining the post operative ACD of the IOL.*

*If you have more than one constant for your lens, such as an A-Constant and a personalized SF, enter the non personalized A-Constant first, then overwrite the calculated SF with your personalized SF. Personalized constants should only be used with the formula they were derived from.*

6. Within the lens table, rotate the knob and select the A-Con cell (selection is indicated by a solid black border).

A-constant		IOL Calculation Groups						
Group 1	Hof Q	Ho1	SRK/T		Haigis			
Dr. Williams	ACD	SF	ACD	a0	a1	a2	A-Con	
Collamer								
Group 2								
Group 3								
Group 4								

Scroll Groups Down    Scroll Groups Up    Delete IOL    Personalize IOLs...    Done...

**Figure 9-5** Selecting the A-Constant Field

7. Enter the A-Constant for the first lens you are entering.

A-constant		IOL Calculation Groups					
Group 1	Hof Q	Ho1	SRK/T	Haigis		A-Con	
Dr. Williams	ACD	SF	ACD	a0	a1	a2	A-Con
Collamer							119.75
Group 2							
Group 3							
Group 4							
Scroll Groups Down		Scroll Groups Up		Delete IOL	Personalize IOLs...		Done...

**Figure 9-6 Entering the IOL Constant**

8. Press the knob to save the value and to deactivate the field. The Accutome A-Scan Plus will then determine the corresponding IOL constant for each formula and automatically fill out the formula cells in the table.

A-constant		IOL Calculation Groups						
Group 1	Hof Q	Ho1	SRK/T	Haigis				
Dr. Williams	ACD	SF	ACD	a0	a1	a2	A-Con	
Collamer	6.06	2.214	6.06	2.370	0.400	0.100	119.75	
Group 2								
Group 3								
Group 4								
Scroll Groups Down		Scroll Groups Up		Delete IOL	Personalize IOLs...		Done...	

**Figure 9-7 First Lens Entered for Group 1**

9. Continue to enter all lens information for the IOL Group in the same manner. When you have completed the table, press the knob or the  $\sqrt{\quad}$  button once to save the last cell entered and then again to deactivate the table.
10. If you have completed entering all IOL Group information, press the button beneath the selection "Done..." to return to the Calculate IOL Screen.

IOL Calculation Group				IOL Calculation Groups			
Group 1	Hof Q	Ho l	SRK/T	Haigis			
Dr. Williams	ACD	SF	ACD	a0	a1	a2	A-Con
Collamer	6.06	2.214	6.06	2.370	0.400	0.100	119.75
MA60AC	4.97	1.229	4.97	1.283	0.400	0.100	118.40
AC IOL	3.28	-0.306	3.28	-0.410	0.400	0.100	115.30
Group 2							
Group 3							
Group 4							
Scroll	Scroll	Delete		Personalize		Done...	
Groups Down	Groups Up	IOL		IOLs...			

Figure 9-8 First IOL Group Complete

# 10 Personalizing Lens Constants

## Overview

One of the great features of the Accutome A-Scan Plus is the ability to personalize the lens constants used in calculating lens power. This ability to fine tune lens constants results in even greater success for patient outcomes.

Note:

*The Personalize IOLs screen does not allow the pasting of patient data for an eye that has Rx Surg set to Yes. If you attempt to personalize IOLS with post refractive surgery eyes, the following message is shown: “Refractive surgery eyes cannot be used.*

## Personalizing Lens Constants

IOL constant personalization is a method for removing consistent errors from the entire IOL implant procedure. It is important that as many variables as possible be consistent when personalizing constants for an IOL. These variables include:

- Diagnostic Technician
- Diagnostic Equipment (A-scan, Keratometer)
- Surgical Technique
- Surgical Equipment
- Patient Pathology
- IOL Manufacturer and Model
- IOL Calculation Formula

For this reason, the Accutome A-Scan Plus tracks personalized constants for each IOL and formula separately.

The process for personalizing lens constants involves entering postoperative results and allowing the Accutome A-Scan Plus to recalculate the constants used in the calculation formulas. The instrument tracks all the data entered in the postoperative results and optimizes all the data to determine the new formula constant.



## How to Personalize Constants

The process of personalizing IOLs consists of:

- Selecting IOL Groups and Lenses
- Entering Postoperative Results
- Updating the IOL Constants

All personalization of IOL Constants takes place at the Personalize IOL Screen. The Personalize IOL Screen can be accessed from the Calculate IOL Screen via the IOL Groups Screen, or by pressing the Calculate button twice. To access the Calculate IOL Screen, and subsequently the IOL Groups screen, press the Calculate button, located at the right side of the front panel. The Calculate IOL Screen shown in Figure 10-1 below will be displayed.

### Accessing the Personalize IOLs Screen

Starting at the Calculate IOL Screen:

1. In the Calculate IOL Screen, press the button beneath the selection “IOL Groups...”. The IOL Groups screen will be displayed.

Indicates eye has had refractive surgery										Calculate IOL	
Group	William Smith									OD	
IOL	SN60WF			MA60AC			MTAU40			Phakic	
Hof O	5.37			5.20			3.39			Rx Surg <input type="checkbox"/> No	
Hof	1.620			1.450			-0.306			AXL	
SRK/T	5.40			5.21			3.28			24.08	
Haig	1.714	0.400	0.100	1.527	0.400	0.100	-0.410	0.400	0.100	K1 44.50 D	
	Power	Refr		Power	Refr		Power	Refr		K2 44.25 D	
	17.50	0.34		17.25	0.32		14.75	0.30		Target 0.00 D	
	17.75	0.18		17.50	0.16		15.00	0.11			
	18.00	0.01		17.75	-0.01		15.25	-0.08			
	18.25	-0.15		18.00	-0.18		15.50	-0.27			
	18.50	-0.32		18.25	-0.35		15.75	-0.46			
Target	18.02			17.73			15.15				
Emme	18.02			17.73			15.15				
Formula	<input type="checkbox"/> Hoffer Q <input checked="" type="checkbox"/> Holladay <input type="checkbox"/> SRK/T <input type="checkbox"/> Haigis									AXL 1 24.11 2 24.06 3 24.07 4 24.05 5 24.09 Avg 24.08 Dev 0.02	
Patient	macqueen, john ID sn10G4222										
Select IOL Group	Select Formula	Compare ON	Compare OFF	OD	OS	Start New Patient	IOL Groups...				

Figure 10-1 Calculate IOL Screen - IOL Groups Selection

- In the IOL Groups screen press the button beneath the selection "Personalize IOLs...". The Personalize IOLs screen will be displayed.

Postoperative Results										Personalize IOLs			
		Description				Hof Q ACD	HoI SF	SRK/T ACD	Haigis a0				
Group 1	>	SI40B				5.26	1.507	5.28	0.462				
Dr. Niels		SI60				5.37	1.620	5.40	1.714				
		AC Lens				3.21	-0.475	3.09	-0.597				
Postoperative Results													
Patient	AXL	ACD	K1	K2	Pwr	Sph	Cyl	Form	Constant				
Nancy OS	24.40	3.80	39.25	38.75	22.50	-0.99	0.00	Haig	a0	-0.49			
Ryan OD	24.12	3.72	42.50	42.00	20.50	-0.50	0.23	Haig	a0	0.68			
Ryan OS	24.12		39.25	38.75	20.00	-0.37	0.21	Haig	a0				
Ryan OD	24.73	3.72	42.50	42.00	18.50	-0.29	0.00	Haig	a0	0.74			
Ryan OD	24.12	3.72	42.50	42.00	20.50	-0.11	0.04	Haig	a0	0.90			
ASCRS2005 OD	24.12	3.72	42.50	42.00	22.00	-0.04	0.07	Haig	a0	1.74			
ASCRS2005 OS	24.12	3.72	42.50	42.00	20.50	-0.03	-0.04	Haig	a0	0.93			
ASCRS2005 OD	24.12	3.72	42.50	42.00	21.50	-0.03	0.04	Haig	a0	1.49			
CWH OS	22.54	4.04	39.25	38.75	29.00	0.00	0.00	Haig	a0	0.21			
	23.57					0.00	0.00	Haig	a0				
12 results						Show			#				
						Hoffer Q	ACD	4.98	10				
						Holladay	SF	1.303	10				
						SRK/T	ACD	5.19	10				
						> Haigis	a0	0.767	9				
Next IOL/Group	Delete Result	Delete All Results	Paste Patient...	Update IOL Constant...	Done...								

Figure 10-2 Personalize IOLs Screen

### Personalize IOLs Screen

The Personalize IOLs screen displays a group field at the top left corner and to the right of the group field is an IOL table that displays the lenses for the currently selected group. Below the group field and IOL table is the Postoperative Results table.

To personalize an IOL's constants, it is first necessary to enter postoperative results for a selected IOL group and lens.

---

### **Personalize IOLs Screen Soft Menus**

At the bottom of the Personalize IOLs screen are the following soft menu selections:

- Next IOL/Group - selects the next IOL in the current group and then scrolls through IOL Group and associated lenses
- Delete Result - deletes the currently selected postoperative results, for the selected IOL within the selected IOL group
- Delete All Results - deletes all postoperative results for the selected IOL within the selected IOL Group
- Paste Patient - pastes current Patient records into the Postoperative Results table
- Update IOL Constant... - displays the Update IOL Constant screen for updating constants

### **Selecting an IOL Group and Lens**

There are two ways to select an IOL Group and Lens: You can use the knob and first select and activate the IOL Group, and then select and activate the IOL Table, and then select and activate the IOL, or you can continuously press the button beneath the Next IOL/Group soft menu selection.

### **Next IOL/Group**

The Next IOL/Group selection scrolls through all entered IOL Groups and their associated lenses. Once you reach the last IOL in a group, the selection moves down to the next IOL group and scrolls through the next group's IOLs, and so on until the user reaches the end of the IOL Groups. If you then continue to press the button for the Next IOL/Group selection, the A-Scan will display the top of the list.

### Selecting IOL Group with the Knob

To select an IOL Group and IOL:

1. In the Personalize IOLs screen, rotate the knob to select the IOL Group field, indicated by a solid black border. You can also press the button beneath the selection 'Next IOL/Group' to select an IOL Group.
2. Press the knob or the  $\checkmark$  button, to activate the field, indicated by a dashed border.
3. Within the IOL Group field, rotate the knob to select one of the pre-entered IOL groups.
4. Press the knob or the  $\checkmark$  button, to save the selected IOL Group and to deactivate the field.
5. Rotate the knob to select the IOL table which contains the lenses for the selected IOL group; selection indicated by a solid black border.
6. Press the knob or the  $\checkmark$  button, to activate the IOL table, indicated by a dashed border.
7. Within the IOL table, rotate the knob to select the lens for which you will be entering postoperative results. You can also press the button beneath the selection 'Next Group/IOL' to select the IOL.
8. Press the knob to save the IOL selection and to deactivate the IOL table.

### Entering Postoperative Results

Part of the process personalizing IOLs is to enter patient postoperative results so that the results can be used in calculating the new constant. It is important that as many variables of the postoperative results be kept constant; e.g. the results are all taken from the same machine using the same lens and formula. See the "Overview" section at the beginning of this chapter for more information.

Part of each postoperative result is the Patient information that includes:

- Patient Name/ID
- AXL
- ACD
- K1
- K2

There are two ways to enter patient information: you can select and activate the Postoperative Results table, then select and activate each Patient field and manually enter the information or you can use the soft menu selection 'Paste Patient...'

### **Pasting Patient Information**

When you press the button beneath the soft menu selection 'Paste Patient...' the soft menu on the Personalize IOLs screen changes to Paste Patient selections. At any point on Personalize IOLs screen, no matter what field is active you can paste current patient info.

Note:

*The Paste Patient function is only available for the currently selected patient.*

1. Press the button beneath the 'Paste Patient' selection.
2. The soft menu selections will change as follows:
  - Paste Name, Paste ID - will toggle between pasting the patient name or ID
  - Paste OD - will paste all Patient OD information
  - Paste OS - will paste all Patient OS information
3. Press the button beneath the 'Paste OD' soft menu selection and all Patient OD information will be automatically entered into the Postoperative Results table.
4. Press the button beneath the 'Paste OS' soft menu selection and all Patient OS information will be automatically entered into the Postoperative Results table.
5. Enter the Postoperative Results described in the "Entering Remaining Postoperative Results" section of this manual.

### Manually Entering Patient Information

1. Rotate the knob to select the Postoperative Results table, indicated by a solid black border.
2. Press the knob or the  $\checkmark$  button, to activate the postoperative results table.
3. Rotate the knob and select the Patient field of the first postoperative result that you are entering. The last row of the table is where you can enter postoperative results. If the row is not there, you have reached the maximum number of results (50).
4. Enter the Patient ID.
5. Press the knob or the  $\checkmark$  button, to save the entered ID.
6. Rotate the knob and select the AXL field of the first postoperative result that you are entering.
7. Enter the AXL value.
8. Enter the ACD value - required for Haigis formula.
9. Press the knob or the  $\checkmark$  button, to save the entered value.
10. Rotate the knob and select the K1 field.
11. Enter the K1 value.
12. Press the knob or the  $\checkmark$  button, to save the entered value.
13. Continue entering the field values until you have keyed in all the postoperative values for:
  - AXL - Axial Length in mm
  - K1, K2 - Keratometry measurements in Diopters or mm

Note:

*The "0.00" values for the Sph and Cyl cells of the Postoperative Results table are present to indicate the last row of the table.*

### **Entering Remaining Postoperative Results**

After all Patient Calculation information has been either pasted or manually entered, select activate and enter the following fields.

- Power - Power of IOL implanted in Diopters
- Sphere - Spherical postoperative refraction in Diopters
- Cyl - Cylinder postoperative refraction in Diopters

### **Deleting Postoperative Results**

Normal Postoperative results are essential in determining an effective personalized IOL constant. There may be times that you would like to delete some or all of the postoperative results; e.g. a value is very high or very low with respect to the average (outliers), entered data inaccurate, etc.

The Personalize IOLs Screen provides two methods of deleting postoperative results; you can delete the currently selected result or you can delete all postoperative results for the current IOL.

### **Deleting Current Postoperative Result**

To delete the current postoperative result:

1. Ensure that the result you would like to delete is selected (there should be a cell with a solid black border).
2. Press the button beneath the selection “Delete Current Result”.
3. The Accutome A-Scan Plus will then query you “Are you sure?”. Press the button beneath the selection “Yes” to continue, or press the Check button ( ✓ ) located at the right side of the front panel.
4. To discontinue deleting the current result, press the button beneath the selection “Cancel”, or press the Delete button ( X ) located at the right side of the front panel.

### **Deleting All Postoperative Results**

To delete all postoperative results for the current IOL:

1. Press the button beneath the selection "Delete All Results".
2. The Accutome A-Scan Plus will then query you "Are you sure?". Press the button beneath the selection "Yes" to continue, or press the Check button ( $\checkmark$ ) located at the right side of the front panel.
3. To discontinue deleting all the results, press the button beneath the selection "Cancel", or press the Delete button ( X ) located at the right side of the front panel.

### **How to View Individual Results for a Formula**

To view the individual results for a formula:

1. Select the Average Table.
2. Press the knob or the  $\checkmark$  button.
3. Select the formula.

Individual results are shown for the selected formula for each patient. This is a view option only and does not affect the averages or results in any way.

### **How to Sort Postoperative Results**

The Accutome A-Scan Plus provides the ability to sort Patient records by several fields:

- Patient
- AXL
- ACD
- K1
- K2
- Pwr
- Sph
- Cyl
- Formula & Constant

The sort fields are located above the Postoperative Results table.



To sort Postoperative results by a field:

1. Within the Personalize IOLs Screen, rotate the knob to select a sort field, indicated by a solid black border. The A-Scan will only select the current sort field. To select another sort field you must activate the current sort field first.
2. Press the knob or the  $\sqrt{\quad}$  button, to activate the field, indicated by the dashed border.
3. If you want to select another of the sort fields, rotate the knob until you have selected the appropriate field.
4. With the field selected by which you would like to sort, press the knob to change the sort order. If you activate the field more than once, the A-Scan will toggle the sort order of the active field from ascending to descending and vice versa.
5. Press the knob or the  $\sqrt{\quad}$  button, to save the sort and to deactivate the field.

### **How to Update IOL Constants**

While you enter postoperative results you will notice the data change in the Average table, located at the bottom right corner of the screen. The Average Table displays a count of postoperative results for each Calculation Formula (Hoffer Q, Holladay, and SRK/T and Haigis). The Average Table also displays the average IOL Constant extracted from the postoperative results.

The process for updating IOL constants consists of going to the Personalize IOLs Screen and selecting an IOL Group, associated lens and formula, and updating the constant for the selected formula. When you have determined you have enough postoperative results to update the IOL constants:

1. In the Personalize IOLs Screen, press the button below the selection "Update IOL Constant...". The Update IOL Constants Screen will be displayed. You can also press the dedicated Calculate button a second time to reach the screen.

**Update IOL Constants Screen**

The Update IOL Constants Screen (see Figure 10-3 below) displays an IOL Group field in the upper left corner. Located to the right of the Group field is a table displaying the selected IOL Group's lenses and the lenses' current formula constants. The lens name that is in white text against a black background is the currently selected lens.

The Average Table (from the Personalize IOLs Screen) is also displayed in the bottom right corner of the screen. The table displays the IOL constant information, optimized from postoperative results, for the currently selected lens. From this screen it is possible to select an IOL Group and update the IOL Constants for a selected lens and formula.

Note:

*The Haigis formula does not do an average but rather a best fit regression. The other formulas calculate the 'average'*

The screenshot shows the 'Update IOL Constants' screen. At the top left, the 'IOL Group' is 'Group 1' and 'Dr. Niels'. The main table lists lenses: SI40B (selected), SI60, and AC Lens. Each lens has columns for Hof Q ACD, HoI SF, SRK/T ACD, and Haigis a0. An 'Averages' table in the bottom right shows optimized constants for Hoffer Q, Holladay, SRK/T, and Haigis formulas. At the bottom, there are buttons for 'Next IOL/Group', 'Update Hof Q ACD', 'Update HoI SF', 'Update SRK/T ACD', 'Update Haigis a0', and 'Done...'.

Description	Hof Q ACD	HoI SF	SRK/T ACD	Haigis a0
> SI40B	5.26	1.507	5.28	0.462
SI60	5.37	1.620	5.40	1.714
AC Lens	3.21	-0.475	3.09	-0.597

Averages		#
Hoffer Q	ACD	4.98 10
Holladay	SF	1.303 10
SRK/T	ACD	5.19 10
Haigis	a0	0.767 9

**Figure 10-3 Update IOL Constants Screen**

### Selecting an IOL Group and Lens

Just like on the Personalize IOLs Screen, there are two ways to select an IOL Group and Lens in the Update IOL Constants Screen: you can use the knob and first select and activate the IOL Group, and then select and activate the IOL Table, and then select and activate the IOL, or you can continuously press the button beneath the Next IOL/Group soft menu selection.

If you are selecting and IOL Group IOL with the knob:

1. In the Update IOL Constants Screen, rotate the knob to select the IOL Group field, indicated by a solid black border. You can also press the button beneath the selection 'Next IOL/Group' to select an IOL Group.
2. Press the knob or the  $\sqrt{\quad}$  button, to activate the field, indicated by the dashed border.
3. Within the IOL Group field, rotate the knob to select one of the pre-entered IOL Groups.
4. Press the knob or the  $\sqrt{\quad}$  button, to save the selected IOL Group and to deactivate the field.
5. Rotate the knob to select the lens constant table for the selected IOL group. Table selection is indicated by a solid black border.
6. Press the knob or the  $\sqrt{\quad}$  button, to activate the table, indicated by the dashed border.
7. Within the IOL Constants Table, rotate the knob to scroll through the list of lenses.
8. After you have selected the lens, press the knob or the  $\sqrt{\quad}$  button, to activate the appropriate lens and to deactivate the table.

9. The Update IOLs screen will display the formulas requiring constants to be updated, as soft menu selections in black text against a gray background. "Update Hol SF" in black text indicates that the Surgeon Factor (SF) for the Holladay formula needs to be updated.
10. At the bottom of the screen, press the button beneath the appropriate formula to update:
  - Update Hoffer Q ACD
  - Update Hol SF
  - Update SRKT ACD
  - Update Haigis a0
11. After pressing the button beneath the formula requiring its IOL constant to be updated, the new constant will replace the old one in the IOL table.

# 11

## Storing and Recalling Records

### Overview

You can save a patient record at any time for later review or calculation. If you are away from your printer, you can save the current patient measurements and print the patient's record at a later date.

The Accutome A-Scan Plus makes storing a patient record an easy process. The A-Scan has the ability to select multiple locations for the storage of patient information, internally, using the A-Scan memory, externally to either a USB stick or network folder. All waveform measurement and IOL calculation settings and data are stored with each patient record when it is saved. Recalling a patient record at a later date allows you to view the patient record exactly as it was saved. Changes to instrument settings including Eye Types and measurement controls made after the patient is stored and before the patient is recalled, do not effect the recalled patient measurements or IOL calculations.


When you recall a patient record the instrument is set to same settings as when you stored the record. Asterisks will appear if settings have altered.

### How to Store a Record

After you have taken all the desired measurements you can save a Patient's measurements to a record so that you can recall it at a later time.

To save a Patient's record:

1. Press the "Patient Records" button located at the right side of the instrument. The Patient Record Screen as shown in Figure 11-1 on the next page will be displayed.



*Figure 11-1 Patient Record Screen*

2. Press the button below "Save to List". The Accutome A-Scan Plus will store the Patient record and indicate record storage by changing the text beside the Patient ID that the record was stored. There will also be a line added to the Patient Records table.



Figure 11-2 Patient Record Stored

**How to Recall a Record**


You may need to recall a patient record at a later date to review a measurement, or execute a calculation.

To recall a Patient’s record:

1. Press the “Patient Records” button located at the right side of the instrument. The Patient Record Screen as shown in Figure 11-3 on the next page will be displayed.
2. Using the button, located below “Select Location”, select the appropriate record location. This is done by pressing the select location button until the appropriate location is selected. The locations are A-Scan Memory, USB Disk and Network Folder.
3. Within the Patient Records list, rotate the knob to select the correct patient record.
4. Press the ‘Recall for List’ soft menu button to recall the patient. If the current patient has not been saved, the A-Scan will confirm that the current patient data will be lost when the stored patient is recalled.

Note:

*The network must be activated in order to allow retrieval of a record from a network domain. Please refer to the network addendum for more detailed information.*



**Figure 11-3** *Recalling a Patient Record*

5. Press the Measure or Calculate button, located at the right side of the front panel. The A-Scan will display the recalled patient record.






Figure 11-4 Recalled Patient Record

**How to Adjust Parameters on Saved Records**

You can adjust any of the waveform parameters on a saved record in exactly the same manner as you would on an active waveform.

To adjust parameters, refer to the “Performing Measurements” section of this manual.

**How to Update Calculations**

You can update calculations on a saved record in exactly the same manner as you would perform a calculation on an active measurement.

To update calculations, refer to the “Performing Calculations” section of this manual.

Note:

*Changing patient record does not change the saved record, and the patient record must be saved again. You may also want to delete the previously saved patient so that there is only one record for that patient.*

## How to Sort Patient Records

The Accutome A-Scan Plus provides the ability to sort Patient records by several fields:

- Patient
- ID or Date of Birth
- Date Saved

The sort fields are located above the Patient Records.

To sort Patient records by a field:

1. Within the Patient Records Screen, rotate the knob to selected sort field, indicated by a solid black border. The A-Scan will only select the current sort field. To select another sort field you must activate the current sort field first.
2. Press the knob or the  $\sqrt{\quad}$  button to activate the field, indicated by the dashed border.
3. If you want to select another of the sort fields, rotate the knob until you have selected the appropriate field.
4. With the field selected by which you would like to sort, press the knob to change the sort order. If you activate the field more than once the A-Scan will toggle the sort order of the active field from ascending to descending and vice versa.
5. Press the knob or the  $\sqrt{\quad}$  button to save the sort and to deactivate the field.

# 12

## Printing Records

### How to Print a Record

The Accutome A-Scan Plus makes printing accessible and easy. Whenever you want to print a patient record, or patient measurements, you simply press the Print button. The Accutome A-Scan Plus will provide you with organized, accurate records of patient waveforms and calculations. You can also print any screen by keying “ALT+P” on the keyboard.

Printing also makes a permanent record of the entire state of the instrument including velocity, probe application method, capture mode, eye type, i.e. all recent settings, on an 8 1/2 X 11” piece of paper.

### Screen Printout Formats

The type of page the Accutome A-Scan Plus prints is determined by the screen from which you execute the print command.

The screens and associated printout formats are:

- Measure Screen - will print up to five waveforms for either OD/OS and will display textual description of each waveform
- Calculate IOL Screen - will print out lens calculations, table of measurements and a selected waveform for both OD/OS
- Other Screens - will print the data that is displayed on the screen
- Patient Record Screen - will print out lens calculations, table of measurements and a selected waveform for both OD/OS

### How to Select the Right Printout Format

You should choose the print format according to your needs. For example, if you need to view each of the waveforms for an irregularity, you should print the Measurement printout. If you need only the calculation information, you should print the Calculation printout.

### Sample Printouts

Figure 12-1 below and Figure 12-2 through Figure 12-5 are given to provide you samples of the printout formats.




Figure 12-1 Measurement Printout




Figure 12-2 Calculation Printout and Patient Record Screen

### How to Batch Print

The Accutome A-Scan Plus also provides a batch print capability. During a batch print you can print multiple selected patient records using the IOL Calculation screen print format. As with direct printing, if the Print to Network Link is enabled on the Setup Screen, records that are batch printed will be sent out to the network folder.

Pressing the 'Select All' selects all patients in the patient list. Pressing "Select All" again deselects all patients.

To perform a batch print from the Patient Records screen:

1. Press the "Patient Records" button, located at the right side of the front panel. The Patient Records screen shown below will be displayed.




Figure 12-3 Saved Patient Record Screen

- Using the button, located below “Select Location”, select the appropriate date storage location. This is done by pressing the select location button until the appropriate data storage location is selected. The locations are A-Scan Memory, USB Disk and Network Folder.

Note:

*The network must be activated in order to allow storage to a network domain. Please refer to the network addendum for more detailed information.*


- Using the button, located below save/recall menu, press until the menu changes to the Print menu.



**Figure 12-4 Print Menu Screen**

- Rotate the knob until you have selected the Patient’s record you would like to print.
- Press the button below the “Select for Print” selection.

6. If you would like to select all Patients, press the “Select All” button for one second. Conversely, if you would like deselect Patients already selected for batch print, hold the “Select for Batch Print” button for one second.
7. Continue to select all Patient records that you want to print.
8. Press the “Print” button located at the right side of the front panel.
9. The Accutome A-Scan Plus will print all records selected for batch print.



*Figure 12-5 Saved Patient Records - Select for Batch Print*



**Required Printer**

The Accutome A-Scan Plus will print to most HP printers currently manufactured. The system has over 200 of the most popular HP drives installed, including the popular Desk Jet PCL3, Laser Jet PC5, Office Jet and Photo Smart.

If you do not have an HP printer, the Accutome A-Scan Plus has many generic printer drives.

In addition, as new printer drives become available from Accutome, they can be updated using one of the USB ports.

Please refer to the preference section, “How to Set the Printer” for more information.

# 13

## Maintenance

### **General Maintenance**

Maintenance that should be performed on the Accutome A-Scan Plus consists of activities such as keeping surfaces free of dust and dirt and storing in a dry and cool place so as to not adversely effect electronic parts.

Care must be taken to use only proper non-linting cloths and non-corrosive solvents when cleaning the screen.

**CAUTION:** No abrasives or harsh cleaning solutions should be used while cleaning the Accutome A-Scan Plus.

Refer to Chapter 2 of the user manual for cleaning and sterilization issues pertaining to the probe.

### **Safety Inspections**

Safety Inspections to ensure the Accutome A-Scan Plus remains in perfect operating condition, the device should undergo a monthly safety check involving a visual inspection of the entire system.

### **Visual Inspection**

A visual inspection should be conducted on a monthly basis on all parts of the Accutome A-Scan Plus unit, including the probe and accessories, footswitch and power supply. Special attention should be paid to the connectors and cords/wires.

### **Ultrasound Inspection**

On a monthly basis an evaluation of the ultrasonic probe should be conducted using the test block located on the top of the unit.

Refer to Chapter 3 on how to test the probe using the test block.

### **Calibration of Accutome A-Scan Plus**

The Accutome A-Scan Plus unit is self calibrating and therefore requires no adjusting or further calibration by the user.

### **Battery Disposal**

Follow the procedure outlined below for proper disposal of lithium batteries.

#### **Instructions for Disposal**

1. Guidelines for the disposal of lithium batteries are continually under review. Waste management companies can provide assistance in the disposal of these cells and batteries.
2. Disposal should be done in accordance with applicable regulations, which vary from country to country. In most countries, trashing of used batteries is forbidden and disposal can be done through non-profit organizations mandated by local authorities or organized by professionals.
3. Cells and batteries should not be incinerated, unless suitable procedures are followed and appropriate precautions have been taken by qualified handlers. Exposure of these cells to high temperatures or fire can cause the cells to vent and/or rupture.
4. Used batteries should be shipped with the same regulations as those for new Lithium/ Thionyl Chloride batteries.
5. Accutome recommends that cells and batteries for disposal should be collected, transported and disposed of in a manner that will prevent short-circuit (the terminals taped).
6. Handling of used cells and batteries should be done according to the safety instructions of fresh cells.
7. Recycling of the cells and batteries should be done in authorized facilities, through licensed waste carrier. A recycler in US is listed below.

#### **Disposal in Europe**

In accordance with applicable EU guidelines and national regulations at the time at which the product was brought onto the market, the product specified on the consignment note is not to be disposed of via the domestic waste system or communal waste disposal facilities.

For further information on disposal of this product, please contact your local dealer or the manufacturer or its legal successor company. Please read the latest Internet information provided by the manufacturer.

Where the product or its components are resold, the seller must inform the buyer that the product is to be disposed of in accordance with the currently applicable national regulations.

**Disposal in US.**

Lithium batteries are neither specifically listed nor exempted from the Federal Environmental Protection Agency (EPA) hazardous waste regulations, as conveyed by the Resources Conservation and Recovery Act (RCRA). The only metal of possible concern in the cell is the lithium metal that is not listed or characterized as a toxic hazardous waste. Significant amount of spent cells and batteries that are untreated and not fully discharged are considered as reactive hazardous waste.

Thus, hazardous waste of spent cells and batteries can be disposed after they are first neutralized through an approved secondary treatment prior to disposal (as required by U.S. Land Ban Restriction of the Hazardous and Solid Waste Amendments of 1984).

Disposal of spent batteries should be performed by authorized, professional disposal company which has the knowledge in the requirements of the Federal, the State and the Local authorities regarding hazardous materials, transportation and waste disposal. ***In any case it is recommended to contact the local EPA office.***

**PROPER SHIPPING NAME: Waste lithium Batteries**

**UN NUMBER: 3090**

**LABEL REQUIREMENTS: MISCELLANEOUS, HAZARDOUS WASTE**

**DISPOSAL CODE: D003**

Following is a suggestion for battery recycler and collector in the US:

**ToxCo Inc.**  
**3200E Frontera, Anaheim, California 92806**

**Contact Person- David Miller**

**Email- DMiller320@aol.com**

**Tel- (714) 879 2076**

**Fax (714) 441 0857**

**www.Toxco.com**

# 14

## Specifications

### Overview

This section provides the physical and operational specifications of the Accutome A-Scan Plus.

### Physical Specifications

Table 14-1 below lists the physical specifications of the instrument and associated peripherals.

**Table 14-1 Accutome A-Scan Plus Physical Specifications**

<b>Main Units</b>	
Dimensions	30.2 X 19.05 x 4.83 cm (11.9" x 7.5" x 1.9")
Weight	1.98 Kg (4 lbs, 6 oz).
DC Input	12 V, 1.25 A
<b>Display</b>	
Type	Monochrome Liquid Crystal Display (LCD)
Size	18.29 cm (7.2") diagonal viewable area
Resolution	640 x 480 pixels, 16-shades of gray
<b>External I/O Connectors</b>	
USB Master	USB A Type R/A Dip Triple
USB Slave	USB B Type R/A Dip
Ethernet	Mag45- RJ45 w/Integrated Magnetics
Serial	RS-232C, DCE, 9-pin D-Sub, female
Footswitch	3.5 mm mono phone jack

**Table 14-2 Accutome A-Scan Plus Physical Specifications**

DC Power	2.5mm DC coaxial
<b>Probe (Use only Accutome PN 24-4001)</b>	
Frequency	10 MHz
Dimensions	4.32 cm (1.7") long, 0.63 cm (0.25") diameter
Cable Length	1.5m (5 feet)
Accessories	Tonometer adapter, extension handle with installation tool
<b>Footswitch (Use only Accutome PN 24-4004)</b>	
Dimensions	8.89 X 6.60 X 2.54 cm (3.5" x 2.6" x 1")
Weight	198 g (7 oz.)
Environmental	IP20, IP68
<b>External Power Supply (Use only Accutome PN 24-4008)</b>	
Dimensions	12.95 X 7.87 X 4.06 cm (5.1" x 3.1" x 1.6")
Weight	425 g (15 oz.)
Input Voltage	100 to 240 VAC 50/60 Hz
Power (typical)	15 Watts
Output	12V, 1.25A
Safety	IEC601-1, UL2601, CSA601, CE
<b>Serial Link Port</b>	
Connector	RS-232C, DCE, 9-pin D-Sub, female

## Environmental Specifications

Table 14-3 on the next page lists the Accutome A-Scan Plus system operating and storage values for temperature and humidity.

**Table 14-3 Environmental Specifications**

<b>Temperature</b>	
Operating	+10° C to +40° C
Storage	-20° C to +60° C
<b>Relative Humidity</b>	
Operating	20% to 80% (non-condensing)
Storage	15% to 90% (non-condensing)
<b>Atmospheric Pressure</b>	
Operating	700 - 1060 hPa
Storage	500 - 1060 hPa

**Measurement Accuracy**

Table 14-4 below lists the accuracy for each type of measurement.

Clinical Accuracy (1 s)	0.1 mm
Electronic Resolution (@1550 m/s)	0.016 mm

**Table 14-4 Measurement Accuracy**

<b>Measurement</b>	<b>Clinical Accuracy (1 s)</b>	<b>Range</b>
Axial Length	0.1 mm	0.01 to 63.6 mm @1555 m/s
Anterior Chamber Depth	0.1 mm	0.01 to 62.7 mm @1532 m/s
Lens Thickness	0.1 mm	0.01 to 67.2 mm @1641 m/s
Vitreous	0.1 mm	0.01 to 62.7 mm @1532 m/s



## Operating Modes

The following table summarizes the mode/application possibilities for each system/transducer combination:

**Table 14-5 Operating Mode(s)**

Clinical Application	A	B	M	PED	CWD	CD	Combined (Specify)	Other (Specify)
Ophthalmic	X							
Fetal Imaging & Other*								
Cardiac, Adult								
Pediatric								
Peripheral Vessel								

\* Abdominal, Intraoperative, Pediatric, Small Organ (breast, thyroid, testes, etc.), Neonatal Cephalic, Adult Cephalic, Musculo-Skeletal (conventional), Musculo-Skeletal (superficial)

† Examples may include: Amplitude Doppler, 3-D Imaging, Harmonic Imaging, Tissue Motion Doppler, Color Velocity Imaging.

## Formula References

Table 14-6 below lists the references for the calculation formulas used in the Accutome A-Scan Plus.

**Table 14-6 Formula References**

Hoffer Q	<p>Hoffer Q formulas are implemented as defined in “The Hoffer Q formula: A comparison of theoretic and regression formulas”, by HOFFER KJ: The Hoffer Q formula: A comparison of theoretic and regression formulas. J Cataract Refract Surg, 19:700-712, 1993; ERRATA 20:677, 1994.</p> <p>The article and its errata do not mention that restricting the calculated post operative ACD to 2.5 to 6.5 should no longer be done, as Dr. Hoffer now requires.</p>
Holladay	<p>Holladay formulas are implemented as defined in “A Three Part System For Refining Intraocular Lens Power Calculations”, by Jack T. Holladay,</p> <p>Journal of Cataract and Refractive Surgery, Vol 14, Jan 1988.</p>
SRK/T	<p>SRK/T formulas are implemented as defined in “Lens Implant Power Calculation, A Manual For Ophthalmologists &amp; Biometrists”, by John A. Retzlaff, Donald R. Sanders, Manus Kraff, Third Edition.</p>
Haigis	<p>“Formulas for the IOL calculation according to Haigis”, by Dr. W. Haigis, Wuerzburg July 8, 2002. The formula has been implemented as specified by Dr. Haigis and has received compliance certification from Dr. Haigis.</p>

## Storage/Range Specifications

Table 14-7 below lists the data storage and range specifications of the Accutome A-Scan Plus.

**Table 14-7 Data Specifications**

<b>Stored Data Capacity</b>	
Waveforms / Patient	10
Stored Patients	100
IOLs	45 total; 15 groups of 3
Post Operative Results	1000 total; 50 per IOL
<b>Waveform Data</b>	
Data Points Per Waveform	4096
Max Depth At 1555 m/sec	64 mm
Gain Adjustment Range	23 dB
<b>Eye Type Storage</b>	
Factory Eye Types	7
User Eye Types	2
Custom Eye Types	Unlimited
Factory Aqueous/Vitreous Materials	3
User Aqueous/Vitreous Materials	2
Factory Lens Materials	4
User Lens Materials	2
Material Velocity Range	500 to 9999 m/sec
Assumed Lens Thickness Range	0 to 9.99 mm
K Readings Range	20 to 60 D 5 to 19.99 mm

**Table 14-8 Data Specifications**

<b>Calculation Field Ranges</b>	
Target Refraction Range	-20 to 20 D
Entered AXL range	15 to 40 mm
Entered IOL A-constant range	110.5 to 122.5
Entered IOL ACD range	0.10 to 6.50 mm
Entered IOL SF range	-3.5 to 3.5 mm
Entered ACD range	0.01 mm to 9.99 mm
Entered IOL a0 constant range	-9.999 to 9.999
Entered IOL a1 constant range	-0.999 to 0.999
Entered IOL a2 constant range	-0.999 to 0.999
<b>Accutome Clock</b>	
Clock/calendar valid	Through year 2099

**Acoustic Output**

Table 14-9 below provides the acoustic output reporting for the following:

**Transducer Model:** Accutome A-Scan Plus

**Operating Mode:** A-Scan

**Application(s):** Ophthalmic

**Table 14-9 Acoustic Output Reporting Table for Track 1  
Non-Autoscanning Mode**

Acoustic Output		MI	ISPTA.3 (mW/cm <sup>2</sup> )	ISPPA.3 (W/cm <sup>2</sup> )	
<b>Global Maximum Value</b>		0.14	2.62	4.11	
Associated Acoustic Parameter	Pr.3 (MPa)	0.41	----	----	
	Wo (mW)	----	0.198	0.198	
	fc (MHz)	9.34	9.34	9.34	
	Zsp (cm)	0.50	0.50	0.50	
	Beam Dimesions	x-6 (cm)	----	0.246	0.246
		y-6 (cm)	----	0.332	0.332
	PD (msec)	0.11	----	0.11	
	PRF (Hz)	5.8	----	5.8	
	EBD	Az. (cm)	----	0.35	----
Ele. (cm)		----	0.35	----	

**Table 14-10 Acoustic Output Reporting Table for Track 1  
Non-Autoscanning Mode**

Operating Control Conditions	Control 1			
	Control 2			
	Control 3			
	Control 4			
	Control 5			

These values are based on measurements of production units.

The “derated” intensity calculations are based on the measured center frequency of the acoustic signal ( $f_c$ , MHz) and the distance from the transducer under test to the hydrophone ( $z$ , cm) using the derating factor  $e^{-0.069f_c z}$ .

### **EMC Compliance Information**

Information Medical Electrical Equipment needs special precautions regarding EMC and needs to be installed and put into service according to the EMC information provided in this manual.

Portable and mobile RF communications equipment can affect Medical Electrical Equipment.

**WARNING!!** The use of Accessories, transducers and cables other than those specified by the manufacturer may result in increased Emissions or decreased Immunity of the A-Scan Plus.

**WARNING!!** The A-Scan Plus should not be used adjacent to or stacked with other equipment and that if adjacent or stacked use is necessary, the A-Scan Plus should be observed to verify normal operation in the configuration in which it will be used.

**Table 14-11 Guidance and manufacturer's declaration-  
electromagnetic emissions**

The A Scan Plus is intended for use in the electromagnetic environment specified below. The customer or the user of the A-Scan Plus should assure that it is used in such an environment.		
Emissions test	Compliance	Electromagnetic environment - guidance
RF Emissions CISPR 11*	Group 1	The A-Scan Plus uses RF energy only for its internal function. Therefore, its RF emissions are very low and not likely to cause any interference in nearby electronic equipment
RF Emissions CISPR 11*	Class A	The A-Scan Plus is suitable for use in all establishments other than domestic and those directly connected to the public low voltage power supply network that supplies buildings used for domestic purposes
Harmonic emissions IEC 61000-3-2	Class A	
Voltage fluctuations/ flicker emissions IEC61000-3-3	Complies	

**Table 14-12 Guidance and manufacturer's declaration -  
electromagnetic immunity**


The A Scan Plus is intended for use in the electromagnetic environment specified below. The customer or the user of the A-Scan Plus should assure that it is used in such an environment.			
Immunity Test	IEC 60601 test level	Compliance level	Electromagnetic environment guidance



**Table 14-12 Guidance and manufacturer's declaration -  
electromagnetic immunity**

Electrostatic Dis-charge (ESD) IEC 61000-4-2	+/- 6kV Contact  +/- 8kV Air	+/- 6kV Contact  +/- 8kV Air	Floors should be wood, con-crete or ceramic tile. If floors are covered with synthetic material, the relative humidity should be at least 30%.
Electrical fast-transient/burst IEC 61000-4-4	+/- 2kV for power supply lines  +/- 1kV for input/ out-put lines	+/- 2kV for power supply lines  +/- 1kV for input/ output lines	Mains power quality should be that of a typical commercial or hospoital environment.
Surge IEC 61000-4-5	+/- 1kV differential mode  +/- 2kV common mode	+/- 1kV differential mode  +/- 2kV common mode	Mains power quality should be that of a typical commercial or hospoital environment.
Voltage dips, short interruptions and voltage variations on power supply input lines IEC 61000-4-11	<5 % UT (>95 % dip in UT) for 0,5 cycle  40 % UT (60 % dip in UT) for 5 cycles  70 % UT (30 % dip in UT) for 25 cycles  <5 % UT (>95 % dip in UT) for 5 sec	5 % UT (>95 % dip in UT) for 0,5 cycle  40 % UT (60 % dip in UT) for 5 cycles  70 % UT (30 % dip in UT) for 25 cycles  <5 % UT (>95 % dip in UT) for 5 sec	Mains power quality should be that of a typical commer-cial or hospotal environment. If the user of the A-Scan Plus requires continued operation during power mains interruptions, it is recommended that the A-Scan Plus be powered from an uninterruptible power supply or a battery.
Power frequency (50/60Hz) magnetic field IEC 61000-4-8	3 A/m	3 A/m	Power frequency magnetic fields should be at levels characteristic of a typical location in a typical commercial or hospital environment
NOTE UT is the a.c. mains voltage prior to application of the test level.			

**Table 14-13 Guidance and manufacturer's declaration - electromagnetic immunity**

The A Scan Plus is intended for use in the electromagnetic environment specified below. The customer or the user of the A-Scan Plus should assure that it is used in such an environment.			
Immunity Test	IEC 60601 test level	Compliance level	levelElectromagnetic environment - guidance
Conducted RF IEC 61000-4-6			<p>Portable and mobile RF communications equipment should be used no closer to any part of the A-Scan Plus, including cables, than the recommended separation distance calculated from the equation applicable to the frequency of the transmitter.</p> <p>Recommended separation distance</p> $D = 1.2 \sqrt{P}$ $D = 1.2 \sqrt{P} \quad 80 \text{ MHz to } 800 \text{ MHz}$ $D = 2.3 \sqrt{P} \quad 800 \text{ MHz to } 2,5 \text{ GHz}$ <p>where P is the maximum output power rating of the transmitter in watts (W) according to the transmitter manufacturer and d is the recommended separation distance in metres (m). Field strengths from fixed RF transmitters, as determined by an electromagnetic site survey, should be less than the compliance level in each frequency range.<sup>b</sup></p> <p>Interference may occur in the vicinity of equipment marked with the following symbol:</p> 
Radiated RF IEC 61000-4-3			
NOTE 1: At 80 MHz and 800 MHz, the higher frequency range applies.			

NOTE 2: These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption and reflection from structures, objects and people.

\*Field strengths from fixed transmitters, such as base stations for radio (cellular/cordless) telephones and land mobile radios, amateur radio, AM and FM radio broadcast and TV broadcast can-not be predicted theoretically with accuracy. To assess the electromagnetic environment due to fixed RF transmitters, an electromagnetic site survey should be considered. If the measured field strength in the location in which the A-Scan Plus is used exceeds the applicable RF compliance level above, the A-Scan Plus should be observed to verify normal operation. If abnormal performance is observed, additional measures may be necessary, such as re-orienting or relocating the A-Scan Plus.

\*Over the frequency range 150 kHz to 80 MHz, field strengths should be less than 3 V/m

**Table 14-14 Recommended separation distances between portable and mobile RF communications equipment and the A-Scan Plus**

<p>The A-Scan Plus is intended for use in an electromagnetic environment in which radiated RF disturbances are controlled. The customer or the user of the A-Scan Plus can help prevent electromagnetic interference by maintaining a minimum distance between portable and mobile RF communications equipment (transmitters) and the A-Scan Plus as recommended below, according to the maximum output power of the communications equipment.</p>			
Rated maximum output power of transmitter W	Separation distance according to frequency of transmitter m		
	150 kHz to 80 MHz $D = 1.2 \sqrt{P}$	80 MHz to 800 MHz $D = 1.2 \sqrt{P}$	800 MHz to 2,5 GHz $D = 2.3 \sqrt{P}$
0,01	0.12	0.12	0.23
0,1	0.38	0.38	0.73
1	1.2	1.2	2.3
10	3.8	3.8	7.3
100	12	12	23
<p>For transmitters rated at a maximum output power not listed above, the recommended separation distance <math>d</math> in metres (m) can be estimated using the equation applicable to the frequency of the transmitter, where <math>P</math> is the maximum output power rating of the transmitter in watts (W) according to the transmitter manufacturer.</p> <p>NOTE 1 At 80 MHz and 800 MHz, the separation distance for the higher frequency range applies.</p> <p>NOTE 2 These guidelines may not apply in all situations. Electromagnetic propagation is affected by absorption and reflection from structures, objects and people.</p>			

# 15 Warranty and Repairs

## **Warranty**

Accutome, Inc. warrants its new equipment to be free from defects in workmanship or materials. Any product that is proven to be defective will be repaired or replaced at our discretion, free of charge, up to one year from the date of purchase by the initial user of the equipment from Accutome, Inc. or any of its authorized distributors.

This warranty covers all repairs and servicing of parts that proved defective by manufacture and not by misuse or mishandling. This type of service will be handled by our trained sales force, or if necessary, in our home office. Shipping charges for returns or repair of non-warranted items will be the responsibility of the customer. Alteration, repair or modification of any product that is performed by persons not authorized by Accutome, Inc. will result in immediate loss of warranty.

---

## Product Returns

Follow the instructions given below to return products to Accutome Inc.

### Service and Repair

Before returning instruments for service or repair, contact the Accutome Technical Service Group for a Return Goods Authorization (RGA) number.

Toll Free (in USA): 1-800-979-2020  
Tech Service: 1-610-889-0200  
Fax: 1-610-889-3233

After receiving authorization, print the RGA number on the outside of the package and send the instrument to:

Technical Service Group  
Accutome, Inc.  
3222 Phoenixville Pike  
Malvern, PA 19355

### All Other Returns

Returns for non-service related reasons must be authorized by the Accutome Customer Service Department. Please contact Customer Service for an RGA number.

Merchandise returned within 60 days of date of invoice will be credited as follows:

- Full credit for all merchandise returned in resalable condition

### Non-Returnable Merchandise

Accutome Inc. will not authorize a return for:

- Merchandise held longer than 60 days

## Replacement Parts

Table 15-1 below lists items that are available from Accutome, Inc. or from your local sales representative. Please be sure to use the Accutome part number for the item when placing an order.

**Table 15-1 Accutome Replacement Parts**

<b>Description</b>	<b>Accutome Part No.</b>
<b>Standard Parts</b>	
Probe Kit	24-4001
Footswitch	24-4004
Power Supply	24-4008
Power Supply Cable	24-4012 (United States)
<b>Optional Parts</b>	
Immersion Shell	24-4100
Serial Link Cable	24-401
CD (A-Scan Manager)	24-4210
Keyboard	24-4203
USB Stick	24-6210

## Documentation

Accutome will make available on request circuit diagrams, component parts, lists, descriptions, calibration instructions or other information that will assist qualified technical personnel to repair the Accutome A-Scan plus.

**Network Addendum**

The Accutome A-Scan Plus has an active Ethernet port that can be turned on to allow the system to connect to a shared folder within a secure class-C network domain.

This shared folder must be located within the operating system. We support the use of Windows XP, Vista or Windows 7 Professional. Use of an earlier version of Windows is not recommended.

The network address can be automatically acquired through DHCP server. If greater security is required, the static IP address, Subnet Mask and the Gateway Address may be manually entered.

When the Accutome A-Scan Plus network is enabled, the name of the host pc must be known and entered into the configuration page.

In addition, the name of the folder, user name and the password must be entered.

Please refer to the set up pages for instruction on how to access the network configuration.

Accutome strongly recommends the use of a trained Information Technology Specialist when connecting the A-Scan to the network domain.

Accutome has Information technology specialists available to assist with connecting the network.